

TOSHIBA

Toshiba B-FP800-DCJA-QM-R Owner's Manual

Dc jack plug adapter

1
2
3
4
5
6
7
8
9
10

•

Bookmarks

[Download this manual](#)

Quick Links



! 0 0 T S C C 0 3 2 6 2 0 1 !

DC Jack plug adapter

TOSHIBA

B-FP800-DCJA-QM-R



Owner's Manual

DC Jack plug adapter

B-FP800-DCJA-QM-R

Owner's Manual

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba B-FP800-DCJA-QM-R

[Adapter TOSHIBA B-EP800-DC48-QM-R Owner's Manual](#)

Toshiba dc adapter (3 pages)

[Adapter Toshiba B-EP800-AC-QM-R Owner's Manual](#)

Ac adapter (3 pages)

[Adapter Toshiba B-FP800-AC-QM-S Owner's Manual](#)

(12 pages)

[Adapter Toshiba B-EP802-DC12-QM-R Owner's Manual](#)

(8 pages)

[Adapter Toshiba VF-S15 Instruction Manual](#)

Option adapter (3 pages)

[Adapter Toshiba VF-S15 Instruction Manual](#)

Option adapter (2 pages)

[Adapter Toshiba TCB-DK01SS-E Owner's Manual](#)

Dyna-kit communication adapter (12 pages)

[Adapter Toshiba Canvio Cast User Manual](#)

(50 pages)

[Adapter Toshiba VF-S15 Instruction Manual](#)

Option adapter (2 pages)

[Adapter Toshiba 4400 Series Installation Instructions Manual](#)

Ups seismic adapter kit (12 pages)

[Adapter Toshiba WUS-G06G-JT User Manual](#)

802.11b/g wireless usb adapter (48 pages)

[Adapter Toshiba TCB-PCNT20E Installation Manual](#)

For air conditioner (7 pages)

[Adapter Toshiba Canvio Wireless Adapter User Manual](#)

(84 pages)

[Adapter Toshiba Sitecom CN-512 Full Manual](#)

Usb bluetooth adapter (78 pages)

[Adapter Toshiba TCB-SS1UU-E Owner's Manual](#)

Link (22 pages)

[Adapter Toshiba WLM-10UB1 Owner's Manual](#)

Usb wifi adapter for toshiba blu-ray disc/dvd player (2 pages)

Summary of Contents for Toshiba B-FP800-DCJA-QM-R

[Page 1](#) ! 0 0 T S C C 0 3 2 6 2 0 1 ! DC Jack plug adapter B-FP800-DCJA-QM-R Owner's Manual...

[Page 2](#) No user-serviceable parts inside. Refer servicing to qualified service personnel. This product is designed for commercial usage and is not consumer product. PRINTED IN INDONESIA © 2016 TOSHIBA TEC CORPORATION All Rights Reserved SPTM-0280 1-11-1, Osaki, Shinagawa-ku, Tokyo 141-8562, JAPAN...

[Page 3](#) Avant d'utiliser cet équipement, veuillez lire entièrement ce manuel, et conservez ce manuel pour un usage futur. AVERTISSEMENT! RISQUE DE CHOC ELECTRIQUE PAS • POUR

EVITER LES RISQUES D'INCENDIE OU DE CHOC ELECTRIQUE, NE PAS EXPOSER A LA PLUIE OU A L'HUMIDITE. •...

[Page 4](#) English> CAUTION! Do not use this device for any devices other than the B-FP3D series portable printer. <Franaçis> PRÉCAUTIONS! N'utilisez pas ce dispositif pour une machine autre que les imprimantes portables de la gamme FP3D. <Deutsch> Achtung! Benutzen Sie dieses Netzteil für kein anderes Modell außer dem B-FP3D <Español>...

[Page 5: Before Using This Product](#)

Before connecting this device to the printer, please make sure that the battery pack is in the printer. We are not responsible for any result caused by use of the printer without the battery pack loaded inside. If any difficulty should arise, unplug the unit and contact your Authorised TOSHIBA TEC representative.

[Page 6](#) AVERTISSEMENT Ce sigle indique un risque de mort ou de blessure sévère si les matériels sont manipulés de façon impropre ou contraire aux indications suivantes. □ N'utilisez cet adaptateur qu'avec les imprimantes portables B-FP3D Le non respect de cette consigne peut entraîner l'explosion, l'embrassement ou la surchauffe du matériel connecté. □...

[Page 7](#) Connecting the DC Input Connect the DC Input to the B-FP3D printer using the following procedure. For how to check the charge status, please refer to the Owner's Manual of the B-FP3D series Owner's Manual. 1. Make sure that the battery pack is in the printer. 2.

[Page 8: Troubleshooting](#)

If you have any problems on this product or the printer when in use, please check the following point first. If a problem cannot be solved by taking actions described below, disconnect this product from the printer and contact the dealer or an authorised TOSHIBA TEC service representative for assistance Symptom Cause and resolution □...

[Page 9](#) English The following information is for EU-member states only: Disposal of products (based on EU-Directive 2002/96/EC, Directive on Waste electrical and electronic equipment - WEEE) The use of the symbol indicates that this product may not be disposed as unsorted municipal waste and has to be collected separately.

[Page 10](#) Nederlands Onderstaande informatie geldt enkel in EU lidstaten: Het afdanken van producten (volgens EU-richtlijn 2002/96/EC, Richtlijn betreffende afgedankte elektrische en elektronische apparatuur - WEEE) Dit symbool geeft aan dat dit product niet mag afgedankt worden als algemeen huishoudelijk afval. Het dient afzonderlijk gecollecteerd te worden.