



Sanyo DRW-500 Quick Manual

Dvd video recorder

1
2
3
4

--

•

Bookmarks

Quick Links

[Download this manual](#) See also: [Instruction Manual](#)



Accessories

- Audio/Video cable
- 75-ohm coaxial antenna cable
- AA size battery (manganese)
- Quantity: 1 pair
- 2 "AA" batteries
- Wireless remote control

**Need help? Call
1-800-813-3435**

**Weekdays: 7:30 AM - 4:00 PM
Central Time**
IAD6P1P2049-- DRW-500, Issue Number 1, Printed in China

**Hook up
(Antenna connections)**



DVD Video Recorder
(Partial back panel)

- or
- 75-ohm coaxial antenna cable (not supplied)
- Cable TV wall jack

After all connections have been made, connect the power cord to a 120V AC 60Hz outlet.

Do not connect the power cord to a 120V AC 60Hz outlet until all connections have been made.
Set the channel number "6" (or "4"), whichever is not used for regular broadcasts in your area.

3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
ANTENNA
VHF/UHF
ANTENNA
IN
TV



75-ohm coaxial antenna cable (supplied)

To AC 120V, 60Hz

[Next Page](#)

1
2
3
4

Related Manuals for Sanyo DRW-500

[DVD Recorder Sanyo DRW-500 Instruction Manual](#)

Dvd video recorder (64 pages)

[DVD Recorder Sanyo DVR-S120 Instruction Manual](#)

Sanyo dvd recorder instruction manual (40 pages)

[DVD Recorder Sanyo DRW-1000 Instruction Manual](#)

Dvd video recorder & 4 head hi-fi stereo vcr (59 pages)

[DVD Recorder Sanyo DVR-500 Instruction Manual](#)

Dvd video recorder (63 pages)

[DVD Recorder Sanyo DVR-SD450 Operating Instructions Manual](#)

(52 pages)

[DVD Recorder Sanyo DVR-DX600 Service Manual](#)

(26 pages)

[DVD Recorder Sanyo DVR-DX600 Instruction Manual](#)

(58 pages)

[DVD Recorder Sanyo HVR-DX625H Instruction Manual](#)

Dvd recorder+vcr (61 pages)

[DVD Recorder Sanyo HVR-DX610 Service Manual](#)

Dvd recorder + vcr (62 pages)

[DVD Recorder Sanyo HVR-DX610 Service Manual](#)

Dvd recorder + vcr (20 pages)

[DVD Recorder Sanyo VA-EXD1B Instruction Manual](#)

(36 pages)

[DVD Recorder Sanyo FWZH776F Owner's Manual](#)

Hd dvr & dvd recorder with digital tuner (84 pages)

[DVD Recorder Sanyo HVR-DX700 Instruction Manual](#)

Hdd/dvd recorder (61 pages)

Summary of Contents for Sanyo DRW-500

[Page 1: Dvd Video Recorder](#)

Need help? Call 1-800-813-3435 Weekdays: 7:30 AM - 4:00 PM Central Time 1AD6P1P2049--DRW-500, Issue Number 1, Printed in China Quick-Guide Do not connect the power cord to a 120V AC 60Hz outlet until all connections have been made. Set the channel number "3" (or "4"), whichever is not used for regular broadcasts in your area.

[Page 2](#) If your TV has the Audio/Video input jacks... AV 1 IN VIDEO ANTENNA COMPONENT VIDEO OUT S-VIDEO AUDIO DVD Video Recorder (Partial back panel) To VIDEO OUT jack (Yellow)
Note: Audio/Video cable (supplied) This unit must be operated in a horizontal position only.

[Page 3](#) Setting the Clock and Tuner Turn on the power. Play/Edit Disc Record Program Record Status Setup Menu Record List Press SETUP to exit "Menu" screen appears. Select "Channel Setup". Recording Setup Recording Setup Record Mode Record Mode Auto Chapter Auto CH Scan Auto Chapter Set Clock Channel List...

[Page 4](#) Load the disc and start recording Place a DVD+RW or DVD+R disc (label facing up) to be recorded. To stop recording Load the disc and start playback Place a disc (label facing up) to

be played back. DVD+RW or DVD+R disc If a DVD-Video disc menu appears on the TV screen...