

Toshiba 1TN Quick Installation Manual

Tcx single station printer

```
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

```
18
19
20
21
22
23
24
25
26
27
28
```

•



Quick Links

- 1 Table of Contents
- 2 Where to Find more Information (Tcx Printers)
- 3 Chapter 1. Installing and Configuring Your Printer
- 4 Connecting Communication Cables
- 5 Configuring the Printer

Download this manual



Toshiba Global Commerce Solutions TCx Single Station Printer 6145

Quick Installation Guide Model 1TN



TC62-0028-00





Related Manuals for Toshiba 1TN

Printer Toshiba e-Studio 162 Service Manual

(176 pages)

Printer Toshiba e-STUDIO 16P Service Manual

Page printer (174 pages)

Printer toshiba 1NR Hardware Service Manual

Single-station printer (110 pages)

Printer Toshiba E-STUDIO2010AC Operator's Manual

Multifunctional digital color systems (32 pages)

Printer Toshiba HSP100 Owner's Manual

Pos printer (53 pages)

Printer Toshiba e-Studio 383P User Manual

Digital led mono printer (76 pages)

Printer Toshiba B-FP3D SERIES Owner's Manual

(39 pages)

Printer Toshiba SureMark 4610 1NR Hardware Manual

(64 pages)

Printer Toshiba e-STUDIO2010AC Management Manual

Multifunctional digital color systems / multifunctional digital systems (32 pages)

Printer Toshiba TEC B-850 Series Key Operation Specification

(90 pages)

Printer Toshiba B-SA4TM Maintenance Manual

B-sa4t series (11 pages)

Printer Toshiba SureMark 4610-SJ6 User Manual

Fiscal printer (52 pages)

Printer Toshiba B-EP4DL-GH20-QM-R Owner's Manual

(22 pages)

Printer Toshiba B-SA4TP SERIES Owner's Manual

Toshiba thermal printer owner's manual (114 pages)

Printer Toshiba B-FP3D-GH30-QM-R Owner's Manual

(21 pages)

Printer Toshiba B-EP Series Interface Specification

External equipment interface specification (788 pages)

Summary of Contents for Toshiba 1TN

 $\underline{\text{Page 1}}$ Toshiba Global Commerce Solutions TCx Single Station Printer 6145 Quick Installation Guide Model 1TN TC62-0028-00...

<u>Page 2</u> If you send information to Toshiba Global Commerce Solutions (Toshiba), you grant Toshiba a nonexclusive right to use or distribute whatever information you supply in any way it believes appropriate without incurring any obligation to you.

Page 3: Table Of Contents

Using the USB cable strain relief.......16 Setting up network options (if applicable)......16 Setting up a WiFi option.........16 Setting up an Ethernet option.........18 Setting up an RS-232 option (if

applicable)....19 Configuring the printer..........20 Notices.......23 Trademarks.........24 Copyright Toshiba Global Commerce Solutions, Inc. ©...

Page 4 TCx Single Station Printer Installation and Service Guide...

Page 5: Safety

Les sikkerhetsinformasjonen (Safety Information) før du installerer dette produktet. Antes de instalar este produto, leia as Informações sobre Segurança. Antes de instalar este producto, lea la información de seguridad. Läs säkerhetsinformationen innan du installerar den här produkten. Copyright Toshiba Global Commerce Solutions, Inc. ©...

Page 6 TCx Single Station Printer Installation and Service Guide...

Page 7: About This Quick Installation Guide

About this Quick Installation Guide This guide contains information about installing, using, and maintaining the Toshiba 6145 $^{\circ}$ Single Station Printer, Model 1TN. The Toshiba TCx Single Station Printer is part of the $^{\top}$ Printer family. $^{\top}$ Who should read this quick installation guide This guide is intended for personnel who are installing, using, or servicing the Toshiba TCx Single Station Printer.

<u>Page 8</u> CAUTION These statements indicate situations that can be potentially hazardous to you. A caution statement is placed just before the description of a potentially hazardous procedure step or situation. DANGER These statements indicate situations that can be potentially lethal or extremely hazardous to you.

Page 9: Chapter 1. Installing And Configuring Your Printer

Chapter 1. Installing and configuring your printer Installing and configuring your printer This section provides information on installing and configuring the Toshiba 6145 printer. Before you begin, be sure to read the Safety Information-Read This First, GC32-0609. To install the 6145 printer: Complete all installation prerequisites (see "Installation prerequisites"...

Page 10: Installing A Filler Panel

Installing a filler panel Based on your printer order, a filler panel might be shipped with your printer. The filler panel is an important part of your integrated system. It secures your printer in the proper position with the system unit and other peripherals. Refer to the installation documentation for your system unit or filler panel for complete instructions.

Page 11: Installing The 58 Mm Wide Paper Guide (Optional)

Installing the 58 mm wide paper guide (optional) The paper guide is included in the paper roll kit. To install the 58 mm wide paper guide, complete the following steps. Open the paper door by pressing the blue release button. Turn off the power to the printer.

Page 12 CAUTION: The wall mounting bracket must be installed by an insured, qualified, professional installer who is familiar with building construction methods, building materials, building codes, electrical codes, fire codes, and local laws governing public access areas. CAUTION: It is imperative that the wall mounting bracket be securely and permanently mounted to the wall.

Page 13: Mounting The Printer To The Wall Mounting Bracket (Optional)

Attach the bracket securely to the wall with four or more 6 mm (0.25 in.) diameter fasteners. Use fasteners that are suitable for the type of wall at your site to ensure that the bracket is securely attached to the wall. For walls that are constructed of gypsum wallboard on wood or metal studs, use good-quality medium-capacity or high-capacity hollow-wall anchors.

Page 14: Configuring The Paper Low Sensor For Wall Mounting

Installing an optional interface adapter card There is an option slot on the back of the Toshiba TCx Single Station printer that can extend the functionality of the base printer. The optional interface adapter card can be either an Ethernet, WiFi, or RS-232 interface adapter card.

Page 15: Connecting Communication Cables

If an optional interface adapter card is included with your order, complete the following steps to install: Turn off the power to your printer. Unplug the power cord from the external power source. Loosen the screw Slide the blank slot cover out of the unit (save the blank slot cover in case you need it in the future).

Page 16: Using The Usb Cable Strain Relief

Setting up a WiFi option The WiFi option for the Toshiba TCx Single Station printer can be used as a network client or as an access point. When using the WiFi option as a client, the printer connects to an existing WiFi network.

<u>Page 17</u> Connect the printer to a USB host system with the TCx Printer Configuration Utility installed, and then power on the printer (if it has been powered off). Note: The Toshiba 6145 printer will automatically power on when power is applied; therefore, it will already be powered on at this point.

Page 18: Setting Up An Ethernet Option

Disconnect the printer from the USB Host system and remove the USB cable unless it is part of the final setup. Note: The TCx Printer Configuration Utility can also be used to perform other configuration tasks. See "Using the TCx Printer Configuration Utility" on page 19 for additional information.

Page 19: Setting Up An Rs-232 Option (If Applicable)

You can setup an RS-232 option using the TCx Printer Configuration Utility or the printer's offline functions. See "Using the Toshiba POS Virtual Serial Driver" on page 20 or "Using the printer offline functions" on page 20 for instructions on setting up your RS-232 option.

Page 20: Configuring The Printer

Applications designed to be used with RS-232 printers can use a 6145 USB printer with the Toshiba POS Virtual Serial Driver. The same serial parameters and communication options are available with this driver. Refer to the Toshiba POS Virtual Serial Drivers User's Guide for additional information.

<u>Page 21</u> System software (such as drivers and utilities) that support the TCx Printers includes an update process that typically runs when the system is booted (or rebooted). On the first boot after a printer is installed or replaced, and after a configuration package is updated, the attached printer will be configured per the configuration package.

Page 22 TCx Single Station Printer Installation and Service Guide...

Page 23: Notices

Web sites. The materials at those Web sites are not part of the materials for this Toshiba Global Commerce Solutions product and use of those Web sites is at your own risk.

Page 24: Trademarks

Trademarks The following are trademarks or registered trademarks of Toshiba, Inc. in the United States or other countries, or both: Toshiba The Toshiba logo The following are trademarks of Toshiba Global Commerce Solutions in the United States or other countries, or both:...

<u>Page 25</u> 58 mm wide guide Ethernet interface card filler panel optional interface adapter card WiFi interface card installing the 6145 printer installing the filler panel integrated configuration notices Toshiba optional interface adapter card installing Copyright Toshiba Global Commerce Solutions, Inc. ©...

Page 26 TCx Single Station Printer Installation and Service Guide...

Page 28 TC62-0028-00...

This manual is also suitable for:

6145

Save PDF