



# Whirlpool AKT 477/IX Instructions For Use

77cm gas on glass induction and gas hob, black glass akt 477/ix



1  
2  
3  
4

--


•

Bookmarks

--

[Download this manual](#)

### Quick Links



Enlarged version





IMPORTANT SAFETY INFORMATION

Your safety and the safety of others are very important.  
This manual and the appliance itself provide important safety messages, to be read and observed at all times.  
This is the safety alert symbol, pertaining to safety, which alerts users to potential hazards to themselves and others. All safety messages will follow the safety alert symbol and either the terms:  
Indicates a hazardous situation which, if not avoided, will cause serious injury.  
Indicates a hazardous situation which, if not avoided, could cause serious injury.  
All safety messages will tell you what the potential hazard is, tell you how to reduce the change of injury, and tell you what can happen if the instructions are not followed.  
- The appliance must be disconnected from the power supply before carrying out any installation work.  
- Installation must be carried out by a qualified technician, in compliance with the manufacturer's instructions and local safety regulations.  
- Do not touch any part of the appliance unless specifically stated in the user manual.  
If the information in this manual is not followed exactly, a fire or explosion may result causing property damage.  
**WARNING**  
- Do not use flammable vapors and liquids in the vicinity of this appliance.

WHAT TO DO IF YOU SMELL GAS:  
- Do not try to light any appliance.  
- Do not touch any electrical switch.  
- Do not use any phone in your building.  
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.  
- If you cannot reach your gas supplier, call the fire department.  
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.  
- Install a separating panel under the appliance  
- Use only gas burners.  
The appliance must comply with local regulations.  
- Regulations require that the appliance is grounded.  
- The power cable must be long enough for connecting the appliance, once fitted in its housing, to the power supply  
- Use only flexible or rigid metal hose for gas connection.  
- Do not place metal objects such as kitchen utensils (knives, forks, spoons...), lids or other similar items on the cooking zone as they can become very hot.  
- When the hob is installed, provide a multi-pole circuit breaker with a contact separation of at least 3 mm.  
- This appliance complies with current safety regulations and electromagnetic compatibility regulations. Nevertheless, people with a pacemaker should not use this appliance. It is impossible to guarantee that all such devices found on the market comply with current safety regulations and electromagnetic compatibility regulations, and that dangerous interference will not occur. It is also possible that people with other types of devices, such as a hearing aid, could experience some discomfort.  
- Do not use multiple plug adapters or extension cords.  
- Do not pull the power supply cord in order to unplug the appliance.  
- The electrical components must not be accessible to the user after installation.  
- Do not touch the appliance with any wet part of the body and do not operate it when barefoot.  
- This hob is designed solely for household use for cooking food. NEVER use this appliance as a space heater to heat or warm the room. Doing so may result in carbon monoxide poisoning and overheating of the hob. The manufacturer declines all responsibility for inappropriate use or incorrect setting of the controls.  
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or with lack of experience and knowledge of the appliance, unless supervised or previously instructed in its use by those responsible for their safety.  
- Do not place flammable materials in or near the appliance: a fire may break out if the appliance is inadvertently switched on.  
- Do not heat or cook sealed jars or containers in the appliance. The pressure that builds up inside might cause the jar to explode, damaging the appliance.  
- Do not use containers made of synthetic materials.  
SAVE THESE INSTRUCTIONS  
5019 619 01340  
- Overheated oils and fats catch fire easily. Always remain vigilant when cooking foods rich in fat and oil.  
- Never leave the appliance unattended during food drying.  
If alcoholic beverages are used when cooking foods (e.g. rum, cognac, wine), remember that alcohol evaporates at high temperatures. As a result, there is a risk that vapours released by the alcohol may catch fire upon coming into contact with the heating element.  
- Keep the packaging materials out of the reach of children, as they are potential hazard.  
- Before cleaning or maintenance wait for hob to cool down.  
NOTES:  
• Improper use of the grids can result in damage to the hob surface. Do not position the grids upside down or drag them across the hob.  
• If the hob has a glass ceramic top, do not use:  
- Cast iron griddles or terracotta pots and pans  
- Heat diffusers (e.g. metallic mesh)  
- Two cookers for the same pot  
• In case of prolonged use, additional ventilation may be needed (opening a window or increasing the extraction force of the hood).  
• This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given initial supervision or instruction concerning use of the appliance by a person responsible for their safety.  
• Keep children away from the hob when it is in use and do not let them play with the controls or any other appliance parts.

Table of Contents

[Next Page](#)

1  
2  
3  
4

## Related Manuals for Whirlpool AKT 477/IX

### [Oven Whirlpool AKT 477/IX Product Description Sheet](#)

(6 pages)

### [Hob Whirlpool AKM 359/NE Troubleshooting Manual](#)

60cm frameless 4 zone ceramic hob, black akm 359/ne (2 pages)

### [Hob Whirlpool AKT 466/NB/01 Instructions For Use](#)

Black 77cm origami 4 burner gas on glass hob akt 466/nb/01 (4 pages)

### [Hob Whirlpool AKT 466/WH Instructions For Use](#)

73cm gas hob with 4 burners, white akt 466/wh (4 pages)

### [Hob Whirlpool AKT 466 Manual](#)

(4 pages)

### [Hob Whirlpool AKT 725 Instruction Manual](#)

Built-in gas hob (4 pages)

### [Hob Whirlpool AKT 464 Instructions](#)

Built-in gas hob (4 pages)

### [Hob Whirlpool AKT 424 Installation](#)

Built-in gas hob (4 pages)

### [Hob Whirlpool AKT 476 Manual](#)

(4 pages)

### [Hob Whirlpool AKT 404/NB Manual](#)

(25 pages)

### [Hob Whirlpool AKT 315/IX Manual](#)

(48 pages)

### [Hob Whirlpool AKT 809 Product Description Sheet](#)

(9 pages)

### [Hob Whirlpool AKT 360/IX Manual](#)

(6 pages)

### [Hob Whirlpool AKT 625/WH Instructions Manual](#)

(8 pages)

### [Hob Whirlpool AKT 801 NE Instructions For Use Manual](#)

(7 pages)

### [Hob Whirlpool AKT 8900 BA Owner's Manual](#)

(74 pages)

## Summary of Contents for Whirlpool AKT 477/IX

### [Page 1: Important Safety Information](#)

**IMPORTANT SAFETY INFORMATION** Your safety and the safety of others are very important. This manual and the appliance itself provide important safety messages, to be read and observed at all times. This is the safety alert symbol, pertaining to safety, which alerts users to potential hazards to themselves and others. All safety messages will follow the safety alert symbol and either the terms: Indicates a hazardous situation which, if not avoided, will cause serious injury.

### [Page 2: Gas Connection](#)

**ELECTRICAL CONNECTION** Installation must be carried out by a qualified electrician who is fully aware of current safety and installation regulations. The manufacturer declines all liability for

injury to persons or animals and for damage to property resulting from failure to observe the regulations provided in this chapter.

### [Page 3: Care And Maintenance](#)

UNDERCOUNTER OVEN INSTALLATION: • If an oven (which must be of our manufacture) is to be installed under the hob, ensure it is equipped with a cooling system and observe the distances given in the figure to the side. • There must be nothing between the cooktop and the oven (cross rails, panels, brackets, etc.).

[Page 4](#) TROUBLESHOOTING GUIDE (INDUCTION ZONE) • Before contacting After-sales Service: • read and follow the instructions given in the section "Operating instructions". • Connect the hob to the electricity supply and check that the supply has not been shut off. • Clean the hob and dry it thoroughly. •...

This manual is also suitable for:

Akt 477/ix akt 477/ixAkm 359Akt 477477/ix