



# Whirlpool AKM 260/IX Instructions For Use Manual

60cm 4 burner gas hob, with flame-failure device akm 260/ix



1  
2  
3  
4  
5  
6  
7  
8

Table Of Contents

9

--

- 

[Table of Contents](#)

- 

Troubleshooting

•

Bookmarks

--

## Table of Contents

1 Instructions for Use

2 Before Using the Cooktop

3 Precautions and General Advice

4 Energy Saving Tips

5 Care and Maintenance


6 Troubleshooting Guide



[7 After Sales Service](#)

[8 Installation](#)

[Download this manual](#)



3gb53231b.fm5 Page 12 Friday, April 11, 2003 12:21 PM

## **INSTRUCTIONS FOR USE**

**BEFORE USING THE COOKTOP**

**SUGGESTIONS FOR ENVIRONMENT PROTECTION**

**PRECAUTIONS AND GENERAL ADVICE**

**ENERGY SAVING TIPS**

**CARE AND MAINTENANCE**

**TROUBLESHOOTING GUIDE**

**AFTER SALES SERVICE**

# INSTALLATION

12

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool AKM 260/IX

### [Hob Whirlpool AKM 260 Service Manual](#)

Gas hob (5 pages)

### [Hob Whirlpool AKM 516/JA Instructions](#)

(4 pages)

### [Cooktop WHIRLPOOL AKM 260 Datasheet](#)

(2 pages)

### [Cooktop Whirlpool ACM816BA Instructions For Use Manual](#)

60cm induction electric cooktop (14 pages)

### [Cooktop Whirlpool ACM795BA Instructions For Use Manual](#)

90cm induction electric cooktop (15 pages)

### [Cooktop Whirlpool AKT 920 Product Description Sheet](#)

(4 pages)

### [Cooktop Whirlpool AKM160/IX Service Manual](#)

Gas cooktop (9 pages)

### [Cooktop Whirlpool AKC7250 C/BLM Instructions For Use Manual](#)

(18 pages)

### [Cooktop Whirlpool AKR 028 User Manual](#)

(19 pages)

### [Cooktop Whirlpool AKM 950/NE/01 Service Manual](#)

(7 pages)

### [Cooktop Whirlpool AKM 605 Instruction Manual](#)

(10 pages)

### [Cooktop Whirlpool ACM-845BH Installation Manual](#)

(12 pages)

### [Cooktop Whirlpool AKM 330 IX Instructions For Use](#)

(5 pages)

### [Cooktop Whirlpool AKM 268/IX Manual](#)

(33 pages)

### [Cooktop Whirlpool AKM 526/NA Instructions For Use Manual](#)

60cm rustic-style gas hob with 4 burners, anthracite akm 526/na (9 pages)

### [Cooktop Whirlpool WCC31430AB Installation Instructions Manual](#)

Electric built-in cooktops 30" (76.2 cm) and 36" (91.4 cm) (12 pages)

## Summary of Contents for Whirlpool AKM 260/IX

### [Page 1: Instructions For Use](#)

3gb53231b.fm5 Page 12 Friday, April 11, 2003 12:21 PM INSTRUCTIONS FOR USE BEFORE USING THE COOKTOP SUGGESTIONS FOR ENVIRONMENT PROTECTION PRECAUTIONS AND GENERAL ADVICE ENERGY SAVING TIPS CARE AND MAINTENANCE TROUBLESHOOTING GUIDE AFTER SALES SERVICE INSTALLATION...

### [Page 2: Before Using The Cooktop](#)

3gb53231b.fm5 Page 13 Friday, April 11, 2003 12:21 PM BEFORE USING THE COOKTOP These instructions are only valid for those Countries where the destination abbreviations are mentioned on the rear cover of the user instructions and on the appliance. • To get full

satisfaction of your cooktop, please read these instructions carefully and keep them for future consultation.

### [Page 3: Energy Saving Tips](#)

3gb53231b.fm5 Page 14 Friday, April 11, 2003 12:21 PM ENERGY SAVING TIPS • The cooktop is equipped with burners and/or a hotplate with different diameters. Use pots and pans whose bottom diameter is equal to that of the burners and hotplate, or slightly larger.

### [Page 4: Care And Maintenance](#)

3gb53231b.fm5 Page 15 Friday, April 11, 2003 12:21 PM CARE AND MAINTENANCE Cleaning the cooktop surface, panstand grids and control panel • Before cleaning the cooktop, disconnect it from mains power supply and wait until it has cooled down. • Wipe with a cloth moistened with hot water and soap or diluted liquid detergent.

### [Page 5: Troubleshooting Guide](#)

3gb53231b.fm5 Page 16 Friday, April 11, 2003 12:21 PM TROUBLESHOOTING GUIDE 1. The burner fails to ignite: • Is the main gas delivery valve open? • Has the delivery of the town gas (methane) been suspended? • Is the gas cylinder (liquid gas) empty? •...

### [Page 6: Installation](#)

3gb53231b.fm5 Page 17 Friday, April 11, 2003 12:21 PM INSTALLATION Technical information for the Installer This cooktop can be embedded in a worktop 20 to 50 mm thick. If there is no oven beneath the cooktop (any oven installed must be manufactured by us and equipped with a cooling system), insert a separator panel at a minimum distance of 20 mm from the bottom of the cooktop.

[Page 7](#) 3gb53231b.fm5 Page 18 Friday, April 11, 2003 12:21 PM INSTALLATION Electrical connection • The electrical connections must comply with local regulations. • The data relevant to the voltage and power absorption are indicated on the rating plate. • The earthing of this appliance is compulsory by law. •...

[Page 8](#) 3gb53231b.fm5 Page 19 Friday, April 11, 2003 12:21 PM INSTALLATION ADJUSTMENT TO DIFFERENT TYPES OF GAS If a different type of gas to the type shown on the rating plate and on the orange sticker affixed to the top of the cooktop is used, the cooktop must be converted to work with the new gas type.

This manual is also suitable for:

Akm 260/whAkm 260/ix akm 260/ixAkm 260/wh akm 260/whAkm 260260/ix