

Whirlpool VS2511 Use And Care Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

--

•

[Table of Contents](#)

-

Troubleshooting


•

Bookmarks

--

[Download this manual](#)

Quick Links





VS2511



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool VS2511

[Vacuum Cleaner Whirlpool VB-100 Instruction Manual](#)

(8 pages)

[Vacuum Cleaner Whirlpool VS1809 Use & Care Manual](#)

(30 pages)

[Vacuum Cleaner Whirlpool VS1405 User Manual](#)

(28 pages)

[Vacuum Cleaner Whirlpool VH1806 User Manual](#)

(11 pages)

[Vacuum Cleaner Whirlpool VL1407 User Manual](#)

(11 pages)

[Vacuum Cleaner Whirlpool VL1602 User Manual](#)

(21 pages)

Summary of Contents for Whirlpool VS2511

[Page 1](#) 〇〇〇〇〇〇〇〇〇〇〇 VS2511...

[Page 2: Important Safety Instructions](#)

IMPORTANT SAFETY INSTRUCTIONS When using an electrical appliance, basic precautions should always be followed, including the following: READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE WARNING : To reduce the risk of fire, electric shock, or injury: 1. Do not pick up detergent, kerosene, blizzard, nee- dle, ash, wet dust, dirty water and match, etc.

[Page 3](#) 9. Do not use if the plug or cord is damaged. 10. Switch the appliance off after use. 11. The charging base requires a 100-240V~, 50/60 Hz supply. Do not use any other power source. 12. Only the supplied charging base should be used with the appliance.

[Page 4](#) 22. Caution: Only charge the vacuum cleaner with the Charging bracket supplied. During charging, the plug feels warm to the touch. This is normal. 23. Caution: Never block the exhaust air openings during vacuuming. 24. Caution: Switch off the appliance when you re-charged it.

[Page 5](#) IMPORTANT SAFETY INSTRUCTIONS (for Bed Cleaner) 1. Check the rating label of Bed Cleaner matches the dedicated Handheld unit. 2. This Bed Cleaner is intended for normal household use only. Do not use the appliance outdoors. Do not use the appliance for other uses than its intended use.

[Page 6: Product Overview](#)

PRODUCT OVERVIEW UPRIGHT UNIT: 1. ON/OFF switch 6. LED light 2. ECO speed switch 7. Motorized brush 3. Foldable handle release 8. Folding handle button 9. Handheld handle 4. Handheld release button 10. Handheld unit 5. Motorized brush 11. Charging bracket release button...

[Page 7](#) PRODUCT OVERVIEW HANDHELD UNIT: 12. ON/OFF switch 20. Extended crevice tool 13. Battery/ Charging indicator 21. Wide brush / Upholstery 14. Dust container release button adaptor 15. Seal ring 22. Wide brush 16. HEPA filter 23. Upholstery 17. Outer filter 24.

[Page 8: Application Of Accessories](#)

APPLICATION OF ACCESSORIES Adaptor: Insert the Adaptor [19] into the inhale handheld nozzle of dust container. It acts as an adaptor for the connection of accessories for different purposes.

To remove the Adaptor from dust container just pull firmly outward. Extended Crevice Tool: Connect [20] Extended Crevice Tool is for cleaning small areas which are difficult to reach, such as corners, gaps, holes, etc.

[Page 9](#) **PRODUCT ASSEMBLING** Foldable Handle Lift the handle to an upright position, the handle will lock To lower the handle, press the automatically. folding handle release button. Press Assembling the Charging bracket Mounting Screws Wall Mount Hole Plastic Wall Anchors • Charging bracket assembly must be placed on a flat ground, mounting screws and plastic wall anchors can fix the charging bracket on the wall.

[Page 10](#) **PRODUCT CHARGING** Charging the Vacuum Cleaner Charge the battery when: `using the product for the first time `after not using the product for a long period of time `when the unit is at low power and the battery/ charging indicator flashes red. 1.

[Page 11: Led Indicator](#)

LED INDICATOR Status LED color Power ON Blue Low battery Blue flashing Empty battery Red flashing Charging Charging complete Blue Bad battery Red & Blue alternative flashing OPERATION Make sure the battery is fully charged before use. Operation of the upright vacuum cleaner 1.

[Page 12: Maintenance And Cleaning](#)

MAINTENANCE & CLEANING Empty the dust container `Dirt and liquid in the dust container should be emptied after each use or at the time when the dust exceeds the maximum dust marking. `Always switch off the vacuum cleaner before cleaning. 1.

[Page 13](#) 4. Remove the filters and wash with water. Dry it before re-installing it. NOTE: Do not clean the vacuum cleaner with paint thinner or chemical solutions as this will damage the vacuum cleaner. 5. Fit the inner and outer filter into the dust container. Make sure you have dried the inside of the dust container.

[Page 14](#) Maintenance for Motorized brush Carry out the maintenance if any waste threads or hair gets tangled in the brush. Press the motorized brush release button to detach the motorized brush from the upright unit. Regular Maintenance Slowly rotate the brush manually and remove any foreign objects Take out tangled around the brush.

[Page 15](#) 5. Re-install the rotating brush back into the motorized brush...

[Page 16](#) 8. UV lamp tube door This Bed Cleaner must be operated with rated 9. Rear wheel (UV triggered device) Handheld unit of VS2511 HOW TO USE THE UV BED CLEANER 1. Fit the Handheld unit onto the UV bed cleaner.

[Page 17](#) 2. Press the Power Button on the Handheld unit to power on. Power Button 3. Slide on the surface of your bed to clean. Slide Bedding surface 4. How to detach UV Bed Cleaner from Handheld unit. Hold the Handheld unit tightly with one hand, then press the two Handheld unit release buttons with your other hand at the same time to unlock.

[Page 18: Maintenance & Cleaning](#)

NOTE Rotating brush (UV triggered device) Rear wheel (UV triggered device) There are totally two triggered devices at the rear wheel of UV bed cleaner and rotating brush. UV lamp will be power on only when all these two triggered devices are actuated. MAINTENANCE / CLEANING 1.

[Page 19](#) 2. How to clean the rotating brush. a. Use your fingers to pull the two rotating brush door locks. b. Then detach the door. Take out the rotating brush, Remove the hair on the and clean it. rotating brush. Scissors Re-assemble the rotating brush and brush door to the UV Bed Cleaner after cleaning.

[Page 20](#) 3. How to clean or exchange the UV lamp tube. a. Use your fingers to pull the two UV lamp tube door locks. b. Then detach the door. a. Use your fingers to hold the UV lamp tube and then rotate it by 90°...

[Page 21: Troubleshooting](#)

Model : VS2511 Battery : 25.2V Li-ion Adaptor : Input: AC 100-240V~ 50/60Hz Output: DC 32V

[Page 22: Disposal Of The Appliance](#)

DISPOSAL OF THE APPLIANCE At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection center or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent material to be recovered...

Page 23 1. 2. 3. 4. HEPA 5. 6. 7. 8. 9. 10. 11. 100-240V~50/60Hz 12. 13. ...

Page 24 18. 19. 20. 21. 22. 23. 24. — 25. ...

Page 25 () 1. 2. 3. 4. 5. 6. () 7. 8. 9. 10. UV ...

Page 26 1. 8. 2. 9. 3. 10. 4. 11. 5. 6. LED 7. ...

Page 27 12. 20. 13. 21. / 14. 22. 15. 23. 16. H EPA 24. 17. 18. 19. ...

Page 28 : [19] : [20] : [22] “ ” / [21] : [23] “ ” / [21] : [24] [19] ...

Page 29 LED ...

Page 30 1. 2. 3. 4. 5. 6. ...

Page 31 LED ...

Page 32 1. 2. 3. LED 4. 5. 1. 2. 3. 4. 5. ...

Page 33 1. ...

UV 2. UV 3. UV ...

[Page 34](#) UV 4. UV 5. HEPA 6. UV ' ...

[Page 35](#) UV 1. UV 2. UV 3. UV 4. UV 5. UV ...

[Page 36](#) UV 1. UV 2. (UV) 3. LED UV 4. UV (UV) 5. UV 6. UV 7. UV 8. UV VS2511 9. UV (UV) UV 1. UV ...

[Page 37](#) UV 2. UV 3. UV UV 4. UV ...

[Page 38](#) UV UV UV UV UV 1. UV ...

[Page 39](#) UV a. UV b. UV UV UV ...

[Page 40](#) UV UV a. UV UV b. UV a. UV UV 90° b. UV UV UV ...

[Page 41](#) UV UV UV * : UV UV UV UV UV UV UV UV UV VS2511 25.2V UV AC 100-240V~ 50/60Hz DC 32V 400mA UV VS2511 25.2V UV 4W 25.2V ...

[Page 42](#) UV UV UV UV UV ...