


Using The Wireless Remote Control Unit - Sanyo CHDZ07263 Service Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118


119
120
121
122
123
124
125
126
127
128



•

•

Bookmarks



2. Wireless Remote Controller

2-4. Using the Wireless Remote Control Unit

Slide switch

With the battery cover removed

How to install batteries


How to use the wireless remote control unit

This is used to set the operation mode of the indoor units and to set the flaps.

• Depending on the indoor unit used, the operation display and airflow direction display settings will differ as shown below.

- Use a pointed implement to change the switch position.
- When the switch position has been changed, press the ACL button.

* For details on the flap functions, refer to the operating instructions of the indoor unit used.



Slide switch position
 Flap display on wireless
 remote control unit
 Operation mode display
 on wireless remote
 control unit
 Slide switch position

• Before use, check that the slide switch has been set to the position shown in the figure above. For details on how to set the slide switch, consult your dealer.

1. Slide the cover in the direction indicated by the arrow and remove it.

2. Install two AAA alkaline batteries. Make sure the batteries point in the direction marked in the battery compartment.

3. Use a pointed implement to press the ACL button.

• The batteries last about a year, depending on how much you use the wireless remote control unit. Replace the batteries when the wireless remote control unit's display fails to light, or when the remote control cannot be used to change the air conditioner's settings.

• When the batteries are to be replaced, make sure that both batteries are new and that the same kind of battery is used.

• Remove the batteries if the wireless remote control unit is not going to be used for a prolonged period.

• Dispose of the used batteries at the designated location.

• Point the wireless remote control unit's transmitter at the signal receiver. If the signal is received properly, a beep is heard. (Two beeps are heard only when operation starts up.)

• Signals can be received over a distance of approximately 26 ft. This distance is approximate: it may be slightly more or less depending on how much charge remains in the batteries and on other factors.

• Ensure that the signals will not be blocked by any objects positioned between the transmitter and signal receiver.

• Avoid placing the wireless remote control unit where it will be exposed to direct sunlight or in the direct path of the air blown out from the air conditioner, near a heating appliance, etc.

• Do not drop, throw or wash the wireless remote control unit.

• Signal reception may not be accepted in rooms with fluorescent lights that use the electronic instantaneous lighting system (rapid start system) or inverter system.

For further details, contact your dealer.

Model which supports

Swing-only model

different flap settings

Heat pump (with auto

cooling/heating

auto cooling/heating

function)

function)

2 - 9

Remote Control Functions


No-flap model

Cooling only

ACL

button

Cover



[Table of Contents](#)

1
...
26
27
28
29
30
31
32
33

Quick Links:

[Table of Contents](#)

Chapters

[Section 1](#) 4

[Section 2](#) 21

[Outdoor Unit Control Pcb/Indoor Unit Control Pcb](#) 91

Related Manuals for Sanyo CHDZ07263

[Air Conditioner Sanyo ECO-i CHDZR07263 Series Service Manual](#)

(146 pages)

[Air Conditioner Sanyo ECO-i AHX0752 Technical Data Manual](#)

(265 pages)

[Air Conditioner Sanyo MINI ECO-i XHX1252 Service Manual & Test Run Service Manual](#)

(190 pages)

[Air Conditioner Sanyo CHDXR09663* Service Manual](#)

2-way eco-i multi system (142 pages)

[Air Conditioner Sanyo AHX0752 Service Manual](#)

W-2way eco-i multi system (114 pages)

[Air Conditioner Sanyo W-3WAY ECO-i 85464369098000 Installation Instructions Manual](#)

W-3way eco-i system air conditioner (106 pages)

[Air Conditioner Sanyo 85464359982001 Installation Instructions Manual](#)

W-2way system air conditioner (96 pages)

[Air Conditioner Sanyo Mini ECO-i CHXR03652 Service Manual](#)

(93 pages)

[Air Conditioner Sanyo Mini ECO-i 85464359981002 Installation Instructions Manual](#)

Sanyo air conditioner installation instructions (90 pages)

[Air Conditioner Sanyo R410A Installation Instructions Manual](#)

W-3way eco-i system air conditioner (54 pages)

[Air Conditioner Sanyo XM18AAB Installation Instructions Manual](#)

W-2way system air conditioner (50 pages)

[Air Conditioner Sanyo ECO R410A Installation Instructions Manual](#)

Eco-i system air conditioner (48 pages)

[Air Conditioner Sanyo XHX1252 Instruction Manual](#)

Split system air conditioner (20 pages)

[Air Conditioner Sanyo THX2452 User Manual](#)

(4 pages)

[Air Conditioner Sanyo DHX4852 Manual](#)

Indoor unit (4 pages)

[Air Conditioner Sanyo THX1852 Manual](#)

Indoor unit (4 pages)

Related Content for Sanyo CHDZ07263

[AHX0752 Using The Wireless Remote Control Unit](#)

Sanyo AHX0752

[SAP-K181AA Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K181AA

[SAP-K181GJH Remote Control Unit Installation Position](#)

Sanyo SAP-K181GJH

[SAP-K71GH Remote Control Unit Installation Position](#)

Sanyo SAP-K71GH

[SAP-KMRV93GJH Using The Remote Control Unit](#)

Sanyo SAP-KMRV93GJH

[SAP-K71GJA-S Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K71GJA-S

[KMS0912 Using The Remote Control Unit](#)

Sanyo KMS0912

[SAP-K71GJHA Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K71GJHA

This manual is also suitable for:

[Chdz09663Chdzt07263Chdzt09663Xhx1252Xhx1852Xhx2452 ...](#) [Show all](#)