


Sanyo VA-DK02 Instruction Manual

In-ceiling bracket

1	1		



Download this manual	Quick Links	



# INSTRUCTION MANUAL

## In-ceiling bracket

Before starting the installation procedure, please read thes keep these instructions handy for future reference.





<del>Vng theilastallation presentwo. เปรเมลาสามารถสามารถสามารถสามารถสามารถสามารถสามารถสามารถสามารถสามารถสามารถสามารถ</del> instructions that dy for future reference.

Wen instance the brocket and camera, select a surface which is flat and durable and which can support

This indicates a point that if not respected may cause death

is plaster 65 and or plaining material, use a reinforcement plate to reinforce bracket and camera are not securely installed, they may fall down. The bracket and camera, select a surface which is list and durable and which can support

The stand camera, and make sure that they are installed securely. rhis indicates a peinetrac ir not respected ma y causel down.

material damage.
This indicates a point that if not respected may cause injuries and/or extensive material damage.

and the trackle to check that they are fully secure. If the bracket a falls down, serious injury may result.

ACCESSORIES

SSOPIOS×10 mm)

Spacers: 4 (12 mm), 3 (22 mm)

② Spacers: 4 (12 mm), 3 (3 Safety wires: 2 mm) res: 2



**Weight:** 550 g

ins (Unit: mm): ¢230×105 (H) Pirospaiens (Weiss mm); ¢230×3605 (H)

specifications are subject to change without Mounting board thickness range: 5 - 30 mm 2 are subject to change with prior notice or obligations.



### Installation method

Make a hole with a diameter of 200 mm

in the ceiling, install the hook of the accessory safety wire (A) into the hooking hole (B) of the bracket, and then install the other end of the safety wire (A) to a point inside the ceiling. ilf the safety wire is too short, use the other safety wire which is also included as an accessory. The safety wire is used to prevent the bracket from falling down once it has been installed If the installation location is not strong enough, reinforce the ceiling, or install the anchor bolt (Y).

Install the bracket to the ceiling, and

tighten both of the screws (C). Secure the ceiling surface with the bracket (D)

# iling bracket

the installation procedure, please read these instructions carefully. Make sure to instructions handy for future reference.

Installation method


Make a hole with a diameter of 200 mm in the ceiling, install the hook of the accessory safety wire (A) into the hooking hole (B) of the bracket, and then install the other end of the safety wire (A) to a point inside the ceiling.



- If the safety wire is too short, use the other safety wire which is also included as an accessory. The safety wire is used to prevent the bracket from falling down once it has been installed
- If the installation location is not strong enough, reinforce the ceiling, or install the anchor bolt (Y).

Install the bracket to the ceiling, and then use a screwdriver to fully tighten both of the screws (C).

Secure the ceiling surface with the bracket (D).




### Install the camera.

Four types of camera can be installed to this bracket.


#### A Installing the vandal resistant dome camera

Place the camera into the In-ceiling bracket, and then secure it by tightening the four supplied screws.




| Installing the pan-focus indoor mini dome camera

Remove the basement (Z) from the camera bottom, secure it by tightening the two supplied screws and then install the mini dome camera to it.



Installing the vari-focal indoor mini dome camera

Remove the basement (Z) from the camera bottom, install the accessory spacer (E: 12mm) to it, secure it by tightening the four supplied screws and then install the mini dome camera to it.



D Installing the vandal resistant mini dome camera

Install the three spacers (F: 22 mm) which are supplied with the In-ceiling bracket, install the camera into the In-ceiling bracket, and then secure it by tightening the three supplied screws



Be sure to remove the rubber cushion on the base of the mini dome camera.



### Install the camera.

Four types of camera can be installed to this bracket.

#### A Installing the vandal resistant dome camera

Place the camera into the In-ceiling bracket, and then secure it by tightening the four supplied screws.







5

4



Pour types of camera can be installed to this bracket.

Installing the vandal resistant dome camera Place the camera into the In-ceiling bracket, and

# RISCRETTO CONING MAIN ANDUAL SCIEWS.

M4×10 mm

Installing the pan-focus indoor mini dome camera

fling bracket ening the two supplied mini dome camera to it.

Installing the teltiation indoced inicipal ease was these instructions carefully. Make sure to Instructions handy for future reference.

Remove the basement (Z) from the camera

domeTARGINGREETERS a point that if not respected may cause death or serious injuries.

ng the bracket and camera, select a surface which is flat and durable and which can support of the bracket and camera, and make sure that they are installed securely viax u mm. lation location is plasterboard or a similar material, use a reinforcement plate to reinforce it. et and camera are not securely installed, they may fall down.

ers (F: 22**This indicates a point that if not respected may cause** eiling braither has and for extensive material damage.

camera into the In-ceiling bracket, and then secure ling the pracket and camera, always be sure to check that they are fully secure. If the bracket in the pracket and camera, always be sure to check that they are fully secure. If the bracket is you used to remove the rubber cushion

property mini dome camera.

4 (M4×10 mm) M4 (12 mm), 3 (22 mm) des: 2

insert the hook of the safety wire which is attached to the cover into the hooking hole (G) of the in ceiling bracket.

# Fusi Cott hooks (H) of the cover, and

the (Yngh the Eoleg With the Heiling bha turir the Kotkinsa ta se Eura h.mm lications are subject to change without

When installing the cover to the ceiling, the hook of the safety wire may become clamped between the hooks (H) and the hooks (H) may open. If the hooks (H) are open when the cove talled, the cover may fall down. SANYO Electric Co., Ltd. Printed in Taiwan


Make a hole with a diameter of 200 mm in the ceiling, install the hook of the accessory safety wire (A) into the hooking hole (B) of the bracket, and then install the other end of the safety wire (A) to a point inside the ceiling.

Installation method



- If the safety wire is too short, use the other safety wire which is also included as an accessory. The safety wire is used to prevent the bracket from falling down once it has been installed
- If the installation location is not strong enough, reinforce the ceiling, or install the anchor bolt (Y).
- 2 Install the bracket to the ceiling, and then use a screwdriver to fully tighten both of the screws (C).

Secure the ceiling surface with the bracket (D).




Install the camera.

Four types of camera can be installed to this bracket.

A Installing the vandal resistant dome camera

Place the camera into the In-ceiling bracket, and then secure it by tightening the four supplied screws.




4

5

(?)


| Installing the pan-focus indoor mini dome camera

Remove the basement (Z) from the camera bottom, secure it by tightening the two supplied screws and then install the mini dome camera to it.



C Installing the vari-focal indoor mini dome camera

Remove the basement (Z) from the camera bottom, install the accessory spacer (E: 12mm) to it, secure it by tightening the four supplied screws and then install the mini dome camera to it.



D Installing the vandal resistant mini dome camera

Install the three spacers (F: 22 mm) which are supplied with the In-ceiling bracket, install the camera into the In-ceiling bracket, and then secure

# Related Manuals for Sanyo VA-DK02

TV Mount Sanyo VA-60BX Instruction Manual

Base bracket (1 page)

TV Mount Sanyo VA-85BX Instruction Manual

Base bracket (1 page)

TV Mount Sanyo VA-DK03 Instruction Manual

In-ceiling bracket (2 pages)