

Sanyo VA-EXD1 W Instruction Manual

External disc unit

```
1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
```

Table of Contents



Download this manual	Quick Links	



External Disc Unit

Instruction manual

About this manual

Before installing and using this unit, please read this manual carefully. Be sure to keep it handy for later reference.

Über diese Anleitung

Lesen Sie bitte diese Bedienungsanleitung vor der Installation und der Verwendung des Gerätes sorgfältig durch. Bewahren Sie die Anleitung zum späteren Nachschlagen auf.

À propos de ce manuel

Avant d'installer et d'utiliser cet appareil, veuillez lire ce manuel attentivement. Assurez-vous de le garder à S

portée de la main pour référence ultérieure.

VA-EXD1B VA-EXD1W

S

Acerca de este manual


Antes de instalar y usar este aparato, lea detenidamente este manual. Asegúrese de guardarlo a mano para futuras referencias.

Nota su questo manuale

Leggere attentamente questo manuale prima di passare all'installazione ed all'uso di questo apparecchio.

Conservare il manuale in un posto sicuro per riferimenti futuri.

Table of Contents





Related Manuals for Sanyo VA-EXD1 W

DVD Recorder Sanyo VA-EXD1B Instruction Manual

(36 pages)

Storage Sanyo VA-EXH Instruction Manual

External storage unit (70 pages)

Storage Sanyo VA-EXH Instruction Manual

(44 pages)

Storage Sanyo POA-USB02 Owner's Manual

Usb memory (26 pages)

Storage Sanyo POA-CFC20 Owner's Manual

Compact flash card (8 pages)

Summary of Contents for Sanyo VA-EXD1 W

Page 1: Instruction Manual

External Disc Unit Instruction manual About this manual Before installing and using this unit, please read this manual carefully. Be sure to keep it handy for later reference. Über diese Anleitung Lesen Sie bitte diese Bedienungsanleitung vor der Installation und der Verwendung des Gerätes sorgfältig durch.

<u>Page 2</u> However, in the event of a problem, the owner is advised not to attempt to make repairs or open the cabinet. Servicing should always be referred to your dealer or Sanyo Authorized Service Centre. CAUTION! Danger of explosion if battery is incorrectly replaced.

Page 3: Table Of Contents

Fitting (x1) Screw (x3) Power cord tie (x3) Instruction Manual Copyright This manual and software are copyrighted by Sanyo Electric Co., Ltd. Brand and product names used in this manual are the trademarks or registered trademarks of their respective companies.

Page 4: Before Use

Always perform test recording, and use a computer to confirm whether playback is normal. Note that Sanyo accepts no responsibility for losses occurring as a result of recording or playback problems caused by malfunction of this unit or any connected devices.

Page 5: Cleaning The Disk

BEFORE USE Cleaning the disk When there are fingerprints or dust on the recording (playback) side of the disk, it may not record properly. Also, image and/or sound quality of playback data may deteriorate. Before recording/playback, remove debris from the disk with a soft cloth by wiping the recording (playback) side outwards from the center.

Page 6: Names And Functions Of Parts

NAMES AND FUNCTIONS OF PARTS Front panel POWER POWER indicator Lights up when the power is on. Microprocessor reset button Resets the microprocessor. Disk tray Inserts CD-R/RWs or DVD+R/+RWs. Rear panel USB terminal Socket for the USB cable (accessory) when connecting the external disc unit to the DVR.

Page 7: Installation And Connection To Dvr

INSTALLATION AND CONNECTION TO DVR Installation Call a specialist to install the unit. (Do not try to install the unit yourself.) Use the following procedures to attach the external disc unit to the DVR. Docking the unit with the DVR is useful. The external disc unit and the DVR must be off

before commencing the following procedures.

Page 8: Connection

INSTALLATION AND CONNECTION TO DVR Attaching the external disc unit to the DVR Place the DVR on the external disc unit. (1) Insert the three legs of the DVR into the corresponding holes in the top of the external disk unit. The fitting should be positioned on the outside of the right side of the DVR.

Page 9: Formatting Disks

FORMATTING DISKS Formatting CD-RWs and DVD+RWs Use the following procedures to format CD-RWs and DVD+RWs. Operating the external disc unit Set the CD-RW or DVD+RW in the disk tray. Operating the DVR (DSR-5016P/5009P) When the still image on the full screen of the playback is displayed, press the [COPY] button.

<u>Page 10</u> The USB terminal is for the use of the recommended Sanyo CD-R/RW drive (sold separately). Non- recommended peripherals cannot be connected. For recommended recordable drives, check the Sanyo homepage or ask at your local Sanyo dealer. Sanyo website URL: http://www.sanyosecurity.com English...

Page 11: Appendix

APPENDIX Specifications Product name External disc unit Product number VA-EXD1B/W Disk drive Slim type Recording format ISO9660 Supported media DVD+R/+RW (VA-EXD1B only) and CD-R/RW Terminals USB terminal (USB2.0, series B terminal) (x1) Power supply voltage 120 to 240V AC, 50/60 Hz Current consumption 1000 mA Allowable operating temperature...

This manual is also suitable for:

Va-exd1wVa-exd1b