
TOSHIBA

Toshiba KT-17DRRS User Manual


Table of Contents





- T - L I		\sim \sim \sim \sim	
120	\sim	Conte	ntc.
Ian			I I I 🦠
IGN			


- 1 Electric Kettle
- 2 Safety Guide
- 3 Operation
- 4 Using Your Kettle


Download this manual














Related Manuals for Toshiba KT-17DRRS

Kettle Toshiba KT-15DRRS User Manual

(10 pages)

Kettle Toshiba KT-17DR1NMY User Manual

Electric jug kettle (8 pages)

Kettle Toshiba KT-17SHNH User Manual

(18 pages)

Kettle Toshiba KT-15DRRH User Manual

(18 pages)

Kettle Toshiba KT-17SH1NMY User Manual

(8 pages)

Kettle Toshiba KT-17DRNH Manual

(18 pages)

Kettle Toshiba KT-15DRTHK User Manual

(24 pages)

Summary of Contents for Toshiba KT-17DRRS

Page 2: Electric Kettle

ELECTRIC KETTLE MODEL: KT-17DRRS...

Page 3: Safety Guide

SAFETY GUIDE Please follow all the safety precautions listed below for safety and to reduce the risk of injury or electrical shock.

Do not touch the body of the kettle when it is hot. Always hold the appliance by the handle when using it.

...

Page 4 SAFETY GUIDE ● If any part of this appliance is damaged or malfunctions in any way, or the connecting cord or mains plug is broken, do not continue to use it. Seek expert assistance. ● "This appliance can only be used by children aged from 8 years and above and persons with reduced physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning...

Page 5 SAFETY GUIDE This appliance is intended to be used in household and ● similar applications such as: -Staff kitchen areas in shops, office and other working environments; -farm houses; -by clients in hotels, motels and other residential type environments; -In bed and breakfast type environments. If the supply cord is damaged, it must be replaced by the ●...

Page 6 ABOUT YOUR KETTLE Filter...

Page 7: Operation

USING YOUR KETTLE PRELIMINARIES Unpack your kettle and any accessories carefully. Retain the packaging so that you can transport the appliance safely. If you dispose of it please do so with regard to any recycling regulations in your area. Before using your kettle: Check that the

voltage marked on the rating plate under the kettle or the base matches your mains voltage.

Page 8: Using Your Kettle

USING YOUR KETTLE the switch down to switch the kettle on. The power switch will illuminate showing the kettle is in operation. When the water has reached the correct temperature, the power switch will switch off. You can stop the boiling at any time by lifting the switch up. To reboil, press the switch again.

<u>Page 9</u> USING YOUR KETTLE Boil Switch with Auto Shut-Out When boiling water, do NOT hold the switch down or steam will be ejected from the lid and you may damage the automatic shut off mechanism. Always ensure that the ON/OFF switch is clear of obstructions, readily operable and is not prevented from switching off.

Page 10 When the kettle is not in use, it should be stored on its base and out of the reach of children and pets. 220-240V~ KT-17DRRS 1.23kg 1800-2150W 50/60Hz THIS APPLIANCE MUST BE EARTHED...