




# Whirlpool RL-8018 Operating Instructions Manual



|                   |  |
|-------------------|--|
| 1                 |  |
| Table Of Contents |  |
| 2                 |  |
| 3                 |  |
| 4                 |  |
| 5                 |  |
| 6                 |  |
| 7                 |  |
| 8                 |  |

|   |
|---|
| c |
|---|

•

[Table of Contents](#)

•

Bookmarks

|  |
|--|
|  |
|--|

## Table of Contents

1 Table of Contents

2 Safety Notes

3 Precautions

4 Introduction


5 Appearance

6 Working Principle

[7 Installation Instruction](#)

[8 Water and Electricity Installation](#)

[Download this manual](#)



**RL-8018**

**Operating Instruction Manual**

**Size:1500X1500X520MM**

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

# Related Manuals for Whirlpool RL-8018

## [Hot Tub Whirlpool 11-0086-11 Owner's Manual](#)

Platinum elite class (66 pages)

## Summary of Contents for Whirlpool RL-8018

[Page 1](#) RL-8018 Operating Instruction Manual Size:1500X1500X520MM...

### [Page 2: Table Of Contents](#)

Catalogue 1. Safety Notes 1.1.Precautions.....1 2. Introduction 2.1.Appearance.....2  
2.2.Working Principle.....4 3. Installation Instruction 3.1.Water And Electricity Installation.... 5...

### [Page 3: Safety Notes](#)

1. Safety Notes 1.1. Precautions □ □ Please read this instruction carefully before using. □ Children need to be accompanied by an adult to use the product. □ Please do not disassemble the products' skirt freely if you are non-professionals to avoid damage to the products. □...

### [Page 4: Introduction](#)

2. Introduction 2.1. Appearance...

[Page 5](#) Number Number Sequence Brief introduction Sequence Brief introduction (PCS) (PCS)  
Waterfall On-off button Hand shower Adjust switch Faucet Big jets Overflow Backwater Drain  
Underwater LED Light...

### [Page 6: Working Principle](#)

2.2. Working Principle As the main parts of this product, electrical parts contain one 0.70KW one speed hydro massage Jet pump ,which provide you with comfortable and stable water pressure. It is allowed to adjust water pressure and water flow to meet the requirements of different customers with the switches on the edge of the bathtub.

### [Page 7: Installation Instruction](#)

3.Installation Instruction 3.1. Water And Electricity Installation Step 1□Preparation Step 2 □ Put the bathtub in the corresponding position, leveling with leveling instrument...

[Page 8](#) Step 3□Faucet installation diagram...