

Back Side - Toshiba Satellite P30-132 User Manual

Toshiba satellite p30-132: user guide

| |
|-------------------|
| 1 |
| 2 |
| 3 |
| 4 |
| 5 |
| 6 |
| 7 |
| 8 |
| 9 |
| 10 |
| 11 |
| 12 |
| 13 |
| 14 |
| 15 |
| Table Of Contents |
| 16 |
| 17 |

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165



-

[Table of Contents](#)

•

Troubleshooting

•

Bookmarks



Microphone Jack

Wireless

Communication

Back side



The following figure shows the computer back panel.

Security Lock

Security Lock

DC-IN 19V Jack

External Monitor



Port

TV Out

Universal Serial Bus
(USB) Port



User's Manual

A standard 3.5 mm mini microphone jack enables connection of a three-conductive type mini-jack for a monaural microphone.



The Wireless Communication Switch turns on the wireless networking transceiver. The Wireless Communication LED next to Wireless communication switch indicates that wireless networking is turned on.

DC-IN 19V Jack

The back side of the computer


A security candel attaches to this port. The optional security cable anchors your computer to a desk or other large object to deter theft.

The DC-IN socket is where you plug in the AC adapter.

This 15-pin port lets you connect an external video display to the computer.

Plug a 4-pin S-video cable into this connector for output of NTSC or PAL signal.

The Universal Serial Bus (USB 2.0 and 1.1) port enables USB-equipped devices (such as keyboards, mice, hard drives, scanners, and printers).



External Monitor Jack

TV out


Universal Serial
Bus (USB) Port

The Grand Tour

Modem Jack

LAN Jack

2-4



[Previous Page](#)
[Next Page](#)

1
...
42
43
44
45
46
47
48
49

Quick Links:

[Hardware](#)

[Specifications](#)

Related Manuals for Toshiba Satellite P30-132

[Laptop Toshiba P30-S6362ST User Manual](#)

P30-s6362st user's guide (230 pages)

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

[Laptop Toshiba A205-S5800 User Manual](#)

A205-s5800 user's guide (245 pages)

[Laptop Toshiba Satellite L650-0QP01X Resource Manual](#)

Toshiba satellite l650-0qp01x: reference guide (36 pages)

[Laptop Toshiba P740-BT4N22 User Manual](#)

P740-bt4n22 user's guide (246 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba A100-S2211TD User Manual](#)

A100-s2211td user's guide (289 pages)

[Laptop Toshiba L300-ST3502 User Manual](#)

L300-st3502 user's guide (230 pages)

Related Content for Toshiba Satellite P30-132

[TECRA A6 Back Side](#)

Toshiba TECRA A6

[Satellite L630 Series Back Side](#)

Toshiba Satellite L630 Series

[X200 Series Back Side](#)

Toshiba X200 Series

[Satellite A300 Back Side](#)

Toshiba Satellite A300

[mini NB200 series Back Side](#)

Toshiba mini NB200 series

[Satellite A200 series Back Side](#)

Toshiba Satellite A200 series

[A200 Series Back Side](#)

Toshiba A200 Series

[Satellite L350 series Back Side](#)

Toshiba Satellite L350 series

This manual is also suitable for:

[Satellite p30-rv2](#)[Satellite p30](#)[Satellite p30-s6362t](#)[Satellite p35-sp609](#)[Satellite p35-sp611](#)[Psp30c-jc100e](#) ... [Show all](#)