



# Ac Adaptor - Toshiba Satellite P30-132 User Manual

Toshiba satellite p30-132: user guide



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
Table Of Contents
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165



•

[Table of Contents](#)



- 

Troubleshooting

•

## Bookmarks





---

## AC adaptor

The AC adaptor converts AC power to DC power and reduces the voltage supplied to the computer. It can automatically adjust to any voltage from 100 to 240 volts and to a frequency of either 50 or 60 hertz, enabling you to use the computer in almost any country/region.

To recharge the battery, simply connect the AC adaptor to a power source and the computer. See Chapter 4, Operating Basics, for details.

*Use of the wrong adaptor could damage your computer. TOSHIBA assumes no liability for any damage in such case. The output rating for the computer is 19 volts DC.*

*Please use only the AC Adapter supplied with the computer or an AC adapter certified by TOSHIBA.*

---

User's Manual

*The AC adaptor*

The Grand Tour

2-14

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1  
...  
52  
53  
54  
55  
56  
57  
58  
59

Quick Links:

[Hardware](#)

[Specifications](#)

## Related Manuals for Toshiba Satellite P30-132

[Laptop Toshiba P30-S6362ST User Manual](#)

P30-s6362st user's guide (230 pages)

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)



P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

[Laptop Toshiba A205-S5800 User Manual](#)

A205-s5800 user's guide (245 pages)

[Laptop Toshiba Satellite L650-0QP01X Resource Manual](#)

Toshiba satellite l650-0qp01x: reference guide (36 pages)

[Laptop Toshiba P740-BT4N22 User Manual](#)

P740-bt4n22 user's guide (246 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba A100-S2211TD User Manual](#)

A100-s2211td user's guide (289 pages)

[Laptop Toshiba L300-ST3502 User Manual](#)

L300-st3502 user's guide (230 pages)

## Related Content for Toshiba Satellite P30-132

[Satellite Pro L450 Series Ac Adaptor](#)

[Toshiba Satellite Pro L450 Series](#)

[Satellite L650D Series Ac Adaptor](#)

[Toshiba Satellite L650D Series](#)

[Satellite Pro A300D Series Ac Adaptor](#)

[Toshiba Satellite Pro A300D Series](#)

[Portege X20W-D Connecting The Ac Adaptor](#)

[Toshiba Portege X20W-D](#)

[Satellite Pro R50-B series Connecting The Ac Adaptor](#)

[Toshiba Satellite Pro R50-B series](#)

[Portege 2010 Ac Adaptor](#)

[TOSHIBA Portege 2010](#)

[Tecra X40-D Connecting The Ac Adaptor](#)

[Toshiba Tecra X40-D](#)

[PORTÉGÉ X20W-D Connecting The Ac Adaptor](#)

[Toshiba PORTÉGÉ X20W-D](#)

This manual is also suitable for:

[Satellite p30-rv2](#)[Satellite p30](#)[Satellite p30-s6362t](#)[Satellite p35-sp609](#)[Satellite p35-sp611](#)[Psp30c-jc100e](#) ... [Show all](#)