

Starting Hibernation; Automatic Hibernation - Toshiba Satellite P30-132 User Manual

Toshiba satellite p30-132: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
Table Of Contents
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165



-

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Benefits of Hibernation

The hibernation feature provides the following benefits:



Saves data to the hard disk when the computer automatically shuts down because of a low battery.

For the computer to shut down in hibernation mode, the hibernation feature must be enabled in two places in TOSHIBA Power Saver: the Power Save Modes tab and the Advanced tab. Otherwise, the computer will shut down in Standby mode. If battery power becomes depleted, data saved in Standby will be lost.

You can return to your previous working environment immediately when you turn on the computer.

Saves power by shutting down the system when the computer receives no input or hardware access for the duration set by the System hibernate feature.



You can use the panel power off feature.

Starting Hibernation

You can also enable Hibernation by pressing Fn + F4. See Chapter 5, The Keyboard, for details.

To enter Hibernation mode, follow the steps below.

1. Click Start.
2. Select Turn Off Computer.
3. Open the Turn Off Computer dialog box. Hibernation is not displayed.
4. Press the Shift key. The Standby item will change to Hibernation.
5. Select Hibernation.

Automatic Hibernation

The computer will enter Hibernation mode automatically when you press the power button or close the lid. First, however, make the appropriate settings according to the steps below.

1. Open the Control Panel.
2. Open Performance and Maintenance and open Power Options.
3. Select the Hibernation tab.
4. Select Enable hibernation, then click OK button.
5. Open Toshiba Power Saver.
6. Select Setup Action tab.
7. Enable the desired Hibernation settings for When I press the power button and When I close the lid of my portable computer.
8. Click the OK button.

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
61
62
63
64
65
66
67
68

Quick Links:

[Hardware](#)

[Specifications](#)

Related Manuals for Toshiba Satellite P30-132

[Laptop Toshiba P30-S6362ST User Manual](#)

P30-s6362st user's guide (230 pages)

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

[Laptop Toshiba A205-S5800 User Manual](#)

A205-s5800 user's guide (245 pages)

[Laptop Toshiba Satellite L650-0QP01X Resource Manual](#)

Toshiba satellite l650-0qp01x: reference guide (36 pages)

[Laptop Toshiba P740-BT4N22 User Manual](#)

P740-bt4n22 user's guide (246 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba A100-S2211TD User Manual](#)

A100-s2211td user's guide (289 pages)

[Laptop Toshiba L300-ST3502 User Manual](#)

L300-st3502 user's guide (230 pages)

Related Content for Toshiba Satellite P30-132

[Satellite L500 Starting Hibernation Mode](#)

Toshiba Satellite L500

[Satellite Pro R50-B Series Starting Hibernation Mode](#)

Toshiba Satellite Pro R50-B Series

[Z30-B Starting Hibernation Mode](#)

Toshiba Z30-B

[C70-B Starting Hibernation Mode](#)

Toshiba C70-B

[R30-C Starting Hibernation Mode](#)

Toshiba R30-C

[C70-C Starting Hibernation Mode](#)

Toshiba C70-C

[Satellite S50-C Series Starting Hibernation Mode](#)

Toshiba Satellite S50-C Series

[Satellite C40-B Starting Hibernation Mode](#)

Toshiba Satellite C40-B

This manual is also suitable for:

[Satellite p30-rv2](#)[Satellite p30](#)[Satellite p30-s6362t](#)[Satellite p35-sp609](#)[Satellite p35-sp611](#)[Psp30c-jc100e](#) ... [Show all](#)