

Before Writing Or Rewriting - Toshiba Satellite P30-132 User Manual

Toshiba satellite p30-132: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
Table Of Contents
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165



-

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Before writing or rewriting

Please observe the following points when you write or rewrite the data.



We recommend the following manufacturers of CD-R and CD-RW media. Media quality can affect write or rewrite success rates. TOSHIBA has confirmed the operation of CD-R and CD-RW media of the manufacturers above. Operation of other media cannot be guaranteed.



CD-RW can generally be rewritten about 1,000 times. However, the

actual number of rewrites is affected by the quality of the media and the way it is used.



Be sure to connect the universal AC adaptor when you write or rewrite.



Be sure to close all other software programs except the writing software.



Do not run software such as a screen saver which can put a heavy load on the CPU.



Operate the computer at full power. Do not use power-saving features.



Do not write while virus check software is running. Wait for it to finish, then disable virus detection programs including any software that checks files automatically in the background.



Do not use hard disk utilities, including those intended to enhance HDD access speed. They may cause unstable operation and damage data.



Write from the computer's HDD to the CD. Do not try to write from shared devices such as a LAN server or any other network device.



Writing with software other than Sonic RecordNow! has not been confirmed. Therefore, operation with other software cannot be guaranteed.

User's Manual

CD-R:

TAIYOYUDEN CO., LTD.

MITSUBISHI CHEMICAL CORPORATION

RICOH Co., Ltd.

Hitachi Maxell Ltd.

CD-RW:

MITSUBISHI CHEMICAL CORPORATION

RICOH Co., Ltd.

Operating Basics

4-8

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
72
73
74
75
76
77
78
79

Quick Links:

[Hardware](#)

[Specifications](#)

Related Manuals for Toshiba Satellite P30-132

[Laptop Toshiba P30-S6362ST User Manual](#)

P30-s6362st user's guide (230 pages)

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

[Laptop Toshiba A205-S5800 User Manual](#)

A205-s5800 user's guide (245 pages)

[Laptop Toshiba Satellite L650-0QP01X Resource Manual](#)

Toshiba satellite l650-0qp01x: reference guide (36 pages)

[Laptop Toshiba P740-BT4N22 User Manual](#)

P740-bt4n22 user's guide (246 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba A100-S2211TD User Manual](#)

A100-s2211td user's guide (289 pages)

[Laptop Toshiba L300-ST3502 User Manual](#)

L300-st3502 user's guide (230 pages)

Related Content for Toshiba Satellite P30-132

[Satellite L630 Series Before Writing Or Rewriting](#)

Toshiba Satellite L630 Series

[Satellite P500 Before Writing Or Rewriting With The Bd-R/Re Drive](#)

Toshiba Satellite P500

[Satellite L500 Before Writing Or Rewriting](#)

Toshiba Satellite L500

[Satellite Pro R50-B Series Before Writing Or Rewriting](#)

Toshiba Satellite Pro R50-B Series

[C70-B Before Writing Or Rewriting](#)

Toshiba C70-B

[R30-C Before Writing Or Rewriting](#)

Toshiba R30-C

[C70-C Before Writing Or Rewriting](#)

Toshiba C70-C

[L70-C Before Writing Or Rewriting](#)

Toshiba L70-C

This manual is also suitable for:

[Satellite p30-rv2](#)[Satellite p30](#)[Satellite p30-s6362t](#)[Satellite p35-sp609](#)[Satellite p35-sp611](#)[Psp30c-jc100e](#) ... [Show all](#)