

TOSHIBA

Toshiba Pocket PC e400 Specifications

Toshiba pocket pc e400: specifications

1

--

•

Bookmarks

--

[Download this manual](#)

Quick Links

TOSHIBA

Toshiba Pocket PC e400 Series

Part Number	Description
-------------	-------------

PD400U-00002	e400: Intel® PXA261 at 300MHz/3.5", 240x320 TFT/16MB(ROM)/64MB(RAM)/32MB NAND (Flash ROM Disk)/SD, MS Pocket PC 2003
PD400U-00002R	e405: Intel® PXA261 at 300MHz/3.5", 240x320 TFT/16MB(ROM)/64MB(RAM)/32MB NAND (Flash ROM Disk)/SD, MS Pocket PC 2003/ArcSoft PhotoBase™

System Characteristics

- Processor
- Intel® PXA261 processor at 300MHz
- Memory
- Main memory: 64MB SDRAM; 3.3V
 - Program memory: 16MB CMOS Flash ROM

NAND Flash memory: 32MB

Display

-

3.5" TFT transreflective color display; 240 x 320 (portrait)

resolution (16 bit)

-

Backlight fluorescent lamp

-

65,536 (64K) colors; 5 step Brightness control (by Software)

Input Devices

-

Touch Panel: Analog resistance sensitive system touch panel

-

Controls/Buttons: 5-way navigation button; 4 application keys-

Calendar, Contacts, Task, Menu; 3 function navigator (Toshiba

Scroller) for Up, Down and Action; Reset switch; Voice record

button; Power on/off button; Battery on/off switch, Hold switch,

Stylus pen

Expandability

-

1 SD (Secure Digital) card slot (3.3V) – SDIO Now!!

Ports

-

Cradle Connection port – (USB Client, USB Host***)

-

IrDA Infrared port (115kbps)

-

DC-in

-

Stereo headphone jack

Physical Description

-

Dimensions (LxWxH): 4.9" x 3.0" x 0.4"

-

Weight: 4.6oz (w/Stylus & battery)

-

LED Indicators: One 2 color (Green, Orange) LED for Power

Indication:

1. Green: Full Charge (while power source is AC adaptor)

2. Orange: Charging (while power source is AC adaptor)

3. Orange Flash: Alarm

4. Yellow (Green and Orange): Out of Temperature

5. Off: Power on/off

Sound

-

AC-97 Codec Chip; WM9712L Sound Chip

-

16-bit stereo; 44.1KHz Sample Rate

-

Full Duplex support

-

Software Volume Control (by software)

-

Built-in Microphone and Built-in Speaker

-

Stereo Headphone jack

Power Supply

-

AC Adapter: 5V/2A DC output; 100-240V input voltage, 50/60Hz frequency

-

Battery Pack: Rechargeable Lithium-Ion battery; 3.7V / 980 mAh

-

Battery Saver: Stand by, Display Auto Off

-

ManualsLib.com

Recharge time (Main battery on/off): 4h/4h

Battery life may vary depending on applications, power management settings and features utilized. Recharge time varies depending on usage.

Operating System

- _____

Microsoft® Mobile Software for Pocket PC 2003 Professional Edition

Additional Software

-

Pocket Word

- _____

Pocket Excel

-

Pocket Internet Explorer

-

Microsoft® Windows® Media™ Player 9 for Pocket PC

-

File Explorer

-

Microsoft® Active Sync® 3.7

-

Microsoft® Outlook®

- _____

World Clock

- _____

Toshiba Voice Recorder

- _____

Toshiba Text to Speech for Pocket PC

- _____

Voice Command

Toshiba America Information Systems Inc. ("TAIS") shall not be liable for damages of any kind for use of this information, which is subject to change without

notice. Copyright 2003 TAIS pocketpc_e400.doc

Warranty

Environmental Specifications

Box Contents

Product/Part Numbers/UPC

Pocket PC e400

Pocket PC e405

Accessories

Select Toshiba Accessories

PA1340U-1PPS

PA3321U-1ACA

PA3325U-1DST

PA3324U-1ETC

PA3320U-1ETC

PA1347U-1PMS

PA3281U-1ETC

Toshiba SD Memory

SD-M3203B3

SD-M6403B3

SD-M2564B3

SD-M5124B3

Toshiba Cases

PA1307U-1PCS

PA1348U-1PCS

PA1343U-1PCS

*** requires USB Host Cable (PA3324U-1ETC) to connect select USB devices

Created on 9/12/2003 5:20 PM

-

ArcSoft PhotoBase™ (e405 only)

-

ManualsLib.com

1 year parts, labor and battery

-

90-day limited warranty on operating system and applications

-

Temperature: Operating: 0° to 40°C (32° to 104°F); Non-operating: -20° to 65°C (-4° to 149°F)

-

Relative Humidity: Operating: 30% to 80%

-

Altitude (relative to sea level):

Operating: 10,000ft; Altitude change rate: 2000ft/min.

Non-operating: 40,000ft; Altitude change rate: 2000ft/min.

-

PDA, Stylus, AC Adapter/Power Cable, USB Client Cable, Warranty Card, Quick Start Card, Safety Instructions, EULA, Companion CD

Power Sync Cable w/CLA

15W AC Adapter

USB Cradle (requires optional AC Adapter)

USB Host Keyboard Cable

Stylus Pen (3-pack)

Screen Overlays

Earphones

32MB Secure Digital (SD) Card

64MB Secure Digital (SD) Card

256MB Secure Digital (SD) Card

512MB Secure Digital (SD) Card

Toshiba Leather Universal PDA Case

Toshiba Enhanced Protection Case

Toshiba Case

Rev. 1.0c

PD400U-00002

PD400U-00002R

Page 1 of 1

Related Manuals for Toshiba Pocket PC e400

[Handhelds Toshiba e400 User Manual](#)

Toshiba pocket pc user's manual e400, e405 (118 pages)

[Handhelds Toshiba e830 Series User Manual](#)

(230 pages)

[Handhelds Toshiba Pocket PC e830 User Manual](#)

(30 pages)

[Handhelds Toshiba Pocket PC e350 Specifications](#)

Toshiba pocket pc e350: specifications (1 page)

[Handhelds Toshiba Pocket PC e750 Specifications](#)

Toshiba pocket pc e750: specifications (2 pages)

[Handhelds Toshiba Pocket PC e755 Specifications](#)

Toshiba pocket pc e755: specifications (1 page)

[Handhelds Toshiba Pocket PC e800 Specifications](#)

Toshiba pocket pc e800: specifications (2 pages)

[Handhelds Toshiba e800 User Manual](#)

Toshiba pocket pc user's guide (236 pages)

[Handhelds Toshiba Pockey PC e800 User Manual](#)

(223 pages)

[Handhelds Toshiba e355 User Manual](#)

E355 user's guide (116 pages)

[Handhelds Toshiba e750 User Manual](#)

Toshiba pocket pc user's manual e750 (215 pages)

[Handhelds Toshiba e310 User Manual](#)

Toshiba user's manual pocket pc e310 (104 pages)

[Handhelds Toshiba e350 User Manual](#)

Toshiba user's manual pocket pc e350 (105 pages)

[Handhelds Toshiba e755 User Manual](#)

Toshiba pocket pc user's guide (187 pages)

[Handhelds Toshiba e740 User Manual](#)

Toshiba user's manual pda e740 (182 pages)

[Handhelds TOSHIBA e570 Instruction Manual](#)

Pocket pc (103 pages)

Related Products for Toshiba Pocket PC e400

[Toshiba E310 - Pocket PC](#)

[Toshiba e350 Series](#)

[Toshiba e740](#)

[Toshiba E335 - Pocket PC - Win Mobile](#)

[Toshiba e750 - Pocket PC](#)

[Toshiba e570](#)

[Toshiba e805](#)

[Toshiba e355](#)

[Toshiba e755 - Pocket PC With Windows Mobile 2003](#)

[Toshiba e755](#)

[Toshiba e830 Series](#)

[Toshiba E40 - A Series](#)

[Toshiba E-studio856se](#)

[Toshiba e-STUDIO6570C Series](#)

[Toshiba e-STUDIO455 Series](#)

[Toshiba E-STUDIO3505AC](#)

This manual is also suitable for:

Pocket pc e405E400E405Pd400u-00002Pd400u-00002r