



Asus CW101 Quick Start Manual

Wireless keyboard and mouse set

1
2

--

•

Bookmarks

--


[Download this manual](#)

Quick Links



148*99mm

80g



Model:

Product Name:

Hardware Version:

Software Version:

CE RED RF Output table (Directive 2014/53/EU)


Max Output Power (EIRP):

Operating Frequency Range:

Frequency Deviation:

Modulation Type:

Mouse Resolution:



Battery:

Power Rated:

Operation Distance:

Keyboard Dimension:

Mouse Dimension:


Dongle Dimension:

Operating Temperature:

System Requirements:

Package contents:

CW101 Keyboard*1, CW101 Mouse*1, USB dongle*1 (stored inside the mouse), Quick Start Guide and Warranty card*1, AAA Alkaline Battery*1, AA Alkaline Battery*1



Installing the batteries

1. Insert the batteries (one AAA battery for keyboard and one AA battery for mouse) into the battery slots of your keyboard and mouse.

The low battery indicator of the keyboard flashes red when the battery is low.

Please replace the battery when the low battery indicator flashes red.

2. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

Your keyboard and mouse is set at the factory to automatically connect to the system. You do not need to press the Connect button on your keyboard and mouse to manually connect to the system.

Keyboard hotkeys

Hotkeys

<Fn+F1>: My Music

<Fn+F3>: Volume +

<Fn+F5>: Previous Track

<Fn+F7>: Next Track

<Fn+F9>: Screenshot

<Fn+F11>: My PC

All above hotkeys can work with Windows® 10 or above.

CW101 is compatible with Windows® 11 and older versions. Some hotkeys only work with Windows® 10 or above. User experience may vary depending on the OS.

E22085a_CW101_KB_MS_QSG.indd 1

Wireless Keyboard and Mouse Set CW101

Keyboard

CW101

Wireless Keyboard

ZV1.0

3FFC

6.23dbm

2402 MHz - 2480 MHz

+/- 144KHz

GFSK

1000 DPI

Keyboard - AAA battery x1; Mouse - AA battery x1

Keyboard: 1.5V/9mA; Mouse: 1.5V/10mA; Dongle: 5V/30mA



[Next Page](#)

1
2

Related Manuals for Asus CW101

[Computer Accessories Asus Audio Cover CA71 User Manual](#)

(112 pages)

[Computer Accessories Asus Chromebit CS10 Quick Start Manual](#)

(2 pages)

[Computer Accessories Asus CA81 User Manual](#)

Audio cover (112 pages)

[Asus CW100 - Wireless Keyboard And Mouse Set Manual](#)

(article)

[Computer Accessories Asus Prime AP201 User Manual](#)

(32 pages)

[Computer Accessories Asus Eee Keyboard & Mouse Kit Manual](#)

(2 pages)

[Computer Accessories Asus ROG-THOR Series Quick Start Manual](#)

Power supply unit (141 pages)

[Computer Accessories Asus P2000 User Manual](#)

Keyboard and mouse set (2 pages)

[Computer Accessories Asus TUF Gaming GT 501 User Manual](#)

(28 pages)

[Computer Accessories Asus Varidrive Installation Manual](#)

Varidrive (4 pages)

[Computer Accessories Asus VENTO 3600 Quick Start Manual](#)

(2 pages)

[Computer Accessories Asus W3000 Quick Start Manual](#)

Wireless keyboard & mouse kit (2 pages)

[Computer Accessories Asus TA-55 User Manual](#)

Screwless model (2 pages)

[Computer Accessories Asus Xonar HDAV 1.3 Slim Quick Start Manual](#)

Av card (44 pages)

[Computer Accessories Asus Eee Keyboard + Mouse Set User Manual](#)

(43 pages)

Summary of Contents for Asus CW101

[Page 1](#) • All above hotkeys can work with Windows® 10 or above. • CW101 is compatible with Windows® 11 and older versions. Some hotkeys only work with Windows® 10 or above. User experience may vary depending on the OS. E22085a_CW101_KB_MS_QSG.indd 1...

[Page 2](#) ASUSTeK Computer Inc., bu aygıtın 2014/53/ ASUSTeK Computer Inc. hereby declares that connection or malfunction of a peripheral by ASUS will be deemed to be the start of the EU Yönergesinin temel gereksinimlerine ve this device is in compliance with the essential device such as printer, optical drive, Warranty Period.

This manual is also suitable for:

Cw101-mCw101-d