

Vcr Code Table - Toshiba
COLORSTREAM 43A10 Owner's
Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



VCR code table

Brand
name
Adventura
Aiko
Aiwa
Akai
American
High
Asha
Audiovox
Beaurnark
Bell & Howd
Bran&
Broksonic
Calix
Canon
Capeheart
Carver
CCE
Citizen
Colt
Craig
Curtis Mathes

VCR code table

| Brand name | Code number | | | |
|-------------------|----------------------------|----------|----------------------------|-------------|
| Adventura | 019 | Jensen | 060 | Quartz |
| Aiko | 297 | JVC | 027, 060, 086 | Quasar |
| Aiwa | 019 | Kenwood | 057, 060, 086 | Radio Shack |
| Akai | 060, 068, 080, 125, 261 | KLH | 091 | Radix |
| American High | 054 | Kodak | 054, 056 | Randex |
| Asha | 259 | Lloyd | 019 | RCA |
| Audiovox | 056 | Lloyd's | 227 | |
| Beaurnark | 259 | logik | 091 | Realistic |
| Bell & Howell | 123 | LXI | 056 | |
| Brandt | 206 | Magnavox | 054, 058, 100, 129, 168 | Ricoh |

Cybernex

Daewoo
 Daytron
 Dynatech
 EDctrohome
 Electrophonic
 Emerex
 Emerson
 Fisher
 Fuji
 Funai
 Garrard
 GE
 Go Video
 GoldStar
 Gradiente
 Harley Davidson
 Harman/Kardon
 Harwood
 Headquarter
 HI-Q
 Hitachi
 Code number
 019
 297
 019
 060, 068, 080, 125,
 261
 054
 259
 056
 259
 123
 206
 140, 203, 230, 314,
 380
 056
 054
 039
 100
 091,297
 056, 297
 091
 056, 066, 091,259
 054, 060, 079
 259
 039, 064, 297
 039
 019
 056
 056
 051
 019, 021,056,
 062,
 080, 087, 140, 203,
 227, 228, 230, 231,
 297, 313, 314, 380,
 498
 066, 073, 085, 123
 052, 054
 019, 344
 019, 344
 054, 079, 084, 221
 251,298
 037, 056, 057
 019
 019
 057, 094
 087, 091
 065
 066
 060, 061,084,
 124,
 185,254
 Jensen
 JVC
 Kenwood

VCR code table

| Brand name | Code number | | |
|-----------------|---|----------------|---|
| Adventura | 019 | Jensen | 060 |
| Aiko | 297 | JVC | 027, 060, 086 |
| Aiwa | 019 | Kenwood | 057, 060, 086 |
| Akai | 060, 068, 080, 125, 261 | KLH | 091 |
| American High | 054 | Kodak | 054, 056 |
| Asha | 259 | Lloyd | 019 |
| Audiovox | 056 | Lloyd's | 227 |
| Beaumark | 259 | logik | 091 |
| Bell & Howell | 123 | LXI | 056 |
| Brandt | 206 | Magnavox | 054, 058, 100, 129, 168 |
| Broksonic | 140, 203, 230, 314, 380 | Magnin | 259 |
| Calix | 056 | Marantz | 054, 100 |
| Canon | 054 | Marta | 056 |
| Capeheart | 039 | Matsushita | 054 |
| Carver | 100 | MEI | 054 |
| CCE | 091, 297 | Memorex | 019, 054, 056, 058, 065, 066, 067, 123, 259 |
| Citizen | 056, 297 | MGA | 062, 080 |
| Colt | 091 | MGN Technology | 259 |
| Craig | 056, 066, 091, 259 | Minolta | 061, 124 |
| Curtis Mathes | 054, 060, 079 | Mitsubishi | 062, 080, 086, 094, 192, 233, 261 |
| Cybernex | 259 | Motorola | 054, 067 |
| Daewoo | 039, 064, 297 | MTC | 019, 259 |
| Daytron | 039 | Multitech | 019, 091 |
| Dynatech | 019 | NAD | 077 |
| Electrohome | 056 | NEC | 057, 059, 060, 069, 086 |
| Electrophonic | 056 | Nikko | 056 |
| Emerex | 051 | Noblex | 259 |
| Emerson | 019, 021, 056, 062, 080, 087, 140, 203, 227, 228, 230, 231, 297, 313, 314, 380, 498 | Olympus | 054 |
| Fisher | 066, 073, 085, 123 | Optimus | 056, 067, 077, 123 |
| Fuji | 052, 054 | Optonica | 081 |
| Funai | 019, 344 | Orion | 498 |
| Garrard | 019, 344 | Panasonic | 054, 096, 181, 244, 473 |
| GE | 054, 079, 084, 221 | Penney | 054, 056, 057, 059, 061, 073, 259 |
| Go Video | 251, 298 | Pentax | 061, 084, 124 |
| GoldStar | 037, 056, 057 | Philco | 054 |
| Gradiente | 019 | Philips | 054, 081, 100, 129 |
| Harley Davidson | 019 | Pilot | 056 |
| Harman/Kardon | 057, 094 | Quartz | |
| | | Quasar | |
| | | Radio Shack | |
| | | Radix | |
| | | Randex | |
| | | RCA | |
| | | Realistic | |
| | | Ricoh | |
| | | Runco | |
| | | Samsung | |
| | | Sanky | |
| | | Sansui | |
| | | Sanyo | |
| | | Scott | |
| | | Sears | |
| | | Sharp | |
| | | Shintom | |
| | | Shogun | |
| | | Singer | |
| | | Sony | |
| | | STS | |
| | | Sylvania | |
| | | Symphonic | |
| | | Tatung | |
| | | Teac | |
| | | Technics | |
| | | Teknika | |
| | | Telefunken | |
| | | TMK | |
| | | Toshiba | |
| | | Totevision | |
| | | Unitech | |
| | | Vector | |
| | | Vector Resea | |
| | | Video Conce | |
| | | Videosonic | |

KLH
 Kodak
 Lloyd
 Lloyd's
 logik
 LXI
 Magnavox
 Magnin
 Marantz
 Marta
 Matsushita
 ME1
 Memorex
 MGA
 MGN Technology
 Minolta
 Mitsubishi
 Motorola
 MTC
 Multitech
 NAD
 NEC
 Nikko
 Noblex
 Olympus
 Optimus
 Optonica
 Orion
 Panasonic
 Penney
 Pentax
 Philco
 Philips
 Pilot
 Pioneer
 Pordand
 Protec
 Pulsar
 Quarter
 O60
 O27,
 O57,
 O91
 O54,
 O19
 227
 O91
 O56
 O54,
 168
 259
 O54,
 O56
 O54
 O54
 O19,
 O65,
 259
 O62,
 259
 O61,
 O62,
 192,
 O54,
 O19,
 O19,
 O77
 O57,
 O86
 O56
 259
 O54
 O56,
 O81
 498
 O54,
 473

VCR code table

| Brand name | Code number | | |
|-----------------|---|----------------|---|
| Adventura | 019 | Jensen | 060 |
| Aiko | 297 | JVC | 027, 060, 086 |
| Aiwa | 019 | Kenwood | 057, 060, 086 |
| Akai | 060, 068, 080, 125, 261 | KLH | 091 |
| American High | 054 | Kodak | 054, 056 |
| Asha | 259 | Lloyd | 019 |
| Audiovox | 056 | Lloyd's | 227 |
| Beaumarck | 259 | logik | 091 |
| Bell & Howell | 123 | LXI | 056 |
| Brandt | 206 | Magnavox | 054, 058, 100, 129, 168 |
| Broksonic | 140, 203, 230, 314, 380 | Magnin | 259 |
| Calix | 056 | Marantz | 054, 100 |
| Canon | 054 | Marta | 056 |
| Capeheart | 039 | Matsushita | 054 |
| Carver | 100 | ME1 | 054 |
| CCE | 091, 297 | Memorex | 019, 054, 056, 058, 065, 066, 067, 123, 259 |
| Citizen | 056, 297 | MGA | 062, 080 |
| Colt | 091 | MGN Technology | 259 |
| Craig | 056, 066, 091, 259 | Minolta | 061, 124 |
| Curtis Mathes | 054, 060, 079 | Mitsubishi | 062, 080, 086, 094, 192, 233, 261 |
| Cybernex | 259 | Motorola | 054, 067 |
| Daewoo | 039, 064, 297 | MTC | 019, 259 |
| Daytron | 039 | Multitech | 019, 091 |
| Dynatech | 019 | NAD | 077 |
| Electrohome | 056 | NEC | 057, 059, 060, 069, 086 |
| Electrohome | 056 | Nikko | 056 |
| Emerex | 051 | Noblex | 259 |
| Emerson | 019, 021, 056, 062, 080, 087, 140, 203, 227, 228, 230, 231, 297, 313, 314, 380, 498 | Olympus | 054 |
| Fisher | 066, 073, 085, 123 | Optimus | 056, 067, 077, 123 |
| Fuji | 052, 054 | Optonica | 081 |
| Funai | 019, 344 | Orion | 498 |
| Garrard | 019, 344 | Panasonic | 054, 096, 181, 244, 473 |
| GE | 054, 079, 084, 221 | Penney | 054, 056, 057, 059, 061, 073, 259 |
| Go Video | 251, 298 | Pentax | 061, 084, 124 |
| GoldStar | 037, 056, 057 | Philco | 054 |
| Gradiente | 019 | Philips | 054, 081, 100, 129 |
| Harley Davidson | 019 | Pilot | 056 |
| Harman/Kardon | 057, 094 | Quartz | |
| | | Quasar | |
| | | Radio Shack | |
| | | Radix | |
| | | Randex | |
| | | RCA | |
| | | Realistic | |
| | | Ricoh | |
| | | Runco | |
| | | Samsung | |
| | | Sanky | |
| | | Sansui | |
| | | Sanyo | |
| | | Scott | |
| | | Sears | |
| | | Sharp | |
| | | Shintom | |
| | | Shogun | |
| | | Singer | |
| | | Sony | |
| | | STS | |
| | | Sylvania | |
| | | Symphonic | |
| | | Tatung | |
| | | Teac | |
| | | Technics | |
| | | Teknika | |
| | | Telefunken | |
| | | TMK | |
| | | Toshiba | |
| | | Totevision | |
| | | Unitech | |
| | | Vector | |
| | | Vector Resea | |
| | | Video Conce | |
| | | Videosonic | |

054,
061,
061,
054
054,
056
077,
039
091
058
065
060, 086
060, 086
056
058, 100, 129,
100
054, 056, 058,
066, 067, 123,
080
124
080, 086, 094,
233, 261
067
259
091
059, 060, 069,
067, 077, 123
096, 181, 244,
056, 057, 059,
073, 259
084, 124
081, 100, 129
086
Quartz
Quasar
Radio Shack
Radix
Randex
RCA
Realistic
Ricoh
Runco
Samsung
Sanky
Sansui
Sanyo
Scott
Sears
Sharp
Shintom
Shogun
Singer
Sony
STS
Sylvania
Symphonic
Tatung
Tcac
Technics
Tecnika
Telefunken
TMK
Toshiba
Totevision
Unitech
Vector
Vector Research
Video Concepts
Videosonic
V-A_rds
XR- 100 0

VCR code table

| Brand name | Code number | | |
|-----------------|---|----------------|---|
| Adventura | 019 | Jensen | 060 |
| Aiko | 297 | JVC | 027, 060, 086 |
| Aiwa | 019 | Kenwood | 057, 060, 086 |
| Akai | 060, 068, 080, 125, 261 | KLH | 091 |
| American High | 054 | Kodak | 054, 056 |
| Asha | 259 | Lloyd | 019 |
| Audiovox | 056 | Lloyd's | 227 |
| Beaumarck | 259 | logik | 091 |
| Bell & Howell | 123 | LXI | 056 |
| Brandt | 206 | Magnavox | 054, 058, 100, 129, 168 |
| Broksonic | 140, 203, 230, 314, 380 | Magnin | 259 |
| Calix | 056 | Marantz | 054, 100 |
| Canon | 054 | Marta | 056 |
| Capeheart | 039 | Matsushita | 054 |
| Carver | 100 | MEI | 054 |
| CCE | 091, 297 | Memorex | 019, 054, 056, 058, 065, 066, 067, 123, 259 |
| Citizen | 056, 297 | MGA | 062, 080 |
| Colt | 091 | MGN Technology | 259 |
| Craig | 056, 066, 091, 259 | Minolta | 061, 124 |
| Curtis Mathes | 054, 060, 079 | Mitsubishi | 062, 080, 086, 094, 192, 233, 261 |
| Cybernex | 259 | Motorola | 054, 067 |
| Daewoo | 039, 064, 297 | MTC | 019, 259 |
| Daytron | 039 | Multitech | 019, 091 |
| Dynatech | 019 | NAD | 077 |
| Electrohome | 056 | NEC | 057, 059, 060, 069, 086 |
| Electrophonic | 056 | Nikko | 056 |
| Emerex | 051 | Noblex | 259 |
| Emerson | 019, 021, 056, 062, 080, 087, 140, 203, 227, 228, 230, 231, 297, 313, 314, 380, 498 | Olympus | 054 |
| Fisher | 066, 073, 085, 123 | Optimus | 056, 067, 077, 123 |
| Fuji | 052, 054 | Optonica | 081 |
| Funai | 019, 344 | Orion | 498 |
| Garrard | 019, 344 | Panasonic | 054, 096, 181, 244, 473 |
| GE | 054, 079, 084, 221 | Penney | 054, 056, 057, 059, 061, 073, 259 |
| Go Video | 251, 298 | Pentax | 061, 084, 124 |
| GoldStar | 037, 056, 057 | Philco | 054 |
| Gradiente | 019 | Philips | 054, 081, 100, 129 |
| Harley Davidson | 019 | Pilot | 056 |
| Harman/Kardon | 057, 094 | Quartz | |
| | | Quasar | |
| | | Radio Shack | |
| | | Radix | |
| | | Randex | |
| | | RCA | |
| | | Realistic | |
| | | Ricoh | |
| | | Runco | |
| | | Samsung | |
| | | Sanky | |
| | | Sansui | |
| | | Sanyo | |
| | | Scott | |
| | | Sears | |
| | | Sharp | |
| | | Shintom | |
| | | Shogun | |
| | | Singer | |
| | | Sony | |
| | | STS | |
| | | Sylvania | |
| | | Symphonic | |
| | | Tatung | |
| | | Teac | |
| | | Technics | |
| | | Tecnika | |
| | | Telefunken | |
| | | TMK | |
| | | Toshiba | |
| | | Totevision | |
| | | Unitech | |
| | | Vector | |
| | | Vector Resea | |
| | | Video Conce | |
| | | Videosonic | |

065
 054,
 019,
 056
 056
 061,
 124,
 019,
 066,
 123,
 053
 058
 064,
 058,
 060,
 065,
 062,
 229,
 054,
 066,
 124
 067,
 091
 259
 091
 051,
 061
 019,
 129
 019,
 060
 019,
 054,
 019,
 206
 227,
 062,
 231,
 056,
 259
 064
 057,
 059,
 259
 019,
 067,
 231,
 019,
 057
 052,
 096
 056, 344
 079, 084, 096,
 125, 168, 221
 054, 056, 065,
 067, 081, 085,
 259
 259
 067
 086
 066, 123, 259
 064, 140, 203,
 230, 231
 056, 061, 065,
 073, 085, 123,
 081
 052, 053, 054
 054, 062, 100,
 344
 060
 181
 054, 056, 071
 259
 064, 085, 229
 385

VCR code table

| Brand name | Code number | | |
|-----------------|---|----------------|---|
| Adventura | 019 | Jensen | 060 |
| Aiko | 297 | JVC | 027, 060, 086 |
| Aiwa | 019 | Kenwood | 057, 060, 086 |
| Akai | 060, 068, 080, 125, 261 | KLH | 091 |
| American High | 054 | Kodak | 054, 056 |
| Asha | 259 | Lloyd | 019 |
| Audiovox | 056 | Lloyd's | 227 |
| Beaumarck | 259 | logik | 091 |
| Bell & Howell | 123 | LXI | 056 |
| Brandt | 206 | Magnavox | 054, 058, 100, 129, 168 |
| Broksonic | 140, 203, 230, 314, 380 | Magnin | 259 |
| Calix | 056 | Marantz | 054, 100 |
| Canon | 054 | Marta | 056 |
| Capeheart | 039 | Matsushita | 054 |
| Carver | 100 | MEI | 054 |
| CCE | 091, 297 | Memorex | 019, 054, 056, 058, 065, 066, 067, 123, 259 |
| Citizen | 056, 297 | MGA | 062, 080 |
| Colt | 091 | MGN Technology | 259 |
| Craig | 056, 066, 091, 259 | Minolta | 061, 124 |
| Curtis Mathes | 054, 060, 079 | Mitsubishi | 062, 080, 086, 094, 192, 233, 261 |
| Cybernex | 259 | Motorola | 054, 067 |
| Daewoo | 039, 064, 297 | MTC | 019, 259 |
| Daytron | 039 | Multitech | 019, 091 |
| Dynatech | 019 | NAD | 077 |
| Electrohome | 056 | NEC | 057, 059, 060, 069, 086 |
| Electrophonic | 056 | Nikko | 056 |
| Emerex | 051 | Noblex | 259 |
| Emerson | 019, 021, 056, 062, 080, 087, 140, 203, 227, 228, 230, 231, 297, 313, 314, 380, 498 | Olympus | 054 |
| Fisher | 066, 073, 085, 123 | Optimus | 056, 067, 077, 123 |
| Fuji | 052, 054 | Optonica | 081 |
| Funai | 019, 344 | Orion | 498 |
| Garrard | 019, 344 | Panasonic | 054, 096, 181, 244, 473 |
| GE | 054, 079, 084, 221 | Penney | 054, 056, 057, 059, 061, 073, 259 |
| Go Video | 251, 298 | Pentax | 061, 084, 124 |
| GoldStar | 037, 056, 057 | Philco | 054 |
| Gradiente | 019 | Philips | 054, 081, 100, 129 |
| Harley Davidson | 019 | Pilot | 056 |
| Harman/Kardon | 057, 094 | Quartz | |
| | | Quasar | |
| | | Radio Shack | |
| | | Radix | |
| | | Randex | |
| | | RCA | |
| | | Realistic | |
| | | Ricoh | |
| | | Runco | |
| | | Samsung | |
| | | Sanky | |
| | | Sansui | |
| | | Sanyo | |
| | | Scott | |
| | | Sears | |
| | | Sharp | |
| | | Shintom | |
| | | Shogun | |
| | | Singer | |
| | | Sony | |
| | | STS | |
| | | Sylvania | |
| | | Symphonic | |
| | | Tatung | |
| | | Teac | |
| | | Technics | |
| | | Teknika | |
| | | Telefunken | |
| | | TMK | |
| | | Toshiba | |
| | | Totevision | |
| | | Unitech | |
| | | Vector | |
| | | Vector Resea | |
| | | Video Conce | |
| | | Videosonic | |

259
059
064, 080
054, 061,066,
081,091,
168,
259
054, 091
053, 058
13

VCR code table

| Brand name | Code number | | | |
|------------|-------------|--------|-----|--------|
| Adventura | 019 | Jensen | 060 | Quartz |

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
10
11
12
13
14
15
16
17

Related Manuals for Toshiba COLORSTREAM 43A10

[TV Toshiba 43A10 Service Manual](#)

(104 pages)

[Projection TV Toshiba 43A10 Owner's Manual](#)

Colorstream projection television (47 pages)

[TV Toshiba 43A10 Service Manual](#)

(8 pages)

[Projection TV Toshiba 43H72 Owner's Manual](#)

Toshiba owner's manual projection television 43h72, 50h72 (56 pages)

[Projection TV Toshiba 43H72 Specifications](#)

Theaterview hd (2 pages)

[Projection TV Toshiba 43HX71 Owner's Manual](#)

Toshiba owner's manual projection television 43hx71, 53hx71 (56 pages)

[Projection TV Toshiba 43A61 Owner's Manual](#)

Projection television (52 pages)

[Projection TV Toshiba 43H70 Owner's Manual](#)

Colorstream projection television (48 pages)

[Projection TV Toshiba 43H71 Owner's Manual](#)

Toshiba projection television owner's manual (52 pages)

[Projection TV Toshiba 43H71 Owner's Manual](#)

(53 pages)

[Projection TV Toshiba COLORSTREAM 43A61 Owner's Manual](#)

(53 pages)

[Projection TV Toshiba 43AX60 Owner's Manual](#)

Colorstream projection television (54 pages)

[Projection TV Toshiba COLOASTREAM 43AX60 Owner's Manual](#)

(54 pages)

[Projection TV Toshiba 50PH46P Service Manual](#)

Wh4 chassis (78 pages)

[Projection TV Toshiba 43PH46P Service Manual](#)

(78 pages)

[Projection TV Toshiba 50HX70 Owner's Manual](#)

Colorstream projection television (56 pages)

Related Content for Toshiba COLORSTREAM 43A10

[43H72 Vcr Code Table](#)

Toshiba 43H72

[43H71 Vcr Code Table](#)

Toshiba 43H71

[42H83 Vcr Code Table](#)

Toshiba 42H83

[ColorStream TZ61V61 Vcr Code Table](#)

Toshiba ColorStream TZ61V61

[TE50T11 Vcr Code Table](#)

Toshiba TE50T11

[50H13 Vcr Code Table](#)

Toshiba 50H13

[50H71 Vcr Code Table](#)

Toshiba 50H71

[50H12 Vcr Code Table](#)

Toshiba 50H12