

Using The Surround Sound Feature - Toshiba COLORSTREAM 43A10 Owner's Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Using the surround sound feature

The surround sound feature expands the audio listening field wider and deeper to create exceptional sound quality from the TV's speakers. The feature uses stereo signals from a TV broadcast or video input.

Using the surround sound feature

To turn on the surround sound feature:

1. Select the stereo mode following the steps under "Selecting stereo/SAP broadcasts" on page 37.
2. Press MEN U, then press 4 or _ until the THEATER menu appears.


To turn off the surround sound feature:

3. Press A or Y to highlight SURROUND.
4. Press 4 or _ to highlight MATRIX.

THEATER
MENU

2. Press MENU, then press ◀ or ▶ until the THEATER menu appears. Choose OFF in step 4 above.

In general, you can leave your TV in MATRIX mode because it automatically produces surround stereo or monaural sound, depending on the broadcast type.



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
35
36
37
38
39
40
41
42

Related Manuals for Toshiba COLORSTREAM 43A10

[TV Toshiba 43A10 Service Manual](#)

(104 pages)

[Projection TV Toshiba 43A10 Owner's Manual](#)

Colorstream projection television (47 pages)

[TV Toshiba 43A10 Service Manual](#)

(8 pages)

[Projection TV Toshiba 43H72 Owner's Manual](#)

Toshiba owner's manual projection television 43h72, 50h72 (56 pages)

[Projection TV Toshiba 43H72 Specifications](#)

Theaterview hd (2 pages)

[Projection TV Toshiba 43HX71 Owner's Manual](#)

Toshiba owner's manual projection television 43hx71, 53hx71 (56 pages)

[Projection TV Toshiba 43A61 Owner's Manual](#)

Projection television (52 pages)

[Projection TV Toshiba 43H70 Owner's Manual](#)

Colorstream projection television (48 pages)

[Projection TV Toshiba 43H71 Owner's Manual](#)

Toshiba projection television owner's manual (52 pages)

[Projection TV Toshiba 43H71 Owner's Manual](#)

(53 pages)

[Projection TV Toshiba COLORSTREAM 43A61 Owner's Manual](#)

(53 pages)

[Projection TV Toshiba 43AX60 Owner's Manual](#)

Colorstream projection television (54 pages)

[Projection TV Toshiba COLOASTREAM 43AX60 Owner's Manual](#)

(54 pages)

[Projection TV Toshiba 50PH46P Service Manual](#)

Wh4 chassis (78 pages)

[Projection TV Toshiba 43PH46P Service Manual](#)

(78 pages)

[Projection TV Toshiba 50HX70 Owner's Manual](#)

Colorstream projection television (56 pages)

Related Content for Toshiba COLORSTREAM 43A10

[65HC15 Using The Wow Surround Sound Feature](#)

Toshiba 65HC15

[55A10 Using The Surround Sound Feature](#)

Toshiba 55A10

[TheaterWide 51HC85 Using The Wow ® Surround Sound Feature](#)

Toshiba TheaterWide 51HC85

[50A50 Using The Surround Sound Feature](#)

Toshiba 50A50

[43AX60 Using The Surround Sound Feature](#)

Toshiba 43AX60

[42HDX82 Using The Wow Surround Sound Feature](#)

Toshiba 42HDX82

[62MX196 Using The Srs Wow™ Surround Sound Feature](#)

Toshiba 62MX196

[56MX195 Using The Srs Wow™ Surround Sound Feature](#)

Toshiba 56MX195