

TOSHIBA

1 2 3 4 5

MEMORY FM/AM

< TUNING >

HOUR MIN

ALARM STOP

MODE ALARM



AUTO REVERSE

DOLBY SYSTEM

GRAPHIC EQUALIZER

100Hz -10 0 +10

1kHz -10 0 +10

10kHz -10 0 +10

10 STATION PRESET

DIGITAL/TUNER/

# Toshiba KT-4568 Service Data

Stereo radio cassette player



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16

• PAGE

1



•

## Bookmarks

[Download this manual](#)

## Quick Links



SERVICE

DATA

FILE NO. 100-304

SEI  
FILE

**TOSHIBA**

STEREO  
RADIO **TOSHIBA**

STEREO RADIO CASSETTE PLAYER



CASSETTE  
PLAYER

# KT-4568

SEE  
FILE

70 STATION PRESET  
DIGITAL TUNER

**SPECIFICATIONS**

Track system:

Recommended tape:

Tape speed:

Frequency response:

Graphic equalizer:

Receiving frequency:

Stereophonic

Normal ferric, chrome dioxide,  
and metal alloy: C-30 to C-90

(Recorded tape)

4.8 cm/sec.

Reproduction:

40 Hz to 14 kHz

(normal), 40 Hz to 16 kHz

(METAL/CrO<sub>2</sub>)

100 Hz, 1 kHz, 10 kHz

U.S.A., Canada

FM: 87.5 MHz to 108 MHz

(0.1 MHz steps)

Case ©

530 kHz to 1610 kHz

(10 kHz steps)

Case @

531 kHz to 1602 kHz

(9 kHz steps)

Europe, Australia, others

FM:

87.5 MHz to 108 MHz

(0.05 MHz steps)

AM:

Specifications are subject to change without notice.

Intermediate

frequency:

Antenna:

Output terminal:

Maximum output

power:

Power supply:

Dimensions:

Weight:

PRINTED IN JAPAN

22905819

June, 1988 ©

# TOSHIBA

## STEREO RADIO CASSETTE PLAYER

# KT-4568



**SPECIFICATIONS**

<b>Track system:</b>	Stereophonic
<b>Recommended tape:</b>	Normal ferric, chrome dioxide, and metal alloy: C-30 to C-90 (Recorded tape)
<b>Tape speed:</b>	4.8 cm/sec.
<b>Frequency response:</b>	Reproduction: 40 Hz to 14 kHz (normal), 40 Hz to 16 kHz (METAL/CrO <sub>2</sub> )
<b>Graphic equalizer:</b>	100 Hz, 1 kHz, 10 kHz
<b>Receiving frequency:</b>	U.S.A., Canada FM: 87.5 MHz to 108 MHz

<b>Intermediate frequency:</b>	AM: Cas 531 (9 k Cas 530 (10
<b>Antenna:</b>	FM: 10.7 AM: 450 FM: Hea AM: For

AM: Case ©  
531 kHz to 1602 kHz  
(9 kHz steps)

Case ®  
530 kHz to 1610 kHz  
(10 kHz steps)

FM:  
10.7 MHz

AM:  
450 kHz

FM:  
Headphones cord

AM:  
Ferrite-core antenna  
3.5 mm dia. stereo headphones  
jack x 1

Integration 60 mW  
(30 mW + 30 mW)

3V DC (IEC R6 "AA" cell x 2)

External power source supplied  
to the [DC IN 3V] jack (3.4 mm  
dia. center connect negative).

83.5(W) x 120(H) x 32.8 (D) mm

245g (without batteries)

K-TA, TC, TE, AY, VF

SEE  
FILE

# TOSHIBA

## STEREO RADIO CASSETTE PLAYER

# KT-4568

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Toshiba KT-4568

### [Cassette Player Toshiba KT-S1 Service Data](#)

Stereo cassette player (16 pages)

### [Cassette Player Toshiba KT-S1 Owner's Manual](#)

Stereo cassette player (9 pages)

### [Cassette Player Toshiba KT-R2 Instruction Manual](#)

Stereo cassette recorder (15 pages)

### [Cassette Player Toshiba KT-AS1 Owner's Manual](#)

Stereo cassette player (20 pages)

### [Cassette Player Toshiba KT-1950 Service Data](#)

(14 pages)

### [Cassette Player Toshiba KT-4087 Service Data](#)

Stereo radio cassette recorder (16 pages)

### [Cassette Player Toshiba KT-RS1 Service Data](#)

Stereo cassette player (16 pages)

### [Cassette Player Toshiba KT-V890 Manual](#)

Stereo radio cassette recorder (16 pages)

### [Cassette Player Toshiba PC-E70 Manual](#)

Stereo cassette deck (19 pages)

### [Cassette Player Toshiba RT-S933 Instruction Manual](#)

Stereo radio cassette recorder (23 pages)

### [Cassette Player Toshiba PC-X88AD Service Data](#)

Stereo (36 pages)

### [Cassette Player Toshiba SD-22VB Service Manual](#)

Dvd video player & video cassette recorder (111 pages)

### [Cassette Player Toshiba RT-7057 Service Data](#)

Stereo radio cassette recorder (16 pages)

### [Cassette Player Toshiba RT-200S Service Data](#)

Stereo radio cassette recorder (11 pages)

### [Cassette Player Toshiba PC-G33 Service Data](#)

Stereo cassette deck (17 pages)

### [Cassette Player Toshiba SD-V280 Service Manual](#)

Dvd video player & video cassette recorder (143 pages)

## Related Products for Toshiba KT-4568

[Toshiba KT-4087](#)

[Toshiba KT-S1](#)

[Toshiba KT-R2](#)

[Toshiba KT-AS1](#)

[Toshiba KT-1950](#)

[Toshiba KT-V780](#)

[Toshiba KT-RS1](#)

[Toshiba KT-V890](#)

[Toshiba KT-15DRRS](#)

[Toshiba KT-17SHNH](#)

[Toshiba KT-15DRRH](#)

[Toshiba KT-17DRNH](#)

[Toshiba KT-17DRRS](#)

[Toshiba KT-15DRTHK](#)

[Toshiba KT-15DRTHKH](#)

[Toshiba KIRAbok Pro](#)