



Sanyo MS30F Service Manual

1
2
3
4
5
6
7
8
9
10
11
12

--

-

Bookmarks

[Download this manual](#)

Quick Links



SERVICE MANUAL
CASSETTE RECORDER

RADIO **SERVICE MANUAL**

> z
<
=
ra ul
o)
=
my Ww
>
ink)

**RADIO
CASSETTE RECORDER**

142 431 79 (Yellow)



600mW (Max)
 HP 7,
 3
 (UM
 Output Power


SERVICE MANUAL



RADIO CASSETTE RECORDER

ion (at Vol. min.) less than -65dBs
 Crosstalk
 distort
 ic D
 Harmonic
 120mA
 Record mode
 120mA
 Playback mode
 Track
 to Track more than 60dB
 Terminal impedance
 Rewind mode
 160mA
 Fast Forward mode
 160mA
 Recording System
 DC Bias
 Earphone
 a
 a
 Se et cles
 no
 Tape Speed

 cece ee eseeeee ceeseee
 1°7/8ipS. 3%
 Fast
 Erasing System
 Magnet Erasing
 Frequency Range
 %
 Slow
 Fast Forward Time
 120 sec. (with C-60)



SPECIFICATIONS

Power Source	DC	3V	Torque	
	(UM-3, HP 7, AA Cell, Mignonzellen, R6 x 2)		Playback
Output Power		600mW (Max.)	Fast Forward/Rewind	...
Current Consumption (at Vol. min.)			Erase Ratio (Overall)
Record mode		120mA	Signal to Noise Ratio
			Harmonic Distortion (K3)

120 Sec. (with C-60)

Wow & Flutter

0.22. cece eee eee

0.4%/WRMS

179(W) x 88(H) x 44(D)mm

Weight (without batteries) 480g

IM@NSIONS 20cececececees
D

Frequency Response (Overall) 250 ~ 6,300Hz

—Specifications subject to change without notice.—

REFERENCE No. WM-19994

SERVICE MANUAL



1
2
3
4
5

Related Manuals for Sanyo MS30F

[Cassette Player Sanyo M-1060C Instruction Manual](#)

Compact cassette recorder (10 pages)

[Cassette Player Sanyo MCD-Z260F Service Manual](#)

(27 pages)

[Cassette Player Sanyo MCD-ZX570M Instruction Manual](#)

Cd portable radio cassette recorder (12 pages)

[Cassette Player Sanyo M9998K Service Manual](#)

(28 pages)

[Cassette Player Sanyo MCD-S670F Service Manual](#)

(21 pages)

[Cassette Player Sanyo MCD-S860F Service Manual](#)

(22 pages)

[Cassette Player Sanyo MCD-Z12F Service Manual Supplement](#)

Cd portable stereo radio cassette recorder (12 pages)

[Cassette Player Sanyo MCD-Z12F Instruction Manual](#)

Cd portable stereo radio cassette recorder (17 pages)

[Cassette Player Sanyo MCD-s900F Service Manual](#)

(20 pages)

[Cassette Player Sanyo MCD-S660F Instruction Manual](#)

Cd portable fm stereo/am cassette recorder (21 pages)

[Cassette Player Sanyo MCD-Z7F Instruction Manual](#)

Cd portable fm stereo/am radio cassette recorder (12 pages)

[Cassette Player Sanyo MCH-S970F Instruction Manual](#)

Cd portable stereo radio cassette recorder (21 pages)

[Cassette Player Sanyo M-W2K Service Manual](#)

Stereo radio double cassette recorder (10 pages)

[Cassette Player Sanyo M7770K Service Manual](#)

Mini stereo radio cassette recorder (27 pages)

[Cassette Player Sanyo M9994K Service Manual](#)

(22 pages)

[Cassette Player Sanyo M2511E Service Manual](#)

Portable cassette recorder (11 pages)

Related Products for Sanyo MS30F

[Sanyo M-1110C](#)

[Sanyo MCD-S870F](#)

[Sanyo MCD-Z3F](#)

[Sanyo MCD-Z8F \(AU\)](#)

[Sanyo MCD-Z165F](#)

[Sanyo MCD-Z160F](#)

[Sanyo MCD-Z250F](#)

[Sanyo M7900K](#)

[Sanyo MCD-S920F](#)

[Sanyo MCD-S660F](#)

[Sanyo MCD-ZX201F](#)

[Sanyo MCD-Z130 series](#)

[Sanyo MCH-S970F](#)

[Sanyo MCD-Z95F](#)

[Sanyo M2541](#)

[Sanyo MGP17](#)

This manual is also suitable for:

[1424317614243177142431781424317914243180](#)