





## Sanyo VPC-HD1 Service Manual

Digital movie camera



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40

---

- 

## Bookmarks

[Download this manual](#)

## Quick Links



FILE NO.

# SERVICE MANUAL

\

(Product Code : 168 027 01)

(U.S.A.)

(Canada)

(Korea)

(Taiwan)

## SERVICE MANUAL

# VPC-HD1EX

(Product Code : 168 027 02)

(Europe)

(South America)

(China)

(Australia)

**Digital Movie Camera**

FILE



V



(Hong Kong)

Contents

(Russia)

1. OUTLINE OF CIRCUIT DESCRIPTION .....secceee 3

(Middle East)

2. DISASSEMBLY .....ccccsssecssscsesetteseneereseeeseneesenees 12

(Africa)

4. USB STORAGE INFORMATION

TROUBLESHOOTING GUIDE

B4

# VPC-HD1E

5

6. PARTS LIST cccssssscssssssscsevsssisessssssseessssssseesssn 26

PACKING MATERIALS cccscscscssssssssssssssssssssssssssssseee 26

OK) Code : 168 027 03)

ACCESSORIES esssesssssssssseessssssseessssseenssasesssecvee 26

CABINET & CHASSIS PARTS 1 ccssssssscssssssssseeceee 23

CABINET & CHASSIS PARTS 2 cccssssscssssssssseeceee 30

ELECTRICAL PARTS sssssssssssscscscsssssssssecsssssssees 32

CIRCUIT DIAGRAMS &

PRINTED WIRING BOARDS ..scssssssssscscscscscssssssnes C1

WARNING

This product has been manufactured using lead-free solder. Be sure to follow the warning given on page 2 when carrying out repair work.

## PRODUCT SAFETY NOTICE

The components designated by the symbol (A) in this schematic diagram designates components whose value are of special significance to product safety. If any component designated by a symbol need to be replaced, use only the part designated in the Parts List. Do not deviate from the resistance, wattage, and voltage ratings shown.

CAUTION : Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

Discard used batteries according to the manufacturer's instructions.

NOTE : 1. Parts of this product are made of plastic, and description.

2. Substitute parts are not supplied as the service parts..... 12

3. N. S. P.: Not available in some areas..... 17


4. USB STORAGE INFORMATION..... 23

5. TROUBLESHOOTING GUIDE..... 24

Design and specifications are subject to change without notice.

SX812/U, EX, E REGISTRATION ..... 23

REFERENCE No. SVEB10652



# SERVICE MANUAL

## Digital Movie Camera

### Contents

1. OUTLINE OF CIRCUIT DESCRIPTION	3
2. DISASSEMBLY	12
3. ELECTRICAL ADJUSTMENT	17
4. USB STORAGE INFORMATION	23
5. TROUBLESHOOTING GUIDE	24

FILE

S

V

(Pro  
(U.S  
(Ca  
(Ko  
(Tai

V

(Pro  
(Eu  
(So  
(Ch  
(Au  
(Ho  
(Ru  
(Mic  
(Afr  
(Ge

V

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Sanyo VPC-HD1

[Camcorder Sanyo Xacti VPC-HD1 Instruction Manual](#)

Digital movie camera (202 pages)

[Camcorder Sanyo VPC-HD1 Service Manual](#)

Digital movie camera (38 pages)

[Digital Camera Sanyo VPC HD1 - Xacti Camcorder - 720p Safety Manual](#)

Instruction manual, vpc-hd1a safety (4 pages)

[Digital Camera Sanyo Xacti VPC-HD700 Instruction Manual](#)

Digital movie camera (241 pages)

[Digital Camera Sanyo VPC-HD700 Service Manual](#)

Digital movie camera (60 pages)

[Digital Camera Sanyo VPC HD700 - Xacti Camcorder - 720p Safety Manual](#)

Instruction manual, vpc-hd700ex safety (4 pages)

[Digital Camera Sanyo VPC E1 - Xacti Camcorder - 6.0 MP Safety Manual](#)

Instruction manual, vpc-e10ex safety (4 pages)

[Digital Camera Sanyo VPC-HD1AEX Instruction Manual](#)

Digital movie camera (247 pages)

[Digital Camera Sanyo VPC-TH1R Safety Manual](#)

Sanyo digital camera safety manual (4 pages)

[Digital Camera Sanyo VPC-S60 Service Manual](#)

(52 pages)

[Digital Camera Sanyo Xacti VPC-C5 Instruction Manual](#)

Digital movie camera (194 pages)

[Digital Camera Sanyo VPC-E2100 Instruction Manual](#)

14 mega pixels (79 pages)

[Digital Camera Sanyo Xacti VPC-S4 Instruction Manual](#)

(139 pages)

[Digital Camera SANYO VPC-S1285 Instruction Manual](#)

(45 pages)

[Digital Camera Sanyo VPC-E7 Service Manual](#)

(65 pages)

[Digital Camera Sanyo VPC-S500EX Instruction Manual](#)

(67 pages)

## Related Products for Sanyo VPC-HD1

[Sanyo VPC-HD100 - High-Definition Camcorder](#)

[Sanyo VPC HD1 - Xacti Camcorder - 720p](#)

[Sanyo VPC-HD1010 - Xacti Camcorder - 1080i](#)

[Sanyo VPC-HD1010BK](#)

[Sanyo VPC-HD1000BK](#)

[Sanyo VPC-HD1000EX](#)

[Sanyo VPC-HD1000GX](#)

[Sanyo Xacti VPC-HD1010GX](#)

[Sanyo Xacti VPC-HD1010EX](#)

[Sanyo VPC-HD1A](#)

[Sanyo Xacti VPC-HD1000 Series](#)

[Sanyo VPC HD1000 - Xacti Camcorder - 1080i](#)

[Sanyo VPC-HD1000EXBK](#)

[Sanyo VPC-HD1000GXBK](#)

[Sanyo VPC-HD1010EXBK](#)

[Sanyo VPC-HD1010GXBK](#)

This manual is also suitable for:

[Vpc-hd1exVpc-hd1e168 027 01168 027 02168 027 03](#)