



Sanyo A33 Service Manual

Stereo integrated amplifier

1
2
3
4
5
6
7
8

--

•

Bookmarks

[Download this manual](#)

Quick Links



SERVICE MANUAL

STEREO

INTEGRATED **SERVICE MANUAL**

AMPLIFIER

A33 STEREO INTEGRATED
AMPLIFIER

(EUROPE)
SPECIFICATIONS
NOTE:



The below mentioned specifications are mainly based on the IHF measurements standard.

They can

therefore not directly be compared with specifications based on the DIN standard or other standards.

Continuous output power

Total harmonic distortion

Input sensitivity and impedance

MIC

PHONO

TUNER/(TV/AUX)/TAPE

PLAY

Phono overload level

Output level

TAPE REC

Frequency

response

Tone control

response

BASS

TREBLE

Subsonic filter response

Loudness control response

100 Hz/10 kHz

Signal to noise ratio

PHONO

TUNER/(TV/AUX)/TAPE PLAY

Power requirements

Power consumption

Dimensions (Approx.)

SERVICE MANUAL

STEREO INTEGRATED AMPLIFIER



Weight (Approx.)

25 W x 2 (at 8 ohms, 0.09% distortion)

0.03% (10 W output, 38 ohms)

2 mV/10 kohms

2.5 mV/47 kohms

150 mV/47 kohms

70 mV RMS (at 1 kHz)

150 mV

+ 1.0 dB (20 Hz — 20 kHz) (TV/AUX)

+5 dB (at 100 Hz)

+8 dB (at 10 kHz)

30 Hz (—6 dB/oct.)

+8 dB/+4 dB

73 dB

90 dB

AC: 110/220V, 50 Hz

150 W

335 (W) x 260 (D) x 62 (H) mm

{13-1/4" x 10-1/4" x 2-1/2"}

4 kg (9 lbs.)

Specifications subject to change without notice.

WM-8506

SPECIFICATIONS

NOTE:

The below mentioned specifications are mainly based on the IHF measurements therefore not directly be compared with specifications based on the DIN standard.

Continuous output power	25 W x 2 (at 8 ohms, 0.09% di
Total harmonic distortion	0.03% (10 W output, 8 ohms)
Input sensitivity and impedance	
MIC	2 mV/10 kohms
PHONO	2.5 mV/47 kohms
TUNER/(TV/AUX)/TAPE PLAY	150 mV/47 kohms
Phono overload level	70 mV RMS (at 1 kHz)
Output level	
TAPE REC	150 mV
Frequency response	± 1.0 dB (20 Hz — 20 kHz) (T
Tone control response	
BASS	± 8 dB (at 100 Hz)

[Next Page](#)

1
2
3
4
5

Related Manuals for Sanyo A33

[Amplifier Sanyo JA 20 Service Manual](#)

(8 pages)

[Amplifier Sanyo JA 224 Service Manual](#)

(7 pages)

[Amplifier Sanyo JA 5503 Service Manual](#)

(10 pages)

[Amplifier Sanyo JA20 Service Manual](#)

(8 pages)

[Amplifier Sanyo SUPER BL P5 Manual](#)

(354 pages)

[Amplifier Sanyo JA 226 Service Manual](#)

(10 pages)

[Amplifier Sanyo DCA 401 Owner's Manual](#)

(11 pages)

[Amplifier Sanyo DCA M15 Service Manual](#)

Integrated stereo amplifier (27 pages)

[Amplifier Sanyo JA 250 Service Manual](#)

(9 pages)

[Amplifier Sanyo PLUS P20 Service Manual](#)

Stereo power amplifier (8 pages)

[Amplifier Sanyo JA 300 Service Manual](#)

(8 pages)

[Amplifier Sanyo DCA 205 Service Manual](#)

(13 pages)

[Amplifier Sanyo JA 566 BLACK Service Manual](#)

(8 pages)

[Amplifier Sanyo JA 477 Service Manual](#)

(8 pages)

[Amplifier Sanyo DCA 200UM Service Manual](#)

(10 pages)