



Whirlpool 8300770 Installation Instructions

30" drop-in ceramic electric range

1
2
3
4
5

--

•

[Table of Contents](#)

•

Bookmarks

[Download this manual](#)

Quick Links



Installation Instructions

Electric Range

IMPORTANT:

Read and save these instructions.

Part No. 8300770

Quick Reference

Table of Contents:

Pages

- 1
- Product dimensions
- 1
- Cabinet opening dimensions
- 1
- Before you start
- 2
- Electrical requirements
- 2
- 3
- Installation steps

If you need assistance:

Check your Use and Care Guide for a toll-free number to call or call the dealer from whom you purchased this appliance. The dealer is listed in the Yellow Pages of your phone directory under "Appliances — Household — Major — Service and Repair."

Call when you:


- Have questions about range installation or operation.
- Need to obtain the name and number of an authorized service company.

When you call, you will need:

The range model number:

The range serial number:

Both numbers are listed on the model/serial rating plate, located on



ManualsLib.com

IMPORTANT:

- Installer: Leave Installation Instructions with the homeowner.
- Homeowner: Keep Installation Instructions for future reference.
- Save Installation Instructions for local electrical inspector's use.

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool 8300770

[Ranges WHIRLPOOL 8300649-D-WH Dimensional Information](#)

30" drop-in electric range (1 page)

[Ranges WHIRLPOOL 8300649 Installation Instructions](#)

30" drop-in electric range (5 pages)

[Ranges WHIRLPOOL 8300770-D-WH Dimensional Information](#)

30" drop-in ceramic electric range (1 page)

[Ranges Whirlpool 8053373A Use And Care Manual](#)

Standard-cleaning gas range super capacity 465 with accubake system 4.65 cubic foot oven (30 pages)

[Ranges Whirlpool 8113P749-60 Use And Care Manual](#)

Self-cleaning electric ranges (16 pages)

[Ranges Whirlpool 8522407 Use And Care Manual](#)

Self-cleaning gas range (16 pages)

[Ranges Whirlpool 8522769 Use And Care Manual](#)

Standard cleaning electric range (19 pages)

[Ranges Whirlpool 8522773A Use And Care Manual](#)

Whirlpool electric range use & care guide (24 pages)

[Ranges Whirlpool 8SF302PSY Use And Care Manual](#)

Standard cleaning gas range (28 pages)

[Ranges Whirlpool 8113P667-60 Use & Care Manual](#)

Self cleaning electric ranges (16 pages)

[Ranges Whirlpool 8273166 Installation Instructions Manual](#)

30" freestanding sealed burner gas range with standard clean oven (10 pages)

[Ranges Whirlpool 8177893 Manual](#)

Direct spark ignition system (29 pages)

[Ranges Whirlpool 8273167 Installation Instructions Manual](#)

30" freestanding sealed burner gas range (10 pages)

[Ranges Whirlpool 8113P023-60 Use And Care Manual](#)

(15 pages)

[Ranges Whirlpool SMP 658C/BT/IXL Manual](#)

(28 pages)

[Ranges Whirlpool SF340BEH Use And Care Manual](#)

Self-cleaning gas range (16 pages)

Summary of Contents for Whirlpool 8300770

[Page 1](#) Electric Range IMPORTANT: IMPORTANT: Installer: Leave Installation Instructions with the homeowner. Read and save these instructions. Homeowner: Keep Installation Instructions for future reference. Save Installation Instructions for local electrical inspector's use. Part No. 8300770...

[Page 2: Product Dimensions](#)

Product dimensions Before you start... Your safety and the safety of others are very important. 29-7/32" 24-13/32" cooktop We have provided many important safety messages in this to back recessed width manual and on your appliance. Always read and obey all safety of oven

messages.

[Page 3: Electrical Requirements](#)

Electrical requirements A time-delay fuse or circuit breaker is If the house has aluminum wiring, follow the If codes permit and a separate ground wire is used, recommended. procedure below. it is recommended that a qualified electrician determine that the ground path and wire gauge are a.) Connect the aluminum wiring to the copper wire Connect directly to the fused disconnect (or in accordance with local codes.

[Page 4: Electrical Connection](#)

Electrical connection cable from cable from power supply junction junction power supply If your house has aluminum wiring, see white black “Electrical requirements” , Page 2. wires wires wires wires WARNING white wire white and bare black wires bare ground ground range wires cable wires —...

[Page 5: If Range Does Not Operate](#)

Both numbers are listed on the model/serial rating directory under “Appliances — Household — plate, located on the oven door or on the oven Major — Service and Repair. ” frame. Part No. 8300770 Printed in U.S.A. © 2001 Whirlpool Corporation...

This manual is also suitable for:

8300770-d-wh