

Upgrading System Memory; Installing Additional Memory - Toshiba Satellite P20-8PW User Manual


Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
Table Of Contents
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142



•

[Table of Contents](#)

•

Bookmarks



Upgrading System Memory

You can upgrade the system memory in your computer. The computer has two sockets for DDR SODIMM memory modules. They are located in the memory compartment on the underside of the computer. Generally, at least one socket has a module installed when you get the computer and the other socket is empty to allow for upgrades, but depending on your configuration you may actually have both sockets occupied with memory modules.

The computer can have a maximum of 2 GB installed. This means it can take two 1 GB memory modules.

If you want to upgrade the system memory, you should use only certified modules. Ask your vendor or check the TOSHIBA web site for a list of approved memory products. The basic specifications of the memory used are:



DDR 266/333 specification compliant



128MB, 256MB, 512MB or 1GB capacity

Installing additional memory

Unless you are familiar with computer upgrades and comfortable doing so, we suggest that you have any memory upgrades installed at the nearest TOSHIBA Service Centre.

If you want to install a memory upgrade yourself, do as follows:

1. Make sure the computer is turned off, with AC adapter disconnected and battery removed.

Never add or remove memory modules with the computer on or in Standby or Hibernation. Ensure the system is turned off, the AC adapter is not connected and the battery has been removed.

Expanding & Upgrading



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

105

106

107

108

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite l500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[NB500 Memory \(Main System\)](#)

Toshiba NB500

[Satellite L500 Memory \(Main System\)](#)

Toshiba Satellite L500

[Qosmio F60 Series System Board \(Flesy* Cn1400 Memory A](#)

[Connector\(200-Pin](#)

Toshiba Qosmio F60 Series

[X200 Series Memory \(Main System\)](#)

Toshiba X200 Series

[Satellite A300 Memory \(Main System\)](#)

Toshiba Satellite A300

[TECRA S5 Memory \(Main System\)*3](#)

Toshiba TECRA S5

[TECRA A10 Satellite Pro S300 Series Memory \(Main System\)*3](#)

Toshiba TECRA A10 Satellite Pro S300 Series

[Satellite A200 series Memory \(Main System\)](#)

Toshiba Satellite A200 series

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)