

System Status Indicators - Toshiba Satellite P20-8PW User Manual


Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
Table Of Contents
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142




•

[Table of Contents](#)

•

Bookmarks



Full instructions on playing CDs, DVDs and digital music files with your computer on or off are given in chapter 5. The Eject button works in system off mode.



System status indicators

The DC-IN LED indicates the computer is connected to the AC adapter and it is plugged into an AC power source.

The Power LED flashes amber while the system is in Standby mode. The LED turns off when the computer is turned off or in hibernation mode.

The Battery LED indicates the battery's current charge/ discharge status. It lights green when the battery is fully charged. It lights amber while the

battery is being charged from the AC adapter. It flashes amber when the battery capacity is low.

POWER
DC-IN
BATTERY



Finding Your Way Around

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
30
31
32
33
34
35
36
37

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite I500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[L555-S7002 System Indicators](#)

Toshiba L555-S7002

[Satellite L635 Series System Indicators](#)

Toshiba Satellite L635 Series

[Satellite Pro L450 Series System Indicators](#)

Toshiba Satellite Pro L450 Series

[Satellite Pro A300D Series System Indicators](#)

Toshiba Satellite Pro A300D Series

[AC100 System Indicators](#)

Toshiba AC100

[TECRA A6 Device Status Indicators / Power Status](#)

Toshiba TECRA A6

[Satellite A500 series System Indicators](#)

Toshiba Satellite A500 series

[Satellite L630 Series System Indicators](#)

Toshiba Satellite L630 Series

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)