

Left Side - Toshiba Satellite P20-8PW User Manual


Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
Table Of Contents
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142



•

[Table of Contents](#)

•

Bookmarks



Left Side

COMMUNICATION


SECURITY LOCK SLOT

The Volume Control adjusts the audio volume level.

The Microphone Jack let you connect a 3.5mm three conductor mini jack microphone or other audio input device.

The Headphone Jack lets you connect stereo headphones or other audio-output devices such as external speakers. Connecting headphones or other devices to this jack automatically disables the internal speakers.

The Line-In Jack is a standard 3.5 mm mini line-in jack that enables connection of a stereo device for audio input.




Not all models come fitted with a wireless communication or Bluetooth device

The Wireless Communication Switch (for Wireless LAN or Bluetooth) turns on the wireless networking transceiver. An indicator LED on the left of the keyboard lights to indicate that wireless networking is turned on.

Not all models will come with wireless LAN device or Bluetooth.

The Security Lock Slot allows you to secure your computer with a cable lock to a desk or some other object to prevent theft.

- WIRELESS SWITCH
- LINE-IN JACK
- MICROPHONE JACK
- Finding Your Way Around
- HEADPHONE JACK
- VOLUME CONTROL



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
32
33
34
35
36
37
38
39

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite l500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[Satellite Pro R50-C Series Left Side](#)

Toshiba Satellite Pro R50-C Series

[Satellite L40-C Series Left Side](#)

Toshiba Satellite L40-C Series

[Satellite U930 Series Left Side](#)

Toshiba Satellite U930 Series

[Tecra A40 C Series Left Side](#)

Toshiba Tecra A40 C Series

[Satellite Radius 15 P50W-C Left Side](#)

Toshiba Satellite Radius 15 P50W-C

[C70-A Series Left Side](#)

Toshiba C70-A Series

[PT930 Left Side](#)

Toshiba PT930

[Satellite Pro R50-D Series Left Side](#)

Toshiba Satellite Pro R50-D Series

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)