

Using The Keyboard; Character Keys; Ctrl, Fn, And Alt Keys; Function Keys - Toshiba Satellite P20-8PW User Manual

Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19

20

21

22

23

Table Of Contents

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64


65

66

67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142



•

[Table of Contents](#)

•

Bookmarks



Using The Keyboard

Character keys

Typing with the character keys is very much like typing on a typewriter, except that:



The space bar creates a space character instead of just passing over an area of the page.



The lowercase letter l and the number 1 are not interchangeable.

The uppercase letter O and the number 0 are not interchangeable. The Caps Lock key shifts the letter keys to upper case - the number and symbol keys are not affected. The Caps Lock LED on the keyboard illuminates when you press Caps Lock.

Ctrl, Fn, and Alt keys

The Ctrl, Fn, and Alt keys do different things depending on the program you are using. For more information, see your program documentation.

Function keys

The function keys (not to be confused with the Fn key) are the 12 keys at the top of the keyboard.

F1 through F12 are called function keys because they perform programmed functions when pressed. Used in combination with the Fn key, function keys marked with icons execute specific functions, such as dimming the computer display and enabling the numeric keypad. See appendix A for more details of these 'hot key' functions.

Learning The Basics



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
56
57
58
59
60
61
62
63

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite l500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[Satellite Pro R50-C Series The Keyboard](#)

Toshiba Satellite Pro R50-C Series

[Satellite L40-C Series Keyboard Shortcuts](#)

Toshiba Satellite L40-C Series

[PORTEGE R35-C The Keyboard](#)

Toshiba PORTEGE R35-C

[Satellite U930 Series The Keyboard](#)

Toshiba Satellite U930 Series

[Tecra A40 C Series Keyboard Shortcuts](#)

Toshiba Tecra A40 C Series

[Satellite Radius 15 P50W-C The Keyboard](#)

Toshiba Satellite Radius 15 P50W-C

[PT930 Keyboard Indicators](#)

Toshiba PT930

[Satellite Pro R50-D Series The Keyboard](#)

Toshiba Satellite Pro R50-D Series

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)