

Using Sd Cards - Toshiba Satellite P20-8PW User Manual


Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
Table Of Contents
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142



•

[Table of Contents](#)

•

Bookmarks



Using SD Cards

SD Cards are small media cards capable of dynamically storing data, similar to a floppy disk. Your computer can read from and write upon SD Cards, which are often used in devices such as digital cameras, digital video recorders, MP3 players, and others. Your computer can support the following size of SD Cards: 8/16/32/64/128/256/512MB.

Do not attach stickers or labels to the card or you may cause a malfunction when it is being read or ejected.

Inserting SD Cards

Hold the SD Card with the gold contact area facing down and the

notched corner on the right side. Gently slide it into the SD Card slot until it clicks into place.

If the system can not recognize SD cards correctly, please format SD cards with TOSHIBA SD Memory Card Format utility.

If SD card is formatted, all of data will be erased.

Learning The Basics

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
67
68
69
70
71
72
73
74

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite I500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[Satellite L630 Series Memory Cards:secure Digital \(Sd\), Secure Digital High Capacity \(Sdhc\), Secure Digital Extended Capacity \(Sdxc\), Memory Stick \(Ms\), Memory Stick Pro \(Ms Pro\) And Multimediacard \(Mmc\)](#)

Toshiba Satellite L630 Series

[Satellite P500 Sd/Sdhc/Mmc/Memory Stick / Memory Stick Pro/Xd Memory Cards](#)

Toshiba Satellite P500

[X200 Series Sd/Sdhc/Mmc/Ms/Ms Pro/Xd Memory Cards](#)

Toshiba X200 Series

[Satellite A200 series Sd/Sdhc/Mmc/Ms/Ms Pro/Xd Memory Cards](#)

Toshiba Satellite A200 series

[A200 Series Sd/Sdhc/Mmc/Ms/Ms Pro/Xd Memory Cards](#)

Toshiba A200 Series

[Satellite X200 Sd/Sdhc/Mmc/Ms/Ms Pro/Xd Memory Cards](#)

TOSHIBA Satellite X200

[Satellite L630 Series Memory Cards:secure Digital \(Sd\), Secure Digital High Capacity \(Sdhc\), Secure Digital Extended Capacity \(Sdxc\),](#)

[Memory Stick \(Ms\), Memory Stick Pro \(Ms Pro\) And Multimediacard \(Mmc\)](#)

[Toshiba Satellite L630 Series](#)

[2010 Sd Cards](#)

[Toshiba 2010](#)

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)