

Turning Off The Computer; Caring For Your Computer; Cleaning The Computer; Moving The Computer - Toshiba Satellite P20-8PW User Manual


Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
Table Of Contents
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142



•

[Table of Contents](#)

•

Bookmarks



Turning Off The Computer

It is a good idea to turn off your computer when you are not using it for a while. Click on Start, then click Turn Off Computer. You will be given the options to Standby, Turn Off or Restart.



If you have work in progress and expect to resume shortly, use your Microsoft your system settings so that, when you turn on the computer again, you automatically return to where you left off.

To leave the computer turned off for a longer period, use your

Never turn off the power if the hard disk drive light is on. It may damage your hard disk drive.

Closing the lid of your computer can be set to put your computer into Standby. Click on Start, Control Panel, then Power Options and select Advanced to choose your preferred setting.

Caring For Your Computer

This section gives tips on cleaning and moving your computer. For information about taking care of your computer's battery, see "Running the computer on battery power" in chapter 4.

Cleaning the computer

To keep your computer clean, gently wipe the display panel and exterior case with a lightly dampened cloth. Ask your TOSHIBA dealer for suggestions for appropriate cleaning products.

Keep liquid, including cleaning fluid, out of the computer's keyboard, speaker grille, and other openings. Never spray cleaner directly onto the computer. Never use harsh or caustic chemical products to clean the computer.

Moving the computer

ManualsLib.com

Before moving your computer, even across the room, make sure that all disk activity has ended (check the system status indicator LEDs) and that all external peripheral cables are disconnected.

Don't pick up the computer by its display/panel or by the back (where the ports are located).

®



Windows

operating system Standby command to save

®

Windows

operating system Turn Off command instead.

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
73
74
75
76
77
78
79
80

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite I500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[Qosmio X300 Series Turning Off The Computer](#)

Toshiba Qosmio X300 Series

[Tecra A9 Series Turning Off The Computer](#)

Toshiba Tecra A9 Series

[Satellite 200 Series Lesson 13: Turning Your Computer Off](#)

Toshiba Satellite 200 Series

[Portégé R830 Series Turning Off The Computer](#)

Toshiba Portégé R830 Series

[SatellitePro L700 Series Turning Off The Computer](#)

Toshiba SatellitePro L700 Series

[Satellite Pro 4600 Series Turning Off The Computer](#)

Toshiba Satellite Pro 4600 Series

[Satellite 110 Series Lesson 13: Turning Your Computer Off](#)

Toshiba Satellite 110 Series

[Satellite R10 Turning Off The Computer](#)

Toshiba Satellite R10

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)