

Using The Toshiba Power Management Utility - Toshiba Satellite P20-8PW User Manual


Toshiba satellite p20-8pw: user guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
Table Of Contents
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142



•

[Table of Contents](#)

•

Bookmarks



Using The TOSHIBA Power Management Utility

The TOSHIBA Power Management Utility is pre-installed in your computer. This software allows you to select the power scheme with the most appropriate settings for this computer.

You can double click the TOSHIBA Power Management Utility icon on the system taskbar to execute the program. Following the on-screen display step by step panels, you will find following settings.

1. Battery Mode: Lets you select either Long Life, Normal, High Power or DVD Playback power schemes. For each individual setting, you can adjust Monitor Brightness, Turn Off Monitor, Turn Off Hard Disks,

System Stand By, and System Hibernate at different battery power capacity.

2. AC Mode: There is one Power Scheme, which is Full Power. As with the various battery modes, you can adjust the specifics for Full Power management.

3. Alarm: You can adjust the Low Battery Alarm and Critical Battery Alarm when the Battery Power reaches a certain level. The Alarm Action be either sound Alarm or Display message or both.

4. Advanced: Lets you can select the power saving settings you want to use. You can select the power button and lid switch function here. You can also select the cooling method you want to use.

5. Battery Power Meter: Displays the current the power source and Battery Power capacity. You can see the current battery capacity on the edge of right side of the on-screen display. After finishing your settings, you should click OK to confirm or cancel to ignore the new settings.

Using Advanced Features

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
94
95
96
97
98
99
100
101

Quick Links:

[Appendix B Features and Specifications](#)

Related Manuals for Toshiba Satellite P20-8PW

[Laptop Toshiba PSM30C-0QQ31 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba Satellite P205D Maintenance Manual](#)

(249 pages)

[Laptop Toshiba Satellite P20-25 Series Maintenance Manual](#)

(250 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite l500 series reference guide (56 pages)

[Laptop Toshiba Satellite A305-S6825 Resource Manual](#)

Toshiba satellite a305-s6825: reference guide (52 pages)

[Laptop Toshiba Satellite U500-ST5305 Resource Manual](#)

Toshiba satellite u500-st5305: reference guide (64 pages)

[Laptop Toshiba Satellite A70 Resource Manual](#)

Toshiba satellite a70: user guide (68 pages)

Related Content for Toshiba Satellite P20-8PW

[M20-S258 Toshiba Power Saver Utility](#)

Toshiba M20-S258

[F25Series Toshiba Power Management](#)

Toshiba F25Series

[Satellite Pro 6000 Series Toshiba Power Saver Utility](#)

Toshiba Satellite Pro 6000 Series

[Satellite Pro 4600 Series Toshiba Power Saver Utility](#)

Toshiba Satellite Pro 4600 Series

[Satellite L40-A Series Toshiba Password Utility](#)

Toshiba Satellite L40-A Series

[PORTEGE R30t-D Series Toshiba Password Utility](#)

Toshiba PORTEGE R30t-D Series

[Satellite W30t-A Series Toshiba Password Utility](#)

Toshiba Satellite W30t-A Series

[Satellite Pro R50-C Series Toshiba Password Utility](#)

Toshiba Satellite Pro R50-C Series

This manual is also suitable for:

[Satellite p20-s103](#)[Satellite p20-s203f](#)[Satellite p25-sp507](#)[Satellite p25-sp526](#)[Satellite p25-sp509](#)[Psp20c-1u8pw](#) ... [Show all](#)