



Asus AIGURUSV1 - Eee Videophone AiGuru SV1 Wireless IP Video Phone User Manual

Internet video phone

1	
2	
Table Of Contents	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

--

•

[Table of Contents](#)

•

Bookmarks

--

[Download this manual](#)

Quick Links



AiGuru SV1



Internet Video Phone

User Manual



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus AIGURUSV1 - Eee Videophone AiGuru SV1 Wireless IP Video Phone

[IP Phone Asus AiGuru S1 User Manual](#)

Wireless music phone (92 pages)

Summary of Contents for Asus AIGURUSV1 - Eee Videophone AiGuru SV1 Wireless IP Video Phone

[Page 1](#) AiGuru SV1 Internet Video Phone User Manual...

[Page 2](#) ASUSTeK COMPUTER, INC. ("ASUS"). Products and corporate names mentioned in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used for identification purposes only.

[Page 3: Table Of Contents](#)

Notes for this manual6 Safety information7 Welcome9 What is Skype?9 Enjoy ASUS AiGuru SV1 Internet Video Phone! 9 Package contents10 AiGuru SV1 product specifications11 Getting to know your SV112 Front view12...

[Page 4](#) Contents Status29 See myself29 Account29 Settings.....30 Network settings30 Advanced settings32 ASUS AiGuru SV1...

[Page 5: Notices](#)

The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. ASUS AiGuru SV1...

[Page 6: Safety Precautions](#)

WARNING: Vital information that you MUST follow to prevent injury to yourself. IMPORTANT: Instructions that you MUST follow to complete a task. TIP: Tips and useful information that help you complete a task. NOTE: Additional information for special situations. ASUS AiGuru SV1...

[Page 7: Safety Information](#)

- The supplied battery model is ASUS, AL21-SV1. Risk of explosion Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the manufacturer's instructions.

[Page 8](#) The device performance changes. This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products. ASUS AiGuru SV1...

[Page 9: Welcome](#)

Get started by creating your own unique Skype Name and then signing in—done directly on ASUS AiGuru SV1. You will soon be enjoying free Skype-to-Skype calls to friends and family. And best of all, you will hear them with excellent sound quality and see them in perfect vision.

[Page 10: Package Contents](#)

Package contents Congratulations on your purchase of ASUS AiGuru SV1. The following illustration displays the package contents of your new videophone. If any of the below items is damaged or missing, contact your retailer. AiGuru SV1 AC adapter Power cord...

[Page 11: Aiguru Sv1 Product Specifications](#)

5-way Navigation keys (Up, Down, Left, Right, and Select) Keys Menu key Back key Call key End key 3.5 mm Headphone jack and Microphone jack RJ-45 connector I/O connectors USB type A connector DC Jack Battery connector ASUS AiGuru SV1...

[Page 12: Getting To Know Your Sv1](#)

This built-in webcam allows you to make video calls and can also take a snapshot of yourself. Webcam LED This LED lights up green to indicate that the webcam is activated. Microphone This is a built-in microphone. ASUS AiGuru SV1...

[Page 13](#) Press to go directly to the idle screen. Volume keys Press to increase/decrease the volume. Call key Press to dial or answer calls. From the idle screen, press to show the Contact list. Menu key Press to go directly to the main menu. ASUS AiGuru SV1...

[Page 14: Rear View](#)

Headphone jack This jack allows you to connect amplified speakers or headphones. Using this jack automatically disables the built-in speakers. LAN port The RJ-45 LAN port supports a standard Ethernet cable for connection to a local network. ASUS AiGuru SV1...

[Page 15: Installing The Battery](#)

Installing the battery Lay the device on its back with the screen facing up. Use your thumbs to release the battery compartment cover tabs to open the cover. Insert the battery into the battery compartment noting the correct orientation. ASUS AiGuru SV1...

[Page 16: Turning On The Videophone](#)

Turning on the videophone Connect the supplied AC adapter to the DC IN jack on the rear panel, and then press the power button to turn on the device. The device screen lights up to show the Skype welcome message. ASUS AiGuru SV1...

[Page 17: Setting Up Your Sv1](#)

Wireless connection (not plugging in the Ethernet cable) A list of wireless networks displays. Highlight one you have access to and then press the Select key to start connecting. If the network is secured, enter the password using the onscreen keyboard. ASUS AiGuru SV1...

[Page 18](#) OK. To set day, month, and year, follow the instructions as above. When done, select To time zone, press the Up/Down key to highlight your time zone and press the Select key to confirm. ASUS AiGuru SV1...

[Page 19](#) 10. Highlight a letter/number and press the Select key to enter. When done, highlight the onscreen Enter key and then press the Select key to confirm. Select the Delete key to delete text. Select ABC display more text options. ASUS AiGuru SV1...

[Page 20](#) You will be asked if you would like to take a video snapshot of yourself to use in your profile. Select Yes and the device webcam will be activated. Select Snapshot and your photo will be taken. ASUS AiGuru SV1...

[Page 21: Using Your Sv1](#)

(from left to right): Settings, Search, Add Contact, Call phones, Contacts, History, Status, See myself, and Account. Press the Left and Right keys to display more menu options. When an option is focused, its icon is enlarged. ASUS AiGuru SV1...

[Page 22: Calls](#)

Left/Right to scroll through tabs. When a tab is in focus, press the Select key to jump letter by letter. To call landlines or mobile phones, you will need to buy Skype Credit or a Skype

subscription. Visit www.skype.com for more information. ASUS AiGuru SV1...

Page 23 Change view: select to hide/show the picture-in-picture • view. • Mute: select to mute/unmute. • Hold call: select to hold call/resume call. View profile: select to view Contact profile. • To terminate a call, press the End key ASUS AiGuru SV1...

Page 24: Calling A Mobile Or Telephone Number

To terminate a call, press the End key To call landlines or mobile phones, you will need to buy Skype Credit or a Skype subscription. Visit www.skype.com for more information. ASUS AiGuru SV1...

Page 25: Answering Calls

When you have an Incoming call, a full screen dialog appears with information on the incoming caller. Select Accept or press the Call key to answer the call. To have calls accepted automatically, go to Settings > Calls > Auto-answer incoming calls. ASUS AiGuru SV1...

Page 26: Contacts

The Action list displays options that may vary with Contacts. You can make a Video call, a Voice call, or Send voicemail to the Contact. You can also View profile, Rename, Remove, or Block the Contact, and send Request details. ASUS AiGuru SV1...

Page 27: Adding A Contact

Enter a Skype Name or telephone number using the onscreen keyboard or dialpad. When done, select the onscreen Enter key. Searching a Contact From the main menu, select Enter a Skype Name, user Search. name, or e-mail address to find a Skype Contact. ASUS AiGuru SV1...

Page 28: History

The number opposite to an event indicates how many events require action. For example, the screen on the right shows there are three Voicemails that have not been listened. Select Voicemails and then select each voicemail to perform further action. ASUS AiGuru SV1...

Page 29: Status

Account Select Account from the main menu to view your account details. You will be able to check your Skype Credit balance and check your subscriptions (for example, voicemail or online numbers). Visit www.skype.com for more information. ASUS AiGuru SV1...

Page 30: Settings

Go to Settings > Network. To change connection from Wired to Wireless, select Change connection and follow the instructions in step 3A on page 17. To modify your wired connection type, select Current connection > Modify connection. ASUS AiGuru SV1...

Page 31 If you use a router, select IP Select Configure addresses. automatically (the other options become unavailable). Static IP connection Enter IP address, Subnet If you have a static IP, select IP addresses. mask and other information using the onscreen dialpad. ASUS AiGuru SV1...

Page 32: Advanced Settings

Internet. Device reset: restoring the device to its factory settings Select Device reset. Choose to Reset everything or Reset all except network. The "Reset device?" dialog appears. Select Yes to confirm the action. ASUS AiGuru SV1...

This manual is also suitable for:

[Aiguru sv1](#)