



# Turning On/Off Mw Led On Another Extension; Microphone - Toshiba DKT3010-SD - Digital Phone User Manual

Strata ctx digital business telephone systems dkt/ipt telephone



1

2

3

4

Table Of Contents

5

6

7

8

9

10

11

12

13

14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114



- 

[Table of Contents](#)

•

## Bookmarks







## The Basics

Microphone

## Turning On/Off MW LED on Another Extension

If you call an extension and it's busy or there is no answer, you may be able to light that extension's Message Waiting LED and enable that extension to call you back. The ability to perform this feature is set in system programming.

1. Dial an internal extension. You hear busy tone or there's no answer.
2. Press **Msg or 7**. The Msg LED flashes red on the called telephone, the Msg LED lights steady red and the LCD shows the station number where you set a Message Waiting light. Example: "MW SET TO 3200"

## The Basics

### Microphone

If you decide to cancel the Message Waiting light at this point, press again, while ring-over tone is playing and the light will be cancelled.

3. Press

flashes until the called party presses the flashing

4. To turn Off a Message LED that you have set on another extension, press

the extension number that has the message light set. Then press

release your telephone. Your LCD shows the extension and "MW CANCEL."

...or dial the extension that you set the Message LED on, then press

## Turning On/Off MW LED on Another Extension

If you call an extension and it's busy or there is no answer, you can turn the Message Waiting LED on or off for that extension's Message Waiting LED and enable that extension's Message Waiting LED.

The ability to perform this feature is set in system programming.

## Microphone

internal extension. You hear busy tone or there's no



2. Press **Msg** or **7**. The Msg LED flashes red on the called telephone, the Msg LED lights steady red and the LCD shows

To turn the Microphone On/Off when the speakerphone is active (Spkr LED is On), press

If you decide to cancel the Message Waiting light at this point, press again while ring-over tone is playing and the light will be cancelled.

When the Microphone is On, the Mic LED is On, steady red. When Mic is Off, the LED is Off and you cannot be heard through the microphone.

The microphone and its LED are always On when you receive a Ring-first call and Off when you receive a Ring-catch call.

3. Press **Spkr**. Your Msg LED turns Off. The Msg LED on the called telephone flashes red until the called party presses the flashing **Msg** button.

Each station's microphone can be set in system programming to:

4. To turn Off a Message LED that you have set on another extension, press the extension number that has the message light set. Then press

- switch On/Off with one touch.
- switch Off only while pressed and held.
- either On/Off at the start of handsfree dialing.

...or dial the extension that you set the Message LED on, then



**Spkr** or hang up to release your telephone.

To talk back to a Handset Off-hook Call Announce call, press and hold

talk over your telephone handset/headset. The LED and microphone remain Off.

## Microphone

### 12

To turn the Microphone On/Off when the speakerphone is On, press **Mic**

. Your Msg LED turns Off. The Msg LED on the called telephone

or hang up to release your telephone. When the Microphone is On, the Mic LED is On, steady red. When the Microphone is Off, the Mic LED is Off and you cannot be heard through the microphone.

button which calls you back.

**Strata CTX DKT/IPT Telephone**

The microphone and its LED are always On when you receive a Ring-first call and Off when you receive a Ring-catch call.

or

Each station's microphone can be set in system programming

plus

- switch On/Off with one touch
- switch Off only while pressed and held
- either On/Off at the start of handsfree dialing.

or hang up to

. Then press

and

## Table of Contents

[Previous Page](#)  
[Next Page](#)

1  
...  
23  
24  
25  
26  
27  
28  
29  
30

Quick Links:

[Call History](#)

## Related Manuals for Toshiba DKT3010-SD - Digital Phone

[Telephone Toshiba STRATA CIX DKT User Manual](#)

Strata cix and ctx ipt/dkt telephone (151 pages)

[Telephone Toshiba DKT User Manual](#)

Strata ctx dkt/ipt telephone (116 pages)

[Telephone Toshiba DKT3000 Series User Manual](#)

Strata ctx digital business telephone systems (106 pages)

[IP Phone Toshiba STRATA CTX DKT3000 User Manual](#)

Dkt3000/2000-series digital business telephone systems (104 pages)

[IP Phone Toshiba DKT3000/2000 User Manual](#)

Dkt3000/2000-series digital business telephone systems (104 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[Telephone Toshiba CIX User Manual](#)

Strata cix and ctx ipt/dkt telephone (141 pages)

[IP Phone Toshiba 2000 series User Manual](#)

2000-series digital telephones for strata dk systems (134 pages)

[Telephone Toshiba Strata IPT User Manual](#)

Lcd featurephones (124 pages)

[IP Phone Toshiba Strata DKT3010F-S User Manual](#)

(115 pages)

[Telephone Toshiba DKT3001/2001 User Manual](#)

Strata ctx digital single line telephone (67 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone Toshiba STRATA CIX-CTX-QRG-VB VERSION B1 Quick Reference Manual](#)

Dkt / ipt telephone (13 pages)

[Telephone Toshiba DKT2001 Technical Bulletin](#)

(6 pages)

[Telephone Accessories Toshiba DKT3014-SDL Quick Reference Manual](#)

Dkt / ipt telephone (2 pages)

[Toshiba 3000 Series, 2000 Series - DKT / IPT Business Telephone Quick Reference Guide with Button Codes](#)

(article)

## Related Content for Toshiba DKT3010-SD - Digital Phone

[DP5000-Series Turning On/Off Mw Led On Another Extension](#)

Toshiba DP5000-Series

[DKT3220-SD - Digital Phone - Charcoal Turning On/Off Mw Led On Another Extension](#)

Toshiba DKT3220-SD - Digital Phone - Charcoal

[Strata DP5000-UG-VC Turning On/Off Mw Led On Another Extension](#)

Toshiba Strata DP5000-UG-VC

[Strata DKT Turning On/Off Mw Led On Another Extension](#)

Toshiba Strata DKT

[Strata CIX IP5000-UG-VC Turning On/Off Mw Led On Another Extension](#)

Toshiba Strata CIX IP5000-UG-VC

[STRATA CIX DKT Turning On/Off Mw Led On Another Extension](#)

Toshiba STRATA CIX DKT

[IP5000 Turning On/Off Mw Led On Another Extension](#)

Toshiba IP5000

[DKT Turning On/Off Mw Led On Another Extension](#)



This manual is also suitable for:

[Dkt3010-sDkt3020-sDkt3020-sdDkt3014-sdllpt1020-sdDkt2010-s ...](#) [Show all](#)

[Save PDF](#)