



# Handle Cf Card And Adapter - Sanyo POAMD07MCI - Digital AV Player Install And Operation Instructions

Media card imager kit



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68

69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108

•

[Table of Contents](#)

•

## Bookmarks



Available languages

- EN
- FR
- DE
- ES
- IT
- JP

More



# Handle CF Card and Adapter

CF Cards / Adapters are high-precision electronic devices. Do not bend, drop, apply strong forces or shock or place it where a strong static electrical charge may be generated.

Do not touch the surface of the contact area with your fingers or allow it to be stained with foreign materials.

G Do not attempt to disassemble or alter CF Cards.

G Moving CF Card rapidly between hot and cold temperatures may cause conden-

sation (water droplets) to form on it, leading to malfunctions. Avoid this problem

by placing the CF Card in a plastic bag and letting it slowly adjust to temperature

changes before removing it from the bag. If condensation should occur, maintain

the CF Card at a constant temperature and let the moisture evaporate naturally.

G Store CF Cards / Adapters in the protective case.

G Do not use or store CF Cards / Adapters in places subject to the following condi-

tions:

- strong magnetic fields
- abundant dirt or dust
- high temperatures, high humidity

ENVIRONMENT of CF Card operation

Operating Temperature : 41 °F ~ 95 °F (5 °C ~ 35 °C)

Storage Temperature

**8**

: 14 °F ~ 140 °F (-10 °C ~ 60 °C)

ManualsLib.com

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
5  
6  
7  
8  
9  
10  
11  
12

# Chapters

[Français 21](#)

[Español 39](#)

[Deutsch 57](#)

[Italiano 75](#)

## Related Manuals for Sanyo POAMD07MCI - Digital AV Player

[Digital Photo Frame Sanyo LVF-PF72S User Manual](#)

Sanyo digital photo frame user guide (1 page)

## Related Products for Sanyo POAMD07MCI - Digital AV Player

[Sanyo POA-MD13NET2](#)

[Sanyo POA-MD13NET](#)

[Sanyo POA-PN03C](#)

[Sanyo POA-SR-140](#)

[Sanyo POA-HDTM01](#)

[Sanyo POA-PN01A](#)

[Sanyo PJ MASTER POA-PJNM01](#)

[Sanyo POA-PN02C](#)

[Sanyo POA-PN02](#)

[Sanyo POA-SP-SU31](#)

[Sanyo POA-WL12](#)

[Sanyo POA-WL11](#)

[Sanyo POA-SP-SU30](#)

[Sanyo POA-LN02](#)

[Sanyo POA-PN40](#)

[Sanyo POA-PN03C XT35 Series](#)