



# Whirlpool XHPC155YC Installation Instructions Manual

15.5" laundry pedestal with chrome handle and storage drawer



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16

• PAGE

1


•

[Table of Contents](#)

•

## Bookmarks

Available languages



## Quick Links


[1 Installation Requirements](#)

[2 Tools and Parts](#)

[3 Installing the Pedestal](#)

## 4 Complete the Installation

[Download this manual](#)





# 15.5" PEDESTAL INSTALLATION INSTRUCTIONS

## INSTRUCTIONS D'INSTALLATION DU PIÉDESTAL DE 15,5"

Para una versión de estas instrucciones en español, visite [www.whirlpool.com](http://www.whirlpool.com)

### Table of Contents

<a href="#">PedeStal Safety</a> .....	1
<a href="#">InStallatIon RequiRementS</a> .....	2
<a href="#">locatIon RequiRementS</a> .....	2
<a href="#">toolS and PartS</a> .....	2
<a href="#">unPaCKInG tHe PedeStal</a> .....	3
<a href="#">BefoRe InStallInG tHe PedeStal</a> .....	3

[InStallInG tHe Pedestal](#) .....4  
[ComPlete tHe InStallaton](#) .....7

InStallaton noteS

date of purchase:

date of installation:

Installer:

model number:

Serial number:  
W10347252B  
W10348602B - SP

For use only with front load washers and dryers  
Pour utilisation avec les produits suivants seulement  
laveuses et sécheuses à chargement par l'avant

PEDESTAL SAFETY


Table des matières

[SéCuRIté du PlédeStal](#) .....9  
[eXIGenCeS d'InStallaton](#) .....9  
[Exigences d'emplacement](#) .....9  
[outillage et pièces](#) .....9  
[InStRuCtIonS d'InStallaton](#) .....10  
[avant l'InStallaton du PlédeStal](#) .....11  
[InStallaton du PlédeStal](#) .....12  
[aCheveR l'InStallaton](#) .....15

noteS ConCeRnant l'InStallaton

date d'achat : **Your safety and the safety of others are very im**  
**We have provided many important safety messages in this manual and on your appliance. Alw**

date d'Installation :

Insta :  This is the safety alert symbol.  
This symbol alerts you to potential hazards that can kill or hurt you and others  
numéro de modèle : All safety messages will follow the safety alert symbol and either the word "DA  
These words mean:

num **▲ DANGER** You can be killed or serious

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool XHPC155YC

[Laundry Accessories Whirlpool WFP2715HW0 Installation Instructions Manual](#)

15.5" pedestal (18 pages)

[Laundry Accessories Whirlpool For use only with front load washer and dryers Installation Instructions Manual](#)

Stack kit for use only with front load washer and dryers (16 pages)

[Laundry Accessories Whirlpool LRF4001RY Quick Start Manual](#)

New fabric freshener (2 pages)

[Laundry Accessories Whirlpool LRF4001RY Use And Care Manual](#)

Fabric freshener (40 pages)

[Laundry Accessories Whirlpool 279787 Installation And Wiring Instructions](#)

Dryer motor kit (4 pages)

[Laundry Accessories Whirlpool 279827 Installation And Wiring Instructions](#)

Dryer motor kit (4 pages)

[Laundry Accessories Whirlpool W10198562A Installation Instructions Manual](#)

15.5" (39.4 cm) washer/dryer pedestal (12 pages)

[Laundry Accessories Whirlpool PEDESTAL Installation Instructions Manual](#)

(16 pages)

[Laundry Accessories Whirlpool W10323246 Installation Instructions Manual](#)

4-way vent kit front load dryer match with full front panel - side and bottom exhaust venting (18 pages)

[Laundry Accessories Whirlpool W10110902 Use And Care Manual](#)

Laundry worksurface (12 pages)

[Laundry Accessories Whirlpool WHP1500SCB Installation Instructions Manual](#)

15.5" (39.4 cm) washer/dryer pedestal (24 pages)

[Laundry Accessories Whirlpool WVP5000SQ Use And Care Manual](#)

Symphony series laundry tower (12 pages)

## Related Products for Whirlpool XHPC155YC

[Whirlpool XHPC155XW](#)

[Whirlpool XHPW155DW0](#)

[Whirlpool XHP1550WR](#)

[Whirlpool XHP1550WL](#)

[Whirlpool XHP1000XW0](#)

[Whirlpool X05002X0](#)

[Whirlpool XW29000V](#)

[Whirlpool XW29000TB0](#)

[Whirlpool XW29000TW0](#)

[Whirlpool XW29000TC0](#)

[Whirlpool XW29000TU0](#)

[Whirlpool XW29000TA0](#)

[WHIRLPOOL XVP8600TW0](#)

[WHIRLPOOL XVP9000TB0](#)

[WHIRLPOOL XVP9000TA0](#)

[Whirlpool X2-30ES](#)

This manual is also suitable for:

[Xhpc155yuMvwc700vj](#)