



Whirlpool ART 471/A+/7 Instructions For Use Manual

Built-in 70:30 fridge freezer with fast freeze, art 471/a+/7

1
2
3
4
5
6

--

-

[Table of Contents](#)

•

Bookmarks

--

Table of Contents

1 First Use

2 When the Appliance Is Not in Use

3 Refrigerator Compartment


4 Defrosting the Freezer Compartment

5 Temperature Adjustment

6 After Sales Service

7 Electrical Connection for Great Britain and Ireland Only

[Download this manual](#)



FIRST USE

Connect the appliance to the mains power supply.

A beep may be emitted by some models, to indicate that the temperature alarm has intervened: press and

hold the button to switch off acoustic alarms. As applicable, insert the anti-bacterial/anti-odour filter into

the fan as indicated on the filter package.

Note: after switching on, the refrigerator needs approximately 4/5 hours to reach the correct temperature for storing a normal fridge load of food.

APPLIANCE MAINTENANCE

AND CLEANING

Clean the appliance regularly using a cloth and a solution of lukewarm water and neutral detergent specifically formulated for refrigerator interiors. Never use abrasive detergents. Clean inside the defrost water drain outlet on the rear wall of the refrigerator (near the fruit and vegetable crisper drawer) regularly, using the tool supplied with the appliance so as to ensure defrost water is removed correctly (see figure). Before all cleaning or maintenance procedures, unplug the appliance from the mains or disconnect the electricity supply.

CHANGING THE BULB OR LED

Always unplug the refrigerator before replacing any light bulbs, then follow the relevant instructions in accordance with the type of lighting fitted in your appliance. Only use bulbs of the same type, which can be requested from the After-Sales Service and authorised dealers.

Lighting type 1)

1. Loosen the screws and take off the lamp cover.
2. The lamp has a bayonet bulb and needs to be pulled out, not unscrewed, following the directions of the arrows as indicated.
3. After the new bulb has been inserted, replace the lamp cover and wait five minutes before plugging the appliance back in.

Lighting type 2)

To remove the light bulb, turn anticlockwise as shown in the figure. Wait for 5 minutes before reconnecting the appliance.

Lighting type 3)

If the product has LED lighting which is in need of replacing, contact the After-Sales Service for assistance. LED lights last longer than normal bulbs, they illuminate better and are more environmentally friendly

10

(depending on the model)

2
1

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool ART 471/A+/7

[Freezer Whirlpool WSF5552 A+NX Declaration Of Conformity](#)

Total no frost side-by-side fridge freezer wsf5552 a+nx (2 pages)

[Freezer WHIRLPOOL ART 864 Installation Instructions Manual](#)

Installation instructions and doors reversibility (16 pages)

[Freezer Whirlpool AFG 7080/IX Service Manual](#)

Super (5 pages)

[Freezer Whirlpool AFG 6512 Operating Instructions Manual](#)

(11 pages)

[Freezer Whirlpool ACO450 Instructions For Use Manual](#)

(11 pages)

[Freezer Whirlpool AFG 074/G Service Manual](#)

Horizontal freezer (5 pages)

[Freezer Whirlpool ART 471/A Instructions For Use Manual](#)

70/30 built-in combi fridge-freezer, art 471/a+ (6 pages)

[Freezer Whirlpool EH050FXVN00 Manual](#)

(32 pages)

[Freezer Whirlpool WZF79R20DW User Manual](#)

(28 pages)

[Freezer Whirlpool W7 931A OX User Manual](#)

(13 pages)

[Freezer Whirlpool WSF5574 A+N Installation Instructions Manual](#)

Black no frost side-by-side fridge-freezer with 6th sense wsf5574 a+n (32 pages)

[Freezer Whirlpool WZF34X20DW User Manual](#)

Upright freezer (44 pages)

[Freezer Whirlpool EH060FXK Use And Care Manual](#)

Whirlpool chest freezer models eh060fxk, eh090fxk use and care guide (8 pages)

[Freezer Whirlpool EV20VS Use And Care Manual](#)

Whirlpool upright freezer use and care guide ev20vs (12 pages)

[Freezer Whirlpool WB 400 FF Me Aa Service Manual](#)

Bttm freezer (7 pages)

[Freezer Whirlpool WSZ57L18DMSS User Manual](#)

(44 pages)

This manual is also suitable for:

Art 262/aArt 479/aArt 869/a+/nf471/a+/7