



# Hardware And System Checklist; System Start-Up - Toshiba PSPA3C- SD402E User Manual

User manual




|                   |
|-------------------|
| 1                 |
| 2                 |
| 3                 |
| 4                 |
| 5                 |
| 6                 |
| 7                 |
| 8                 |
| 9                 |
| 10                |
| 11                |
| 12                |
| 13                |
| 14                |
| Table Of Contents |
| 15                |
| 16                |
| 17                |

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172



•

[Table of Contents](#)



- 

Troubleshooting

•

## Bookmarks





Record your observations so you can describe them to your dealer.

Software

Hardware

---

## Hardware and system checklist

This section discusses problems caused by your computer's hardware or attached peripherals. Basic problems may occur in the following areas:



## System start-up

---



Self test



Power



Overheating power down



AC Power



Battery



Password



Keyboard



LCD panel



Hard disk drive



Memory cards



Wireless LAN



DVD-ROM and CD-R/RW drive

## System start-up

When the computer does not start properly, check the following items:



Self Test



---

## Power Sources



---

## Power-on Password

### User's Manual

The problems may be caused by your software. If you cannot load a software package, the media may be damaged or the program might be corrupted. Try loading another copy of the software.

If an error message appears while you are using a software package, check the software documentation.

These documents usually include a problem solving section or a summary of error messages.

Next, check any error messages in the operating system documentation.

If you cannot find a software problem, check your hardware. First run through the items in the preliminary checklist above. If you still cannot correct the problem, try to identify the source. The next section provides checklists for individual components and peripherals.



## PC Card




## Diskette drive



## Monitor



## Sound system



## Pointing device



## USB



LAN



Standby/Hibernation



Memory expansion



Modem



i.LINK (IEEE1394)



DVD Super Multi drive



Real Time Clock



Bluetooth

Troubleshooting

9-3

[Table of Contents](#)



[Previous Page](#)  
[Next Page](#)

1  
...  
128  
129  
130  
131

## Related Manuals for Toshiba PSPA3C-SD402E

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz User Manual](#)

Toshiba online users guide for satellite p105 (280 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba P100-ST7211 User Manual](#)

P100-st7211 user's guide (275 pages)

[Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

## Related Content for Toshiba PSPA3C-SD402E

[Satellite U930 Series Hardware And System Checklist](#)

Toshiba Satellite U930 Series

[Satellite Radius 15 P50W-C Hardware And System Checklist](#)

Toshiba Satellite Radius 15 P50W-C

[PT930 Hardware And System Checklist](#)

Toshiba PT930

[Satellite Pro R50-D Series Hardware And System Checklist](#)

Toshiba Satellite Pro R50-D Series

[Satellite Radius 12 P20W-C Hardware And System Checklist](#)

Toshiba Satellite Radius 12 P20W-C

[PORTEGE Z30-E Hardware And System Checklist](#)

Toshiba PORTEGE Z30-E

[L70-B Hardware And System Checklist](#)

Toshiba L70-B

[PORTEGE R30-A Series Hardware And System Checklist](#)

Toshiba PORTEGE R30-A Series

This manual is also suitable for:

[PspaaU-01200sPspadc-ma605cPspagu-00j00xP100](#)