



# Starting Up For The First Time; Turning Off The Power; Hibernation Mode - Toshiba PSPA3C-SD402E User Manual

User manual




1
2
3
4
5
6
7
8
9
10
11
12
13
14
Table Of Contents
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172



•

Table of Contents



- 

Troubleshooting

•

## Bookmarks





---

## Starting up for the first time

When you first turn on the power, the computer's initial screen is the Windows

each screen. During setup, you can click the Back button to return to the previous screen.

Be sure to read the Windows Agreement carefully.

# Turning off the power

The power can be turned off in one of the following modes: Shut down (Boot), Hibernation or Standby mode.

## Shut Down mode (Boot mode)

When you turn off the power in Shut Down mode, no data is saved and the computer will boot to the operating system's main screen.

1. If you have entered data, save it to the hard disk or to a diskette.
2. Make sure all disk activity has stopped, then remove the optical disc drive or floppy drive diskette.

*Make sure the Built-in Hard Disk Drive and optical disc drive are off. If you turn off the power while a disk is being accessed, you can lose data or damage the disk.*

3. Click Start and click Turn off Computer. From the Turn off Computer dialogue box, choose Turn Off.
4. Turn off the power to any peripheral devices.

*Do not turn the computer or devices back on immediately. Wait a moment to let all capacitors fully discharge.*

## Hibernation mode

The hibernation feature saves the contents of memory to the hard disk when the computer is turned off. The next time the computer is turned on, the previous state is restored. The hibernation feature does not save the status of peripheral devices.

1. *While entering hibernation mode, the computer saves the contents of memory to the Hard Disk Drive. Data will be lost if you remove the battery or disconnect the AC adapter before the save is completed.*

*Wait for the Built-in Hard Disk Drive indicator to go out.*

2. *Do not install or remove a memory module while the computer is in hibernation mode. Data will be lost.*

User's Manual

®

XP Startup Screen Logo. Follow the on-screen directions for

®

Operating System End User License

Getting Started

---

Table of Contents

[Previous Page](#)  
[Next Page](#)

1  
...  
54  
55  
56  
57  
58  
59  
60  
61



## Related Manuals for Toshiba PSPA3C-SD402E

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz User Manual](#)

Toshiba online users guide for satellite p105 (280 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba P100-ST7211 User Manual](#)

P100-st7211 user's guide (275 pages)

[Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

## Related Content for Toshiba PSPA3C-SD402E

[Satellite A500 series Starting Up For The First Time](#)

Toshiba Satellite A500 series

[SATELLITE R850 Starting Up For The First Time](#)

Toshiba SATELLITE R850

[NB500 Starting Up For The First Time](#)

Toshiba NB500

[Satellite L630 Series Starting Up For The First Time](#)

Toshiba Satellite L630 Series

[Satellite L500 Starting Up For The First Time](#)

Toshiba Satellite L500

[X200 Series Starting Up For The First Time](#)

Toshiba X200 Series

[Portege M930 Series Starting Up For The First Time](#)

Toshiba Portege M930 Series

[L550 Starting Up For The First Time](#)

Toshiba L550

This manual is also suitable for:

[PspaaU-01200sPspadc-ma605cPspagu-00j00xP100](#)