

Standby Mode - Toshiba PSPA3C-SD402E User Manual

User manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
Table Of Contents
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172



•

Table of Contents

-

Troubleshooting

•

Bookmarks



Data save in hibernation mode

When you turn off the power in hibernation mode, the computer takes a moment to save current memory data to the hard disk. During this time, the Built-in Hard Disk Drive indicator will light.

After you turn off the computer and memory is saved to the hard disk, turn off the power to any peripheral devices.

Do not turn the computer or devices back on immediately. Wait a moment to let all capacitors fully discharge.



Standby mode

In standby mode the power remains on, but the CPU and all other devices are in sleep mode.



If the computer is not used or accessed in any way, including receipt of e-mail, for approximately 15 or 30 minutes when the AC adapter is connected, the computer will automatically enter Standby mode (Power Options default).



To restore operation, press the power button.



If the computer automatically enters Standby mode while a network application is active, the application might not be restored when the computer wakes up from Standby.



To prevent the computer from automatically entering Standby mode, disable Standby in Power Options. That action, however, will nullify the computer's Energy Star compliance.

Standby precautions



Before entering Standby mode, be sure to save your data.



Do not remove/install memory or remove power components:



In any of the above cases, the standby configuration will not be saved.



If you carry the computer on board an aircraft or into a hospital, be sure to shut down the computer in hibernation mode or in shutdown mode to avoid radio signal interference.

Benefits of standby

The standby feature provides the following benefits:



Restores the previous working environment more rapidly than does hibernation.



Saves power by shutting down the system when the computer receives no input or hardware access for the duration set by the System Standby feature.



You can use the panel power off feature.

[User's Manual](#)

Do not remove/install the memory module. The computer or the module could be damaged.

Do not remove the Battery Pack.

[Getting Started](#)

3-9



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
56
57
58
59
60
61
62
63

Related Manuals for Toshiba PSPA3C-SD402E

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz User Manual](#)

Toshiba online users guide for satellite p105 (280 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba P100-ST7211 User Manual](#)

P100-st7211 user's guide (275 pages)

[Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

Related Content for Toshiba PSPA3C-SD402E

[TECRA M3 Standby Mode](#)

Toshiba TECRA M3

[TECRA A4 Standby Mode](#)

Toshiba TECRA A4

[tegra s3 Standby Mode](#)

Toshiba tegra s3

[Satellite Pro 4600 Series Going Into Standby Mode More Quickly](#)

Toshiba Satellite Pro 4600 Series

[Qosmio G10 Standby Mode](#)

Toshiba Qosmio G10

[TECRA A8 Standby Mode](#)

Toshiba TECRA A8

[Satellite M110 Standby Mode](#)

Toshiba Satellite M110

[Portege M400 Standby Mode](#)

Toshiba Portege M400

This manual is also suitable for:

[PspaaU-01200sPspadc-ma605cPspagu-00j00xP100](#)