



# Writing Cds On A Dvd-Rom And Cd-R/Rw Drive - Toshiba PSPA3C-SD402E User Manual

User manual




1
2
3
4
5
6
7
8
9
10
11
12
13
14
Table Of Contents
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172



•

Table of Contents



- 

Troubleshooting

•

## Bookmarks





## Operating Basics

---

Previous

Arrows Up



Next

Arrows Left



OK



Arrows Right

Play/Pause



Arrows Down



Volume+



Stop

Volume-

## Writing CDs on a DVD-ROM and CD-R/RW drive

You can use the DVD-ROM and CD-R/RW drive to write data to CD-R/RW discs.

### Important message

Before you write or rewrite to CD-R/RW discs, read and follow all setup and operating instructions in this section. If you fail to do so, the DVD-ROM and CD-R/RW drive may not function properly, and you may fail to write or rewrite, lose data or incur other damage.

### Disclaimer

TOSHIBA does not bear responsibility for the following:

Damage to any CD-R/RW disc that may be caused by writing or rewriting with this product.

Any change or loss of the recorded contents of CD-R/RW disc that may be caused by writing or rewriting with this product, or for any business profit loss or business interruption that may be caused by the change or loss of the recorded contents.

Damage that may be caused by using third party equipment or software.

Given the technological limitations of current optical disc writing drives, you may experience unexpected writing or rewriting errors due to disc quality or problems with hardware devices. Also, it is a good idea to make two or more copies of important data, in case of undesired change or loss of the recorded contents.

4-18

Go to the previous chapter

DVD menu - move the cursor up

Go to the next chapter

DVD menu - move the cursor left

---

Select the menu item

DVD menu - move the cursor right

Toggle between play and pause mode

DVD menu - move the cursor down

Volume up

Stop playing

Volume down

User's Manual

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
77  
78  
79  
80  
81  
82  
83  
84



## Related Manuals for Toshiba PSPA3C-SD402E

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz User Manual](#)

Toshiba online users guide for satellite p105 (280 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba P100-ST7211 User Manual](#)

P100-st7211 user's guide (275 pages)

[Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

## Related Content for Toshiba PSPA3C-SD402E

[TECRA A8 Writing Cds On Dvd-Rom&Cd-R/Rw Drive](#)

Toshiba TECRA A8

[Satellite M110 Writing Cds On Cd-Rw/Dvd-Rom Drive](#)

Toshiba Satellite M110

[Portege M400 Writing Cds On Dvd-Rom&Cd-R/Rw Drive](#)

Toshiba Portege M400

[Libretto U100 Writing Cds On Dvd-Rom&Cd-R/Rw Drive](#)

Toshiba Libretto U100

[Satellite L20 Series Writing Cds With On Cd-Rw/Dvd-Rom Drive](#)

Toshiba Satellite L20 Series

[Satellite L350 series Writing Cds On Cd-Rw/Dvd-Rom Drive](#)

Toshiba Satellite L350 series

[TECRA M4 Writing Cds On Dvd-Rom&Cd-R/Rw Drive](#)

Toshiba TECRA M4

[Satellite A80 Series Writing Cds On A Cd-Rw/Dvd-Rom Drive](#)

Toshiba Satellite A80 Series

This manual is also suitable for:

[Pspaau-01200sPspadc-ma605cPspagu-00j00xP100](#)