

Power Indicators - Toshiba PSPA3C-SD402E User Manual

User manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
Table Of Contents
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172



•

Table of Contents

-

Troubleshooting

•

Bookmarks



Power indicators

As shown in the above table, the Battery, DC IN and Power indicators on the system indicator panel alert you to the computer's operating capability and battery charge status.

Battery indicator

Check the Battery indicator to determine the status of the battery pack. The following indicator lights indicate the battery status.

Flashing amber

Amber

blue

No light

DC IN indicator

Check the DC IN indicator to determine the power status with the AC adapter connected:

blue

No light

Power indicator

Check the Power indicator to determine the power status:

blue

Blinking amber

No light

User's Manual

The battery charge is low. The AC adapter must be connected to recharge the battery

Indicates the AC adapter is connected and charging the battery.

Indicates the AC adapter is connected and the battery is fully charged.

Under any other conditions, the indicator does not light.

Indicates the AC adapter is connected and supplying proper power to the computer.

Indicates the AC adapter is not connected.

The power button will be shining blue while power is being supplied to the computer and the computer is turned on. The power indicator in front of computer will be shining blue while system is on.

Indicates power is being supplied to the computer while the computer is in Standby mode.

Under any other conditions, the indicator does

not light.

Power and Power-Up Modes

6-3

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
92
93
94
95
96
97
98
99

Related Manuals for Toshiba PSPA3C-SD402E

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz User Manual](#)

Toshiba online users guide for satellite p105 (280 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba P100-ST7211 User Manual](#)

P100-st7211 user's guide (275 pages)

[Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

Related Content for Toshiba PSPA3C-SD402E

[Satellite Pro L450 Series Power Indicators](#)

Toshiba Satellite Pro L450 Series

[Satellite Pro A300D Series Power Indicators](#)

Toshiba Satellite Pro A300D Series

[Portege 2010 Power Indicators](#)

TOSHIBA Portege 2010

[TECRA A6 Device Status Indicators / Power Status](#)

Toshiba TECRA A6

[Satellite A500 series Power Indicators](#)

Toshiba Satellite A500 series

[Satellite P500 Power Indicators](#)

Toshiba Satellite P500

[Satellite L500 Power Indicators](#)

Toshiba Satellite L500

[X200 Series Power Indicators](#)

Toshiba X200 Series

This manual is also suitable for:

[PspaaU-01200sPspadc-ma605cPspagu-00j00xP100](#)