



# Overheating Power Down; Ac Power - Toshiba PSpCDC-03H00C User Manual

User manual




|                   |
|-------------------|
| 1                 |
| 2                 |
| 3                 |
| 4                 |
| 5                 |
| 6                 |
| 7                 |
| 8                 |
| 9                 |
| 10                |
| 11                |
| 12                |
| 13                |
| 14                |
| 15                |
| Table Of Contents |
| 16                |
| 17                |

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185





•

[Table of Contents](#)

•

Troubleshooting

•

## Bookmarks





## Power

---

When the computer is not plugged into an AC outlet, the battery pack is the primary power source. However, your computer has a number of other power resources, including an intelligent power supply and a Real Time Clock battery. These resources are interrelated and any one could affect apparent power problems. This section provides checklists for AC power and the battery. If you cannot resolve a problem after following them, the cause could lie with another power resource. In such a case, contact your dealer.

## *Overheating power down*

---

If the computer's internal temperature becomes too high, the computer will automatically enter Hibernation Mode or Sleep Mode and shut down. If the computer has reached room temperature and still does not start, or if it starts but shuts down quickly contact your dealer.

## *AC power*

If you have trouble turning on the computer with the AC adaptor connected, check the Battery indicator. Refer to Chapter 6, *Modes for more information.*

### Problem

AC adaptor doesn't power the computer

## *Battery*

If you suspect a problem with the battery, check the Battery indicator. For information on indicator and battery operation refer to Chapter 6, *and Power-Up*

### Problem

Battery doesn't power the computer

### User's Manual

### Procedure

Check the connections. Make sure the cord is firmly connected to the computer and a power outlet.

Check the condition of the cord and terminals. If the cord is frayed or damaged, replace it. If the terminals are soiled, wipe them with cotton or a clean cloth.

If the AC adaptor still does not power the computer, contact your dealer.

### *Modes.*

### Procedure

The battery may be discharged. Connect the AC

adaptor to charge the battery.

---

**Troubleshooting**

*Power and Power-Up*

*Power*

**9-4**

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)



1

...

140

141

142

143

## Related Manuals for Toshiba PSPCDC-03H00C

### [Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

### [Laptop Toshiba P15-S4091 User Manual](#)

P15-s4091 user's guide (240 pages)

### [Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

### [Laptop Toshiba P25-S509 User Manual](#)

P25-s509 user's guide (230 pages)

### [Laptop Toshiba P30-S6362ST User Manual](#)

P30-s6362st user's guide (230 pages)

### [Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

### [Laptop Toshiba P100-ST7211 User Manual](#)

P100-st7211 user's guide (275 pages)

### [Laptop Toshiba PSPB3U-01V00L Brochure](#)

Brochure (2 pages)

### [Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

### [Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

### [Laptop Toshiba P500-ST5801 User Manual](#)

P500-st5801 user's guide (254 pages)

### [Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

### [Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

### [Laptop Toshiba PSPA3C-SD402E User Manual](#)

User manual (172 pages)

### [Laptop Toshiba PSPB0U-00W008 User Manual](#)

User manual (175 pages)

### [Laptop Toshiba Satellite P500-BT2G22 Resource Manual](#)

Toshiba satellite p500-bt2g22: reference guide (60 pages)

## Related Content for Toshiba PSPCDC-03H00C

### [Satellite A500 series Overheating Power Down](#)

Toshiba Satellite A500 series

### [Satellite L500 Overheating Power Down](#)

Toshiba Satellite L500

### [SATELLITE CLICK 10 LX0W-C Overheating Power Down](#)

Toshiba SATELLITE CLICK 10 LX0W-C

### [Z30-B Overheating Power Down](#)

Toshiba Z30-B

### [C70-B Overheating Power Down](#)

Toshiba C70-B

[R30-C Overheating Power Down](#)

Toshiba R30-C

[C70-C Overheating Power Down](#)

Toshiba C70-C

[L9W-B Overheating Power Down](#)

Toshiba L9W-B

This manual is also suitable for:

[Pspccc-06001cP300 seriesP300d series](#)