






## Sanyo WXU30 - PLC - LCD Projector Owner's Manual

Memory viewer function



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
Table Of Contents  
13



•

[Table of Contents](#)

•

## Bookmarks

## Quick Links

[Download this manual](#) See also: [Service Manual](#), [Owner's Manual](#)





# Owner's Manual

## Memory Viewer function

This is the manual for the Memory Viewer function.

Read this manual thoroughly to operate the Memory Viewer function.

First, read the owner's manual of the projector to understand the basic operation of the projector and the safety instructions.

The safety instructions in the owner's manuals should be followed strictly.



## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Sanyo WXU30 - PLC - LCD Projector

[Projector Sanyo PLC-WXU30 Owner's Manual](#)

(270 pages)

[Projector Sanyo WXU30 - PLC - LCD Projector Owner's Manual](#)

Network set-up and operation (144 pages)

[Projector Sanyo PLC-WXU30 Service Manual](#)

Multimedia projector (130 pages)

[Projector Sanyo PLC-WXU30 Owner's Manual](#)

Sanyo multimedia projector owner's manual plc-wxu30 (82 pages)

[Projector Sanyo PjLink PLC-WXU30K Owner's Manual](#)

(82 pages)

[Projector Sanyo WXU30 - PLC - LCD Projector Owner's Manual](#)

Network set-up and operation (58 pages)

[Software Sanyo PLC-XU300 - XGA LCD Projector Owner's Manual](#)

Pj network manager for windows (32 pages)

[Projector Sanyo PLC-XE32 Brochure](#)

Sanyo projectors product brochure (12 pages)

[Projector Sanyo PLC-WXU30 Specifications](#)

(2 pages)

[Projector Sanyo PLC-WXU30 Command List](#)

Ir command list (1 page)

[Projector Sanyo PLC-WXU30A - 3700 Lumens Specification Sheet](#)

3700 ansi lumens, wireless & wired networking projector (1 page)

[Projector Sanyo PLC-WXU30A Service Manual](#)

Sanyo multimedia projector service manual (134 pages)

[Projector Sanyo PLC-WXU300 - 2500 Lumens Brochure](#)

Ultra portable multimedia projector (2 pages)

[Projector Sanyo 3LCD PLC-WXU300 Quick Reference Manual](#)

Sanyo projector user manual (1 page)

[Projector Sanyo PDG-DSU30 - 2500 Specifications](#)

Expand serial command functional specifications (42 pages)

[Projector Sanyo PLC-WXU300 Technical Information](#)

Sanyo lcd projector datasheet (1 page)

## Summary of Contents for Sanyo WXU30 - PLC - LCD Projector

### [Page 1: Memory Viewer Function](#)

Owner's Manual Memory Viewer function This is the manual for the Memory Viewer function. Read this manual thoroughly to operate the Memory Viewer function. First, read the owner's manual of the projector to understand the basic operation of the projector and the safety instructions. The safety instructions in the owner's manuals should be followed strictly.

[Page 2](#) Memory viewer function Memory Viewer function The Memory Viewer function is to make a presentation or project an image without using computers or some other external equipment. You do not have to carry a computer or other equipment to project images.

### [Page 3: Sd Memory Card Slot](#)

Memory card for the Memory Viewer function The memory card is not provided with this projector. The types of memory card which can be used with the Memory Viewer function of this projector is "SD Memory Card". It may not be used with this projector depending on the type of the SD memory card.

### [Page 4: Inserting The Sd Memory Card](#)

Memory viewer function Inserting the SD memory card Insert the SD memory card into the card slot on the back side of the projector as shown in the figure below. Insert a card with cutting side up until it clicks. Removing the SD memory card Push the SD memory card in the arrow direction gently to remove.

### [Page 5: Entering The Memory Viewer Mode](#)

Entering the memory viewer mode 1. Select "Wired" or "Wireless" from the input menu of the projector. The "Please wait..." message will be displayed on the screen. After short time, the network connection standby display screen "Ready for use" will appear. 2.

### [Page 6: Displaying The Memory Viewer Browser Window](#)

Memory viewer function Displaying the memory viewer browser window When you press AUTO SETUP/CANCEL button in the memory viewer mode, following browser window "Thumbnail" or "Filename list" appears on the screen. Thumbnail display Displays current directory path Menu Filename list display Displays current directory path Menu Moves...

### [Page 7: Menu Tree](#)

Menu tree Menu Sub menu Description Menu Manual mode Mode to select a playing file respectively Available file types are JPEG(.jpg), Bitmap(.bmp), Text(.txt). Others are not available. Program mode Mode to select a program file (.dpf ) created by the program editor. Format Formats the SD memory card Display...

### [Page 8: Image Viewer In The Manual Mode](#)

Memory viewer function Image viewer in the manual mode 1. Select "Manual mode" from "Menu" on the browser window of the memory viewer and press SELECT button. 2. Select a file to display with point buttons and press SELECT button. The selected file image is displayed on the screen.

### [Page 9: Termination Of Memory Viewer](#)

Image viewer in the program mode 1. Select "Program" on "Menu" of the browser window of the memory viewer. And press SELECT button. The program files (.dpf ) in the DispParam folder under the top directory are displayed. \* If the DispParam folder is not placed in the top directory, the list of the folder name is displayed. Find the DispParam folder which stores the program file manually to display the contents of the folder.

[Page 10](#) Memory viewer function Duplicating the data into the SD memory card It is described how to duplicate the data converted with the Network Viewer 4 [File Converter 1, File Converter 2] into the SD memory card through the network. 1. Launch the explorer software of the computer and type the IP address of the network board which has the SD memory card onto the address column.

### [Page 11: Formatting The Sd Memory Card](#)

\* The data converted by the Network Viewer 4 [File Converter1] can be stored into the SD memory card mounted on the projector directly. For further information, refer to chapter Network Viewer function, "Setting of output destination and conversion mode" (p.113) described on the separated booklet of Network Owner's manual.

### [Page 12](#) MV-KB3AC SANYO Electric Co., Ltd. MEMORY VIEWER OWNER'S MANUAL...

This manual is also suitable for:

Plc-wxu30a