

## Asus Eee Pad Transformer Prime TF201 User Manual

Eee pad transformer prime tf201 english user manual

```
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

```
68

69

70

71

72

73

74

75

76

77

78

79

80
```



### Quick Links

- 1 Charging Your Batteries
- 2 Charging the Transformer
- 3 Unlocking Your Transformer
- 4 Power Management

Download this manual

See also: Installation Manual , Using Manual



# Transformer User Manual

TF201

## **Charging Your Batteries**

If you intend to use battery power, be sure to fully charge your battery pack

before going on long trips. Remember that the power adapter charges the

battery pack as long as it is plugged into the computer and an AC power

source. Be aware that it takes much longer to charge the battery pack when the

Transformer is in use.

Remember to fully charge the battery (8 hours or more) before first use and

whenever it is depleted to prolong battery life. The battery reaches its maximum

capacity after a few full charging and discharging cycles.

## Airplane Precautions

Ask an airline personnel if you want to use your Transformer onboard an aircraft.

Most airlines have restrictions for using electronic devices. Most airlines allow

electronic use only between and not during takeoffs and landings.

There are three main types of airport security devices: X-ray machines (used

on items placed on conveyor belts), magnetic detectors (used on people

walking through security checks), and magnetic wands (hand-held devices used on people or individual items). You can send your Transformer through airport X-ray machines. But do not send your

Transformer through airport magnetic detectors or expose it to magnetic

wands. E7135
Table of Contents
Next Page



#### Related Manuals for Asus Eee Pad Transformer Prime TF201

Laptop Asus Eee Pad Transformer Prime TF201 Manual

(70 pages)

Laptop Accessories Asus Eee Pad Transformer Prime TF201 Installation

Manual

Gps extension kit (8 pages)

Laptop Asus Eee Pad Transformer Prime TF201 Using Manual

(6 pages)

Laptop Asus Eee Pad Transformer TF101G Manual

(8 pages)

Laptop Asus ASUS Transformer Pad TF300T Bruksanvisning

Tf300t (90 pages)

Laptop Asus Eee PC T91 User Manual

Windows xp edition (68 pages)

Laptop Asus TX201LA E-Manual

User's manual for english edition (154 pages)

Laptop Asus T100 Series E-Manual

T100 series notebook pc (102 pages)

Laptop ASUS T100 Series E-Manual

T100 series notebook pc (104 pages)

Laptop Asus T100 series E-Manual

Notebook pc (92 pages)

Laptop Asus T100 Manual

Device encryption rework sop (18 pages)

Laptop Asus TP550L User Manual

(118 pages)

Laptop Asus TP370QL User Manual

(17 pages)

Laptop Asus VivoBook Flip TP410 Series E-Manual

(108 pages)

Laptop Asus VivoBook Flip 14 E-Manual

(104 pages)

Laptop Asus Vivobook T3300KA Repair Manual

(23 pages)

# Summary of Contents for Asus Eee Pad Transformer Prime TF201

#### Page 1: Charging Your Batteries

E7135 Transformer User Manual TF201 Charging Your Batteries If you intend to use battery power, be sure to fully charge your battery pack before going on long trips. Remember that the power adapter charges the battery pack as long as it is plugged into the computer and an AC power source.

#### Page 2: Table Of Contents

Undocking the Transformer
Page 3 Sharing

#### Page 4: Package Contents

Package Contents Transformer USB Charger Power Plug Dock connector to USB cable User Manual Warranty Card • If any of the items is damaged or missing, contact your retailer. • The power plug that comes with your Transformer may vary depending on your territory to fit the wall outlet. ASUS Transformer Manual...

#### Page 5: Your Transformer

Your Transformer ASUS Transformer Manual...

#### Page 6: Power Button

If the system becomes unresponsive, press the reset button to force the Transformer to restart. Forcing the system to restart may result in data loss. Please inspect your data to ensure there is no data loss. We strongly recommend that important data be backed up regularly. ASUS Transformer Manual...

<u>Page 7</u> Using this jack automatically disables the built-in speaker. For microphone input function, the jack best supports headset microphones by ASUS. Built-in Rear Camera Use the built-in camera for picture taking, video recording, video conferencing, and other interactive applications.

#### Page 8: Charging The Transformer

AC 100V-240V, and the output voltage of this adapter is DC 15V, 1.2A. • To prolong battery life, fully charge the battery for up to 8 hours when using the Transformer for the first time and whenever the battery power is fully depleted. • TF201 can be charged via the USB port on the computer only when it is powered off. • Charging through the USB port may take longer time to complete. • If the computer does not provide enough power for charging the Transformer, use the wall outlet instead. ASUS Transformer Manual...

#### Page 9: Transformer Mobile Dock (Optional)

Transformer Mobile Dock (optional) The Transformer mobile dock is purchased separately. Backspace Enter Caps Lock Shift Shift PgUp Ctrl Ctrl PgDp Home ASUS Transformer Manual...

<u>Page 10</u> Move the mobile docking latch to the left to release the Transformer from the mobile dock. Keyboard The keyboard provides comfortable travel (depth at which the keys can be depressed) and palm rest for both hands. The keyboard differs by territory. ASUS Transformer Manual...

#### Page 11: Using The Touchpad

Touchpad Click the touchpad area marked below to simulate the left and right mouse buttons. Use the hot key to disable the touchpad. Using the Touchpad ASUS Transformer Manual...

#### Page 12: Special Keyboard Functions

Toggles the internal wireless LAN ON or OFF. Toggles the internal Bluetooth ON or OFF. Toggles the touchpad ON or OFF. Decreases display brightness. Increases display brightness. Toggles the ambient light sensor ON or OFF. Captures screen image. PgUp Home ASUS Transformer Manual...

Page 13 Activates the properties menu and is equivalent to on the screen. PgUp PgDp Home PgUp PgDp Home PgUp PgDp Home PgDp PgDp Home Press <Fn> and arrow keys to scroll up and down or scroll to the start and end in documents. ASUS Transformer Manual...

#### Page 14: Docking The Transformer

Ensure that the latch completely moves to the right. When your Transformer is attached to the mobile dock, never pick up the Transformer alone. Always pick up the entire assembly from the bottom of the mobile dock. ASUS Transformer Manual...

#### Page 15: Undocking The Transformer

Undocking the Transformer Use one hand to move the latch to the left to release the Transformer and stabilize the mobile dock. Use the other hand to remove the Transformer from the mobile dock. ASUS Transformer Manual...

#### Page 16: Charging The Transformer On The Dock

AC 100V-240V, and the output voltage of this adapter is DC 15V, 1.2A. • To prolong battery life, fully charge the battery for up to 8 hours when using the Transformer for the first time and whenever the battery power is fully depleted. • The Transformer cannot be charged via USB cord when it is connected to the mobile dock. ASUS Transformer Manual...

#### Page 17: To Begin

Tap and drag the lock out from the circle to the lock icon to unlock your Transformer. Quick Camera Mode Tap and drag the lock out from the circle to the camera icon to enter the Camera mode. ASUS Transformer Manual...

#### Page 18: Home Screen

Open Google Text search Open Google Voice search Home Screen page scroll Shortcuts Display recent apps Notification area & Settings Return to Home Screen Return to the previous screen The Home Screen may update and change with Android OS. ASUS Transformer Manual...

#### Page 19: Asus Launcher

Display local weather information. Tap to customize weather widget settings, location, and frequency updates. Display local date Display your e-mail inbox. Tap to configure the email account for the first time, and tap to read unread e-mails in the e-mail inbox folder. ASUS Transformer Manual...

#### Page 20: Screen Views

Screen Views The screen view rotates by itself when you hold the tablet horizontally to vertically, and vice versa. To enable/ disable Auto-rotate screen, go to Settings>Display to configure. Landscape view Portrait view ASUS Transformer Manual...

#### Page 21: Touch Panel Control

• Tap and hold an application to drag and drop it or its shortcut to another Home Screen page. • Tap and hold the Recent Apps Key to capture screen images. (To enable Screenshot, go to Settings> ASUS customized setting) • Tap and hold a file in the Gallery to enter selection mode. Zooming Spread apart or bring two fingers together to zoom in or out an image in Gallery, Maps, or Places.

<u>Page 22</u> Tap or hold the desired text on the web page and a tool bar appears on the top. You can copy, share, select, find, or search on the web. ASUS Transformer Manual...

#### Page 23: Managing Apps

Apps menu. Tap and hold an app on your Home Screen. Remove will appear on the top of the Home Screen page. Drag the held app to Remove to clear it from the Home Screen. ASUS Transformer Manual...

<u>Page 24</u> Create folders to organize your applications and shortcuts on your Transformer Home Screen. On your Home Screen, tap and drag an app or shortcut onto another. A folder will appear. Tap the new folder and tap Unnamed Folder to rename the folder. ASUS Transformer

<u>Page 25</u> Swipe up and down the list to view Recent Apps. Swipe a recent app to the left or right to remove from list. Tap and hold a recent app to display menu. Select to remove app from list or display app information. ASUS Transformer Manual...

#### Page 26: Task Manager

Task Manager ASUS widget displays a list of currently running utilities and applications and their usages in percentages on your Transformer. Tap on the top right corner of the Home Screen to access the tablet utilities. Tap Widgets to display the widgets menu.

#### Page 27: File Manager

The Internal Storage (/sdcard/) and any connected external storage devices (/Removable/) are displayed on the left panel. Tap on the source icon on the left panel to display content list. Select a source by tapping to view the content. ASUS Transformer Manual...

<u>Page 28</u> Tap on the Return folder icon to return to the root directory of My Storage. To access the external storage device directly: Tap the USB or SD card icon on the bottom right corner. Tap on the folder icon in the pop-up notification box. ASUS Transformer Manual...

<u>Page 29</u> The content of the external storage device (Removable/XXX/) is displayed. To copy, cut, delete, or share files: Tick the file and tap on the action icon at the tool bar on the upper right. Or, tick the file and drag to drop in the destination. ASUS Transformer Manual...

#### Page 30: Market

Download the latest Adobe Flash Player version 11.1.112.60 for ICS devices. You cannot restore the deleted applications, but you can login with the same ID and download them again. ASUS Transformer Manual...

#### Page 31: Settings

Wireless & networks, Device, Personal, and System. Tap on the tabs on the left to switch screens and do the configurations. There are two ways to enter the Settings screen. From the Apps menu: Tap on Settings to display the settings menu. ASUS Transformer Manual...

<u>Page 32</u> From ASUS Quick Setting: Tap on the notification area on the bottom right corner. The Quick Setting panel will pop up on the right. Display local date and time Dock / Pad Internet Battery Status connection status Settings Menu Performance...

<u>Page 33</u> 1. Swipe a prompt update to the left or right to remove from list. 2. You can enable or disable ASUS Quick Setting to Simplified Mode in Settings> ASUS customized setting> NOTIFICATION PANEL.

#### Page 34: Power Management

Tap on the top right corner of the Home Screen to access tablet utilities. Tap on Widgets to display the widgets menu. Tap and hold ASUS Battery. The ASUS Battery box will appear on the Home Screen. ASUS Quick Setting and the notification panel also display battery status.

#### Page 35: Music

AMR-NB, AMR-WB, MP3, FLAC, MIDI, PCM/WAVE, Vorbis, WAV a-law/mu-law, WAV linear PCM, WMA 10, WMA Lossless, WMA Pro LBR Video Codec: H.263, H.264, MPEG-4, VC-1/WMV, VP8 Encoder Audio Codec: AAC LC/LTP, AMR-NB, AMR-WB Video Codec: H.263, H.264, MPEG-4 ASUS Transformer Manual...

#### Page 36: Image

You can play all image files in a slideshow, or tap to select your desired image or video files. Use the button on the top to sort the files by album, by location, by time, by people, or by tags. Select item or Group by Browse in slideshow mode The current album ASUS Transformer Manual...

<u>Page 37</u> Tap on a desired album in the gallery and hold until the tool bar on the top appears. You can upload, delete, or share selected albums through the Internet. Tool bar Share the

selected album through ASUS Webstorage, Bluetooth®, Picasa®, Google+®, or Gmail®. Album details Delete the selected album. ASUS Transformer Manual...

<u>Page 38</u> Tool bar Delete the selected image. Share the selected album through ASUS Webstorage, Bluetooth®, Picasa®, Check the image information, Google+®, or Gmail®. and edit the selected image. You cannot restore a deleted file. ASUS Transformer Manual...

<u>Page 39</u> Tap on Widgets to display the widgets menu. Tap and hold Photo Gallery. The gallery widget box will take you the Home Screen and a Choose images menu box appears. Choose the album or image(s) to place as a shortcut on the Home Screen. ASUS Transformer Manual...

#### Page 40: Camera

The image files will be saved to Gallery automatically. Camera mode Zoom in Camera switch Capture button Camera settings Zoom out Mode switch Flash Mode Return White Balance Exposure Advanced settings Scene Mode ASUS Transformer Manual...

<u>Page 41</u> Video mode White balance Torch mode Return Record button Effects Advanced settings Video quality Time lapse interval Panoramic mode Capture button Captured range Panoramic image ASUS Transformer Manual...

#### Page 42: Mail

To set up an Email account: Tap on Email on the Apps menu. Enter your Email address and Password, then tap Next. Please wait while the Transformer automatically checks your outgoing mail server settings. Configure the Account options and tap Next. ASUS Transformer Manual...

<u>Page 43</u> Tap on Settings on the top right corner. All the preferences of this account are displayed. Tap Add account on the top right corner to add another account. You can include all your e-mail accounts in Email. ASUS Transformer Manual...

#### Page 44: Gmail

Tap Done to sign in to your Gmail. If you have several e-mail accounts in addition to Gmail, use Email to save your time and access all your e-mail accounts at same time. ASUS Transformer Manual...

#### Page 45: Reading

Android Market to open. Download Adobe Flash® player before using MyLibrary. All your bookshelves Search directly Sort by title, author, date, or My Array Recent Read List and other settings Selection mode Login asus@vibe Books on the selected bookshelf Latest read ASUS Transformer Manual...

<u>Page 46</u> 2. Tap on the Bookmark list and select the marked page to show the bookmark icon on the upper right corner of the screen. Flip pages like a real book or move the page scroll at the bottom. ASUS Transformer Manual...

<u>Page 47</u> You can highlight the selected word with a marker, add a note, speak the selected text, or simply copy the word. Move selection tab to extend the selected region to a whole phrase or sentence if needed. ASUS Transformer Manual...

#### Page 48: Locating

Check-in to your current location for position acquisition. Google Maps Maps helps you locate where you are. Use the tool bar on the top to get directions or create your own maps. ASUS Transformer Manual...

#### Page 49: Documenting

To start using Polaris® Office: Tap on the top right corner of the Home Screen to access tablet utilities. In the Apps menu, tap Polaris® Office. Add new folder Settings Add new file Recent files Search file ASUS Transformer Manual...

<u>Page 50</u> 1. Polaris® Office 3.0 supports file types as below: • Microsoft Word: .doc/ .docx • Microsoft Excel: .xls/ .xlsx • Microsoft Powerpoint: .ppt/ .pptx • Adobe Acrobat: .pdf • Text: .txt • Images: .bmp/ .jpg/ .jpeg/ .png/ .gif/ .wbpm • Zip Archives: .zip 2. Polaris® Office 3.0 currently

saves files into .doc/ .xls/ .ppt formats only. ASUS Transformer Manual...

<u>Page 51</u> Google docs and Box.net. Tap on the settings button on the top right corner and select Add account. Select a desired service to add. Enter your e-mail account and password and tap OK to add the account. ASUS Transformer Manual...

#### Page 52: Configuring Settings

Configuring Settings Tap settings button on the top right corner and select Settings. You are allowed to configure File list settings and General settings. ASUS Transformer Manual...

#### Page 53: Sharing

Windows Media Player on the PC. (Go to "More streaming options..." to configure, if necessary.) On the Server list, select the source device on the left panel to view the contents. Source device Search and Settings Current source Content ASUS Transformer Manual...

<u>Page 54</u> 3G network. Network location for connecting devices must all be set to Home network. Long pressing a media file allows you to upload or download the file to and from the connecting devices. ASUS Transformer Manual...

<u>Page 55</u> To enable Digital Media Server, tap on Settings at the upper right corner and tick Digital Media Server Settings to allow the other connecting devices to access media files on your Transformer. You can also select the location of the file you want to share. ASUS Transformer Manual...

#### Page 56: Mycloud

Tap on MyCloud on the Apps Menu. Click Next to continue. MyCloud needs to work with ASUS Pad PC Suite to avail its full function. Download and install ASUS Pad PC Suite from the ASUS support site at support.asus.com to your PC. Click Next to continue.

<u>Page 57</u> Tap I have an account to sign in or tap Create an account to create your free account. After signing in, you will see all your data stored in ASUS Webstorage. Locate your data according to its category. ASUS Transformer Manual...

<u>Page 58</u> My Desktop allows you to remotely control your other PC from your Transformer. You will need to download ASUS Pad PC Suite to your PC first to enable My Desktop on your Transformer. To install and set up Transformer PC...

<u>Page 59</u> Read the license agreement and click Accept to continue. Create a password and click Next. Click Enjoy Now to continue. Copy the IP address of your PC for later use on your Transformer. ASUS Transformer Manual...

<u>Page 60</u> Ensure that your Transformer and the PC are connected to the same wireless access point (AP). Access My Desktop. Tap the screen to scan the available devices. Tap on the plus sign (+) on the top right corner to add your client PC. ASUS Transformer Manual...

<u>Page 61</u> PC and tap Done to add the client. The devices must be connected to the same wireless access point (AP) while enabling My Desktop. Accordingly, My Desktop will not be able to function when connecting through 3G network. ASUS Transformer Manual...

<u>Page 62</u> Setting up Internet Discovery for My Desktop On your PC: Download and activate Splashtop Streamer from the ASUS support site. Go to Network in Splashtop Remote Streamer. Enter your Google credentials in the Email and Password fields. Then click Sign in.

<u>Page 63</u> TV anytime and anywhere. The contents supplied may vary with the country of origin. Login with your ASUS Access account to enjoy the multimedia content at @ Vibe. Tap on Apps menu and tap @Vibe.

#### Page 64: App Locker

Activate App Locker from Settings on the upper right corner. Lock signs will appear by the locked apps on the Home Screen. You will be asked for your password every time you access the locked apps. ASUS Transformer Manual...

#### Page 65: App Backup

File Manager at the lower right of the dialog box to select the external storage location to duplicate backup app files. Key in the file name of new backup file to create and select OK. Backup files are automatically stored in App\_Backup folder in internal storage and selected external storage. ASUS Transformer Manual...

<u>Page 66</u> Tap on a backup file to restore or click on Browse at the upper right to access files in the internal or external storage. Enter file password to decrypt the backup file and restore contents to your Transformer. ASUS Transformer Manual...

#### Page 67: Supernote

All your notebooks and paintbooks Delete, copy, move, import or export pages Setting, View books backup, Sort by page or last modified restore Pages and contents ASUS Transformer Manual...

<u>Page 68</u> On the upper right, tap on Share to share by e-mail, webstorage, social networks, or online gallery. Insert/ Delete page All pages view SuperNote return path Add to Favorites Share and Export Settings Page Scroll Page number Space Previous/ Next page Backspace Return ASUS Transformer Manual...

<u>Page 69</u> In Scribble mode, select Color and Stroke weight to customize strokes. Tap to set a spot for the text cursor, then scribble on the tablet. The manuscript will be automatically adjusted into the page lines. Tap on the Baseline function for penmanship guidelines, if necessary. ASUS Transformer Manual...

<u>Page 70</u> Tap on Undo to delete changes. Tap Redo to keep the changes. SuperNote automatically saves and sorts the files by date in /sdcard/ supernote. Insert/ Delete page Disable Edit Redo/ Undo ASUS Transformer Manual...

Page 71 Edit mode. Tapping on Select enables you to move, scale, rotate, or edit the selected area. A red dotted box will appear to designate the area. Tap on Done to return to Paintbook mode. Paintbook mode Edit mode ASUS Transformer Manual...

#### Page 72: Asus Pad Pc Suite (On Pc)

ASUS Pad PC Suite (on PC) ASUS Pad PC Suite consists of My Desktop PC Server, ASUS Webstorage and ASUS Sync. It is a package tool on your PC to co-work with your Transformer. My Desktop PC Server It is a remote desktop tool that works with My Desktop on your Transformer.

#### Page 73: Asus Sync

To synchronize your Transformer with your PC: Connect your Transformer to the PC, with the installed ASUS Pad PC Suite. Click the ASUS Sync on the bottom right corner to build the connection between your Transformer and the PC. Start ASUS Sync on your PC.

<u>Page 74</u> Click the item you want to synchronize and click Sync Selected, or you can click Select All to sync both items. Click Calendar or Contacts on the left for detailed configurations. ASUS Transformer Manual...

#### Page 75: Declarations And Safety Statements

FCC with the EUT transmitting at the specified power level in different channels. The highest SAR value for the device as reported to the FCC is 0.387 W/kg when placed next to the body. ASUS Transformer Manual...

#### Page 76: Ic Regulations

The County Code Selection feature is disabled for products marketed in the US/Canada. For product available in the USA/ Canada markets, only channel  $1\sim11$  can be operated. Selection of other channels is not possible. ASUS Transformer Manual...

#### Page 77: Ce Mark Warning

H05VV-F, 2G, 0.75mm ASUS Recycling/Takeback Services ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment.

We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials.

Page 78 (Froyo) and 2.3 (Gingerbread) devices and an initial beta release for Android 3.x (Honeycomb) tablets that include at least Google's 3.0.1 system update. For more details, please visit http://blogs.adobe.com/flashplayer/. Download the latest Adobe Flash Player version 11.1.112.60 for ICS devices. ASUS Transformer Manual...

#### Page 79: Copyright Information

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement. This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

Page 80 ASUS Transformer Manual...

#### This manual is also suitable for:

Tf201-b1-grTf201-c1-cgTf201-b1-cgTf201-c1-grTransformer tf201