



# Bios Setup Program - Asus P5E3 Premium WiFi-APn User Manual

User manual




1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200






•

[Table of Contents](#)

•

## Bookmarks





## 4.2

### BIOS setup program

This motherboard supports a programmable Serial Peripheral Interface (SPI) chip

that you can update using the provided utility described in section 4.1

Managing

and updating your BIOS.

Use the BIOS Setup program when you are installing a motherboard, reconfiguring

your system, or prompted to "Run Setup." This section explains how to configure your system using this utility.

Even if you are not prompted to use the Setup program, you can change the configuration of your computer in the future. For example, you can enable the security password feature or change the power management settings. This requires you to reconfigure your system using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM of the SPI chip.

The SPI chip on the motherboard stores the Setup utility. When you start up the computer, the system provides you with the opportunity to run this program. Press

<Del> during the Power-On Self-Test (POST) to enter the Setup utility; otherwise, POST continues with its test routines.

If you wish to enter Setup after POST, restart the system by pressing <Ctrl+Alt+Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on. Do this last option only if the first two failed.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.

.  
. .

4-8

The default BIOS settings for this motherboard apply for most conditions to ensure optimum performance. If the system becomes unstable after changing any BIOS settings, load the default settings to ensure system compatibility and stability. Select the Load Setup Defaults item under the Exit Menu. See section 4.9 Exit Menu.

The BIOS setup screens shown in this section are for reference purposes

only, and may not exactly match what you see on your screen.

Visit the ASUS website ([www.asus.com](http://www.asus.com)) to download the latest BIOS file for this motherboard.

Chapter 4: BIOS setup

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1  
...  
77  
78  
79  
80  
81  
82  
83  
84



Quick Links:

[Motherboard Overview](#)

[Motherboard Layout](#)

[System Memory](#)

[Memory Configurations](#)

[Jumpers](#)

[Internal Connectors](#)

## Related Manuals for Asus P5E3 Premium WiFi-APn

[Network Card Asus P5Q3 Deluxe WiFi-AP n User Manual](#)

User manual (44 pages)

[Motherboard Asus Crosshair II Formula - Republic of Gamers Series](#)

[Motherboard User Manual](#)

User manual (44 pages)

[Motherboard Asus A7N266-VM AA User Manual](#)

User manual (8 pages)

[Motherboard Asus P5E3 DELUXE WiFi-AP User Manual](#)

Wifi-ap@n user's manual (194 pages)

[Motherboard Asus P5E3 WS PRO User Manual](#)

User manual (172 pages)

[Motherboard Asus P5E64 WS Pro Installation Manual](#)

Motherboard installation guide (180 pages)

[Motherboard Asus P5E Deluxe - Ai Lifestyle Series Motherboard User Manual](#)

User manual (174 pages)

[Motherboard Asus P5E WS PROFESSIONAL User Manual](#)

User manual (44 pages)

[Motherboard Asus P5E WS PROFESSIONAL User Manual](#)

User manual (172 pages)

[Motherboard Asus P5E - AiLifestyle Series Motherboard Instructions Manual](#)

Motherboard installation guide (176 pages)

[Motherboard Asus P5E-V HDMI User Manual](#)

User manual (162 pages)

[Motherboard Asus P5Q-VM DO User Manual](#)

User manual (104 pages)

[Motherboard Asus P5E-VM - Motherboard - Micro ATX User Manual](#)

User manual (156 pages)

[Motherboard Asus P5E-VM SE User Manual](#)

User manual (102 pages)

[Motherboard Asus P5E3 PRO User Manual](#)

User manual (62 pages)

[Motherboard Asus P5KPL User Manual](#)

(68 pages)

## Related Content for Asus P5E3 Premium WiFi-APn

[PRIME X299-A Series Bios Setup Program](#)

Asus PRIME X299-A Series

[ROG RAMPAGE V EDITION 10 Bios Setup Program](#)

Asus ROG RAMPAGE V EDITION 10

[Q170A-IM-A Bios Setup Program](#)

Asus Q170A-IM-A

[Z13PE-D16 Bios Setup Program](#)

Asus Z13PE-D16

[WS X299 SAGE Bios Setup Program](#)

Asus WS X299 SAGE

[Pro A620M-C-CSM Bios Setup Program](#)

Asus Pro A620M-C-CSM

[PRIME H310M-A R1.0 Bios Setup Program](#)

Asus PRIME H310M-A R1.0

[TUF GAMING B650-E WIFI Bios Setup Program](#)

