

# Asus AiGuruSV1T User Manual

Internet video phone

18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			

Table of Contents

•

Bookmarks

•

# Quick Links

1 Advanced Settings

Download this manual







**Table of Contents** 

Next Page

### Related Manuals for Asus AiGuruSV1T

Telephone Asus Eee Videophone AiGuru SV1T User Manual Internet video phone (34 pages) Telephone Asus ASUS Z01FD User Manual (54 pages) Telephone Asus ZD553KL Service Manual (55 pages) Telephone Asus ZB551KL Training & Trouble Shouting Manual Board level (69 pages) Telephone Asus X007D User Manual (86 pages) Telephone Asus Zenfone Z01KD User Manual (28 pages) **Telephone Asus E9995 User Manual** (29 pages) **Telephone Asus AiGuru S2 Manual** Wireless skype phone (106 pages) Telephone Asus AiGuru U1 User Manual Usb phone for skype (38 pages) **Telephone Asus ROG ZS660KL User Manual** (92 pages) **Telephone Asus P320 Service Manual** (33 pages) Telephone Asus ZB553KL User Manual (106 pages) Telephone Asus Go ZB500KL User Manual (32 pages) Telephone Asus AiGuru U1 Quick Start Manual (56 pages)

# Summary of Contents for Asus AiGuruSV1T

Page 1 AiGuru SV1T Internet Video Phone User Manual...

<u>Page 2</u> ASUSTEK COMPUTER, INC. ("ASUS"). Products and corporate names mentioned in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used for identification purposes only.

#### Page 3: Table Of Contents

Page 4 Contents Contacts	27 Viewing a Contac	t27 Adding a Contact
	ontact	
See myself	Account	

#### Page 5: Notices

The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. ASUS AiGuru SV1T...

#### Page 6: Safety Precautions

WARNING: Vital information that you MUST follow to prevent injury to yourself. IMPORTANT: Instructions that you MUST follow to complete a task. TIP: Tips and useful information that help you complete a task. NOTE: Additional information for special situations. ASUS AiGuru SV1T...

#### Page 7: Safety Information

• The supplied battery model is ASUS, AL21-SV1. Risk of explosion Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the manufacturer's instructions.

<u>Page 8</u> The device performance changes. This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products. ASUS AiGuru SV1T...

#### Page 9: Welcome

Get started by creating your own unique Skype Name and then signing in—done directly on ASUS AiGuru SV1T. You will soon be enjoying free Skype-to-Skype calls to friends and family. And best of all, you will hear them with excellent sound quality and see them in perfect vision.

#### Page 10: Package Contents

Package contents Congratulations on your purchase of ASUS AiGuru SV1T. The following illustration displays the package contents of your new videophone. If any of the below items is damaged or missing, contact your retailer. AiGuru SV1T AC adapter Power cord...

#### Page 11: Aiguru Sv1T Product Specifications

5-way Navigation keys (Up, Down, Left, Right, and Select) Keys Menu key Back key Call key End key 3.5 mm Headphone jack and Microphone jack RJ-45 connector I/O connectors USB type A connector DC Jack Battery connector ASUS AiGuru SV1T...

#### Page 12: Getting To Know Your Sv1T

This built-in webcam allows you to make video calls and can also take a snapshot of yourself. Webcam LED This LED lights up green to indicate that the webcam is activated. Microphone This is a built-in microphone. ASUS AiGuru SV1T...

<u>Page 13</u> Press to go directly to the idle screen. Volume keys Press to increase/decrease the volume. Call key Press to dial or answer calls. From the idle screen, press to show the Contact list. Menu key Press to go directly to the main menu. ASUS AiGuru SV1T...

#### Page 14: Rear View

Headphone jack This jack allows you to connect amplified speakers or headphones. Using this jack automatically disables the built-in speakers. LAN port The RJ-45 LAN port supports a standard Ethernet cable for connection to a local network. ASUS AiGuru SV1T...

#### Page 15: Installing The Battery

Installing the battery Lay the device on its back with the screen facing up. Use your thumbs to release the battery compartment cover tabs to open the cover. Insert the battery into the battery compartment noting the correct orientation. ASUS AiGuru SV1T...

### Page 16: Turning On The Videophone

Turning on the videophone Connect the supplied AC adapter to the DC IN jack on the rear panel, and then press the power button to turn on the device. The device screen lights up to show the

Skype welcome message. ASUS AiGuru SV1T...

#### Page 17: Setting Up Your Sv1T

Setting up your SV1T Using the touch screen Use the touch screen to set up your SV1T, make calls, and use other functions. • Drag left or right on the top or bottom to scroll the Menu screen or the Contacts screen. •...

#### Page 18: Basic And Network Settings

Wireless connection (not plugging in the Ethernet cable) A list of wireless networks displays. Double-tap or highlight one you have access to and then press the Select key to start connecting. If the network is secured, enter the password using the onscreen keyboard. ASUS AiGuru SV1T...

Page 19 OK. To set day, month, and year, follow the instructions as above. When done, select To set time zone, double-tap or press the Up/Down key to highlight your time zone and press the Select key to confirm. ASUS AiGuru SV1T...

<u>Page 20</u> Select key to enter. When done, tap or highlight the onscreen Enter key then press the Select key to confirm. Select the Delete key to delete text. Select ABC display more text options. ASUS AiGuru SV1T...

<u>Page 21</u> You will be asked if you would like to take a video snapshot of yourself to use in your profile. Select Yes and the device webcam will be activated. Select Snapshot and your photo will be taken. ASUS AiGuru SV1T...

#### Page 22: Using Your Sv1T

(from left to right): Settings, Search, Add Contact, Call phones, Contacts, History, Status, See myself, and Account. Drag left and right or press the Left and Right keys to display more menu options. When an option is focused, its icon is enlarged. ASUS AiGuru SV1T...

#### Page 23: Calls

When a tab is in focus, press the Select key to jump letter by letter. To call landlines or mobile phones, you will need to buy Skype Credit or a Skype subscription. Visit www.skype.com for more information. ASUS AiGuru SV1T...

<u>Page 24</u> Mute: select to mute/unmute. • Hold call: select to hold call/resume call. View profile: select to view Contact profile. • To terminate a call, tap on the right side of the screen or press the End key ASUS AiGuru SV1T...

#### Page 25: Calling A Mobile Or Telephone Number

To terminate a call, tap on the right side of the screen or press the End key To call landlines or mobile phones, you will need to buy Skype Credit or a Skype subscription. Visit www.skype.com for more information. ASUS AiGuru SV1T...

#### Page 26: Answering Calls

When you have an Incoming call, a full screen dialog appears with information on the incoming caller. Select Accept or press the Call key to answer the call. To have calls accepted automatically, go to Settings > Calls > Auto-answer incoming calls. ASUS AiGuru SV1T...

#### Page 27: Contacts

The Action list displays options that may vary with Contacts. You can make a Video call, a Voice call, or Send voicemail to the Contact. You can also View profile, Rename, Remove, or Block the Contact, and send Request details. ASUS AiGuru SV1T...

#### Page 28: Adding A Contact

Enter a Skype Name or telephone number using the onscreen keyboard or dialpad. When done, select the onscreen Enter key. Searching a Contact From the main menu, select Enter a Skype Name, user Search. name, or e-mail address to find a Skype Contact. ASUS AiGuru SV1T...

### Page 29: History

The number opposite to an event indicates how many events require action. For example, the screen on the right shows there are three Voicemails that have not been listened. Select Voicemails and then select each voicemail to perform further action. ASUS AiGuru SV1T...

### Page 30: Status

Account Select Account from the main menu to view your account details. You will be able to check your Skype Credit balance and check your subscriptions (for example, voicemail or online numbers). Visit www.skype.com for more information. ASUS AiGuru SV1T...

#### Page 31: Settings

Go to Settings > Network. To change connection from Wired to Wireless, select Change connection and follow the instructions in step 3A on page 17. To modify your wired connection type, select Current connection > Modify connection. ASUS AiGuru SV1T...

<u>Page 32</u> If you use a router, select IP Select Configure addresses. automatically (the other options become unavailable). Static IP connection Enter IP address, Subnet If you have a static IP, select IP addresses. mask and other information using the onscreen dialpad. ASUS AiGuru SV1T...

#### Page 33: Advanced Settings

Select Yes. The device will download and install the latest software from the Internet. Device reset: restoring the device to its factory settings Select Device reset. Choose to Reset everything or Reset all except network. ASUS AiGuru SV1T...

Page 34 The "Reset device?" dialog appears. Select Yes to confirm the action. ASUS AiGuru SV1T...

# This manual is also suitable for:

Sv1ts - skype video phone touchAiguru sv1t