



Asus HDP-R1 - O!Play - Digital Multimedia Receiver User Manual

Hd media player

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38

--

•

[Table of Contents](#)

-

Troubleshooting


•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [User Manual](#)



O!Play
ASUS®

HD Media Player

User Manual

ASUS®

HDP-R1

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus HDP-R1 - O!Play - Digital Multimedia Receiver

[Media Player ASUS O!Play HDP-R1 User Manual](#)

Hd media player o!play (45 pages)

[Media Player Asus HDP-R3 User Manual](#)

Asus portable multimedia player user manual (49 pages)

[Media Player Asus O!PLAY HD2 E5763 User Manual](#)

Asus mp3 player user manual (76 pages)

[Media Player Asus O!Play HD2 User Manual](#)

(8 pages)

[Media Player Asus O!Play HD2 Quick Start Manual](#)

(189 pages)

[Media Player Asus O!Play HD2 User Manual](#)

Media player with usb 3.0 (3 pages)

[Media Player Asus O!Play HD2 Quick Start Manual](#)

(358 pages)

[Media Player Asus O!Play Live User Manual](#)

User manual (66 pages)

[Media Player Asus O!PLAY MINI PLUS User Manual](#)

Hd media player (64 pages)

[Media Player Asus Nexus Player TV500I User Manual](#)

(49 pages)

[Media Player Asus Clique R100 Quick Start Manual](#)

Wireless music streamer (2 pages)

[Media Player Asus ASUS CUBE with Google TV User Manual](#)

Media streamer (66 pages)

[Media Player Asus O!PLAY MINI PLUS User Manual](#)

Hd media player (70 pages)

[Media Player Asus O!PLAY GALLERY User Manual](#)

Hd media player (72 pages)

[Media Player Asus O!Play Quick Start Manual](#)

(3 pages)

[Media Player Asus Clique R100 Quick Start Manual](#)

Wireless music streamer (2 pages)

Summary of Contents for Asus HDP-R1 - O!Play - Digital Multimedia Receiver

[Page 1](#) O!Play HD Media Player User Manual HDP-R1...

[Page 2](#) Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

[Page 3: Table Of Contents](#)

Contents	Contents	iii	Notices	v	Federal Communications Commission Statement	v	Canadian Department of Communications Statement	v	REACH Notice	vi	Important Safety Instructions	vii	Conventions used in this guide	viii	Where to find more information	viii	Chapter 1: Product introduction	
Introduction																		

3.4.2 Viewing photos in slideshow mode	3-8	3.4.3 Photo setup	3-9
Appendix Troubleshooting guide	A-2	Display	A-2
Audio	A-3	USB Device	A-4
Remote Control	A-4	Firmware Update	A-5
ASUS contact information	A-6...		

[Page 5: Notices](#)

Notices Federal Communications Commission Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: • This device may not cause harmful interference, and • This device must accept any interference received including interference that may cause undesired operation.

[Page 6: Reach Notice](#)

REACH Notice Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://green.asus.com/english/REACH.htm>.

[Page 7: Important Safety Instructions](#)

Important Safety Instructions • Read these instructions. • Keep these instructions. • Heed all warnings. • Follow all instructions. • Do not use this apparatus near water. • Clean only with dry cloth. • Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

[Page 8: Conventions Used In This Guide](#)

Refer to the following sources for additional information and for product and software updates. ASUS websites The ASUS website provides updated information on ASUS hardware and software products. Refer to the ASUS contact information. Optional documentation Your product package may include optional documentation, such as warranty flyers, that may have been added by your dealer.

Page 9 Chapter 1 This chapter describes the general features of the ASUS O!Play HD media ASUS O!Play HD media player including specifications, front including specifications, front / side / rear panel features, and LED definitions. This chapter also includes the key table for the remote control.

[Page 10: Chapter 1: Product Introduction](#)

Introduction Thank you for choosing the ASUS O!Play HD media player, a device that allows you to enjoy digital media files from your PC or portable USB/eSATA storage devices to your TV or entertainment system. Enjoy new levels of entertainment by accessing, viewing, and playing media files with the ASUS O!Play HD media...

[Page 11: Product Features](#)

Storage LED Status Description Power No power is supplied Power is supplied but system is off Blue Power is supplied and system is on Storage No storage device was found A storage device is plugged ASUS O!Play HD media player...

[Page 12: Side Panel](#)

1.4.2 Side panel The side panel features one USB port and one eSATA / USB combo port for your USB and eSATA storage devices. USB port Reset button eSATA / USB combo port Refer to the rear panel connector descriptions below. •...

[Page 13: Rear Panel](#)

HDMI port. This port is for a high-definition multimedia interface (HDMI) connector. • LAN (RJ-45) port. This port allows connection to a Local Area Network (LAN) through a network hub. • Power

socket. This socket connects the power adapter. ASUS O!Play HD media player...

[Page 14: Remote Control](#)

1.4.4 Remote control Use the remote control to power on/off the O!Play HD media player, browse through menus, and select media to play, view, or listen to. Refer to the table on the next page for the description of the remote control buttons. Power on/off Display DISPLAY...

[Page 15](#) Press to select the language of the video you are watching SETUP Open the Setup menu PHOTO Press to quickly enter Photos mode Toggles to shuffle the order of the music files in the connected Music shuffle storage device ASUS O!Play HD media player...

[Page 16: Technical Specifications](#)

1.5 Technical specifications Network TCP/IP (DHCP or Static IP Address) 10/100Mbps Wired LAN Supported video formats MPEG1/2/4, H.264, VC-1, RM/RMVB Supported video file .mp4, .mov, .xvid, .avi, .divx, .asf, .wmv, .mkv, .rm, .rmvb, extension .flv, .ts, m2ts, .dat, .mpg, .vob Supported audio formats MP3, WAV, AAC, OGG, WAV, FLAC, AIFF Supported image formats JPEG, BMP, PNG, GIF, TIFF...

[Page 17](#) Chapter 2 This chapter provides information on how to set up the HD media player.

[Page 18: Chapter 2: Setup Information](#)

Connecting the O!Play HD media player Below is an illustration of how devices may be connected to the ASUS O!Play HD media player. Desktop PC or Notebook SLENDID MENU LAN (RJ45) USB / eSATA AI-FLASH Router TV/Home Theater To connect the HD media player: Connect the HD media player to your television and audio device.

[Page 19: Setting Up The Hd Media Player](#)

The IP address of the HD media player and that of the PC should be in the same workgroup and subnet. A pop-up message Save Network Setting appears. Select OK to save the setting or CANCEL to discard the setting. ASUS O!Play HD media player...

[Page 20: Network Neighborhood Setup](#)

2.2.2 Network neighborhood setup The network neighborhood function allows you to easily access the shared folder (s) on a connected computer via the HD media player. To set up the network neighborhood function under Windows XP OS: ® Create a folder named HD, for example, on the Windows desktop of the computer to be connected, and place the media files in the folder.

[Page 21: System Setup](#)

To set the time, press OK to enter Time, then use up / down keys to increase or decrease the value and left / right keys to move to the other parts. When done, press OK to save the setting. ASUS O!Play HD media player...

[Page 22](#) Chapter 2: Setup information...

[Page 23](#) Chapter 3 This chapter provides information on how chapter provides information on how provides information on how to enjoy media contents using the HD media player.

[Page 24: Chapter 3: Enjoying Media Contents](#)

Home screen menu Below is the Home screen menu of the HD media player. Use the remote control to navigate through the menus. Refer to Chapter 1 for remote control key functions. Home screen options There are five main Home options for you to choose from: Movies, Music, Photo, Setup, and File Copy.

[Page 25: Playing Video](#)

Select OK to resume playback or CANCEL to start playback from the beginning. ASUS O!Play HD media player...

[Page 26: Video Control Buttons On The Remote Control](#)

Video control buttons on the remote control Button Function DISPLAY Press to display the video file source, file name, format, and elapsed DISPLAY time Go back to the previous screen DISPLAY Play/pause DISPLAY Rewind Press the button repeatedly to change the rewinding speed to x1.5, x2, x4, DISPLAY x8, x16, x32, or normal speed (x1) DISPLAY...

[Page 27: Listening To Music](#)

Network, then press <OK>. Then, locate the music file you want to play. You can preview the information about the music file to be played. To play the file, press <OK> or the <Play/Pause> button. ASUS O●Play HD media player...

[Page 28: Music Control Buttons On The Remote Control](#)

Music control buttons on the remote control Button Function DISPLAY Press to display the video file source, file name, format, and elapsed DISPLAY time Go back to the previous screen DISPLAY Play/pause DISPLAY Rewind Press the button repeatedly to change the rewinding speed to x1.5, x2, x4, x8, x16, x32, or normal speed (x1) DISPLAY Forward...

[Page 29: Viewing Photos](#)

Network, then press <OK>. Then, locate the image file you want to view. You can preview the information about the image file to be displayed. To display the file, press <OK> or the <Play/Pause> button. ASUS O●Play HD media player...

[Page 30: Viewing Photos In Slideshow Mode](#)

Photo control buttons on the remote control Button Function DISPLAY Press to display the image file source, file name, format, and elapsed DISPLAY time Go back to the previous screen DISPLAY DISPLAY Play/pause the slideshow DISPLAY Stop the playback DISPLAY DISPLAY DISPLAY Skip to the previous image file...

[Page 31: Photo Setup](#)

Select the effect displayed between slides in a slideshow. You can select the transition effect from Off, Cross Fade, Left to Right, Top to Bottom, Waterfall, Snake, Dissolve, Strip Left Down, and All Effect Shuffle. ASUS O●Play HD media player...

[Page 32](#) 3-10 Chapter 3: Enjoying media content...

[Page 33: Appendix](#)

Appendix This chapter presents solutions to common problems that you may encounter when installing, setting up, or using the HD media player and offers the ASUS contact information..

[Page 34: Troubleshooting Guide](#)

Troubleshooting guide This troubleshooting guide provides answers to some common problems that you may encounter while installing and/or using ASUS O●Play HD media player. These problems require simple troubleshooting that you can perform by yourself. Contact ASUS Technical Support if you encounter problems not mentioned in this section.

[Page 35: Audio](#)

If you are using the multiple audio Amplifier, the RAW setting should be enabled. • If you are watching a video that supports multiple audio channels, press Audio Options button repeatedly until the intended audio channel is displayed. ASUS O●Play HD media player...

[Page 36: Usb Device](#)

I can't hear any sound when I'm playing music files. • Ensure that the audio cables are properly connected. • If the audio cables are connected to your TV, the TV must be turned on to play any music files. •...

[Page 37: Firmware Update](#)

Go to Setup > System > System Update to perform the firmware upgrade • process. • If you are still unable to update the firmware, reset the system and perform the updating process

again. ASUS O^oPlay HD media player...

[Page 38: Asus Contact Information](#)

+1-510-739-3777 +1-510-608-4555 Web site usa.asus.com Technical Support Telephone
+1-812-282-2787 Support fax +1-812-284-0883 Online support support.asus.com ASUS
COMPUTER GmbH (Germany and Austria) Address Harkort Str. 21-23, D-40880 Ratingen,
Germany +49-2102-959911 Web site www.asus.de Online contact www.asus.de/sales Technical
Support Component Telephone +49-1805-010923...