



# Asus NX1101 User Manual

Gigabit pci network adapter



1  
2  
3  
4

--

•

## Bookmarks

[Download this manual](#)

## Quick Links



# **NX1101**

**Gigabit PCI Network Adapter**

**1**



[Next Page](#)

1  
2  
3  
4

## Related Manuals for Asus NX1101

### [PCI Card Asus NX1001 Quick Installation Manual](#)

Pci fast ethernet adapter (4 pages)

### [PCI Card Asus PCE-AC55BT Quick Start Manual](#)

802.11ac wireless dual-band with bluetooth 4.0 pci-e adapter (for 802.11 a/g/b/n/ac wireless networks) (2 pages)

### [PCI Card Asus Hyper M.2 x16 Gen 4 Quick Start Manual](#)

(10 pages)

### [PCI Card Asus S370-DL Installation Manual](#)

(8 pages)

### [PCI Card Asus XONAR DX Quick Start Manual](#)

Xonar dx quick start guide for english (10 pages)

### [PCI Card Asus Xonar DG SI User Manual](#)

Pci 7.1 & headphone amp audio card (52 pages)

### [PCI Card Asus PCE-AC56 Quick Start Manual](#)

Dual-band wireless pci-e adapter (for 802.11 a/g/b/n/ac wireless networks) (2 pages)

### [PCI Card Asus WL-130g User Manual](#)

Wifi-g 54mbps pci ap/wlan adapter (46 pages)

### [PCI Card Asus Xonar D1 Quick Start Manual](#)

Pci audio card (10 pages)

### [PCI Card Asus ROG Xonar Phoebus Quick Start Manual](#)

7.1 channel pci express audio card (73 pages)

### [PCI Card Asus PCE-N53 User Manual](#)

Wireless dual-band pci-e card (for 802.11 a/b/g/n wireless networks) (35 pages)

### [PCI Card Asus DVI-ADD2 Installation Manual](#)

Pci express digital display card (9 pages)

### [PCI Card ASUS PCI-SC896 User Manual](#)

2ch. ultra2 pci scsi card (34 pages)

### [PCI Card Asus Xonar D-Kara User Manual](#)

Pci 5.1 karaoke audio card (44 pages)

### [PCI Card Asus PCI-L101 User Manual](#)

10/100 fast ethernet pci card (28 pages)

## Summary of Contents for Asus NX1101

[Page 1](#) ✕ NX1101 Gigabit PCI Network Adapter...

### [Page 2: Package Contents](#)

Introduction Thank you for purchasing the ASUS NX1101 Gigabit Network Adapter! It is a high performance 10BASE-T, 100BASE-TX, and 1000BASE-T network adapter with Windows Plug and Play for PCI local bus computers. Features • Integrated 10/100/1000 transceiver • Auto-Negotiation with Next page capability •...

[Page 3](#) 2. Open your PC case and find an available PCI slot on the motherboard. 3. Insert the ASUS NX1101 into the PCI slot until all contacts are seated. 4. Secure the ASUS NX1101 bracket

to your PC chassis with a screw.

## [Page 4: Technical Specifications](#)

Status Indicators and Ports 10/100 ACT: Blinking: Data transferring at 10 or 100Mbps 1000 ACT: Blinking: Data transferring at 1,000Mbps RJ-45: This is a port used to connect the Ethernet cable RJ-45 Technical Specifications Communication Standards Compliant with IEEE 802.3z Full Duplex flow control IEEE 802.3x IEEE 802.1q VLAN tagging 10BASE-T:...