



# Battery Types - Toshiba PSPB0U-00W008 User Manual

User manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18


## Table Of Contents

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175



•



- 

Troubleshooting

•

## Bookmarks





## DC IN indicator

---

Check the DC IN indicator to determine the power status with the AC adapter connected:

Blue

No light

## Power indicator

---

Check the Power indicator to determine the power status with the AC adapter connected:

Blue

Blinking Amber

No light

---

## Battery types

The computer has two types of batteries:



Battery pack



Real Time Clock (RTC) battery

### Battery pack

When the AC adapter is not connected, the computer's main power source is a removable lithium ion battery pack, also referred to in this manual as the battery.

You can purchase additional battery packs for extended use of the computer away from an AC power source.

The battery is a disposable item. When its operation becomes short even when fully charged, replace it with a new one.

#### User's Manual

Indicates the AC adapter is connected and is correctly supplying power to the computer.

Indicates the AC adapter is not connected.

Indicates power is being supplied and the computer is turned on.

Power indicator is located inside of the Power Button (depending the model you purchased) and in the front of the computer.

Indicates power is being supplied to the computer while the computer is in Sleep mode.

Under any other conditions, the indicator does not light.

#### Power and Power-Up Modes

6-3

[Previous Page](#)  
[Next Page](#)

1

...

101

102

103

104



## Related Manuals for Toshiba PSPB0U-00W008

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba P15-S4091 User Manual](#)

P15-s4091 user's guide (240 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P25-S509 User Manual](#)

P25-s509 user's guide (230 pages)

[Laptop Toshiba PSPB3U-01V00L Brochure](#)

Brochure (2 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba P500-ST5801 User Manual](#)

P500-st5801 user's guide (254 pages)

[Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

## Related Content for Toshiba PSPB0U-00W008

[Satellite Pro A300D Series Battery Types](#)

Toshiba Satellite Pro A300D Series

[Satellite Pro R50-B series Battery Types](#)

Toshiba Satellite Pro R50-B series

[AC100 Battery Types](#)

Toshiba AC100

[Satellite A500 series Battery Types](#)

Toshiba Satellite A500 series

[Satellite L630 Series Battery Types](#)

Toshiba Satellite L630 Series  
[Satellite P500 Battery Types](#)

Toshiba Satellite P500  
[Satellite L500 Battery Types](#)

Toshiba Satellite L500  
[Z30-B Battery Types](#)

Toshiba Z30-B

This manual is also suitable for:

[P200 series](#)