

Windows Special Keys; Number Pad; Generating Ascii Characters - Toshiba PSPB0U-00W008 User Manual

User manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18


Table Of Contents

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175




•

-

Troubleshooting

•

Bookmarks



Windows special keys

The keyboard provides two keys that have special functions in Windows Vista. One activates the Start menu and the other has the same function as the secondary mouse button.

This key activates the Windows Vista Start menu

This key has the same function as the Right mouse button.

Number Pad



The number pad is activated by pressing the Num Lock key, the LED will appear when active. Use the keypad to type numbers and generate ASCII



characters.

Generating ASCII characters

Not all ASCII characters can be generated using normal keyboard operation. But, you can generate these characters using their ASCII codes.

With the Num lock on:

1. Hold down Alt.
2. Using the number pad keys, type the ASCII code.
3. Release Alt, and the ASCII character appears on the display screen.



With the Num Lock off:

1. Hold Alt + Fn.
2. Using the number pad keys, type the ASCII code.
3. Release Alt + Fn, and the ASCII character appears on the display screen.



User's Manual
The Keyboard
5-4

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
96
97
98
99
100
101
102
103

Related Manuals for Toshiba PSPB0U-00W008

[Laptop Toshiba Satellite P200 Maintenance Manual](#)

(251 pages)

[Laptop Toshiba P205-S6277 User Manual](#)

P205-s6277 user's guide (242 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(238 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

(220 pages)

[Laptop Toshiba Satellite Pro P200 Series User Manual](#)

(194 pages)

[Laptop Toshiba Satellite P200 Series User Manual](#)

Toshiba laptop user's manual p200 (194 pages)

[Laptop Toshiba Satellite P200 Series Maintenance Manual](#)

(193 pages)

[Laptop Toshiba P200 Series User Manual](#)

Toshiba dvd video player user's manual (183 pages)

[Laptop Toshiba P15-S4091 User Manual](#)

P15-s4091 user's guide (240 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba P25-S509 User Manual](#)

P25-s509 user's guide (230 pages)

[Laptop Toshiba PSPB3U-01V00L Brochure](#)

Brochure (2 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba P500-ST5801 User Manual](#)

P500-st5801 user's guide (254 pages)

[Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

[Laptop Toshiba Satellite P20-8PW User Manual](#)

Toshiba satellite p20-8pw: user guide (142 pages)

Related Content for Toshiba PSPB0U-00W008

[Satellite A660D Series Windows Special Keys](#)

[Toshiba Satellite A660D Series](#)

[Satellite L635 Series Windows Special Keys](#)

[Toshiba Satellite L635 Series](#)

[Satellite C660 Series Windows Special Keys](#)

Toshiba Satellite C660 Series

[Satellite Pro L450 Series Windows Special Keys](#)

Toshiba Satellite Pro L450 Series

[Satellite L650D Series Windows Special Keys](#)

Toshiba Satellite L650D Series

[Satellite Pro A300D Series Windows Special Keys](#)

Toshiba Satellite Pro A300D Series

[Portege 2010 Windows Special Keys](#)

TOSHIBA Portege 2010

[NB100 Series Special Windows ® Keys](#)

Toshiba NB100 Series

This manual is also suitable for:

[P200 series](#)